

[Manuals.plus](#) /

› [iBUYPOWER](#) /

› iBUYPOWER Slate Gaming PC SWI9N5703 User Manual

iBUYPOWER SWI9N5703

iBUYPOWER Slate Gaming PC SWI9N5703 User Manual

INTRODUCTION

This manual provides essential information for the setup, operation, maintenance, and troubleshooting of your iBUYPOWER Slate Gaming PC Desktop Computer, model SWI9N5703. Please read this manual thoroughly before using your new computer to ensure proper functionality and longevity.

SWI9N5703

Best for 1440P Gaming



Slate 9 Gaming PC



**Intel Ultra 9
285 Processor**



Powering Advanced AI

**NVIDIA GeForce RTX
5070 12GB GPU**



32GB RAM (2 x 16GB)
DDR5 5200MHz



2TB SSD
High-Speed & Modern
NVMe SSD

Image: Front view of the iBUYPOWER Slate Gaming PC SWI9N5703, showcasing its design and RGB lighting.

WHAT'S INCLUDED

The following items are included with your iBUYPOWER Slate Gaming PC SWI9N5703:

- iBUYPOWER Slate Gaming PC Desktop Computer (SWI9N5703)
- Wired RGB Gaming Keyboard
- Wired RGB Gaming Mouse
- Power Cable
- Extra SATA Cable
- Wi-Fi Antenna
- User Manuals



Image: The complete package contents of the iBUYPOWER Slate Gaming PC, showing the computer, keyboard, mouse, and accessories.

SETUP

1. Unpacking

Carefully remove the computer and all accessories from the packaging. Retain the packaging for future transport or warranty claims.

2. Connecting Peripherals

- **Monitor:** Connect your monitor to the graphics card's HDMI or DisplayPort output. Ensure the cable is securely fastened.
- **Keyboard and Mouse:** Connect the included gaming keyboard and mouse to any available USB ports on the rear of the PC.

- **Audio:** Connect speakers or headphones to the audio output jacks on the rear or front of the PC.
- **Network:** For a wired connection, connect an Ethernet cable to the RJ-45 port. For wireless, attach the included Wi-Fi antenna to the designated ports on the rear.



Convenient Front I/O Ports

Easily accessible USB ports on front panel.
There are even more ports on the PC's back as part of the motherboard I/O ports.

Image: A view of the top of the iBUYPOWER Slate PC case, indicating the location of front I/O ports for convenient access.

3. Power Connection

Connect the power cable to the power supply unit (PSU) inlet on the rear of the PC, then plug the other end into a grounded electrical outlet.

OPERATING INSTRUCTIONS

1. Powering On

Press the power button located on the top or front of the PC case. The system will initiate the boot sequence.

2. Initial Windows Setup

Upon first boot, you will be guided through the Windows 11 Home setup process. Follow the on-screen instructions to configure your operating system, including language, region, network settings, and user account creation.



Image: A monitor displaying the Windows 11 desktop, indicating the operating system is ready for use.

3. Gaming and Performance

Your iBUYPOWER Slate Gaming PC is equipped with an Intel Core Ultra 9 285 CPU and NVIDIA GeForce RTX 5070 12GB GPU, designed for high-performance gaming and content creation. Ensure graphics drivers are up-to-date for optimal performance. Adjust in-game settings to match your desired frame rates and visual quality.



Game Changing Graphics

Powered by the new NVIDIA® GeForce RTX™ 50-Series GPU, experience next-level graphics and performance.

Image: A user engaged in PC gaming, illustrating the immersive experience provided by the system's advanced graphics capabilities.

MAINTENANCE

1. Cleaning

Regularly clean the exterior of the PC with a soft, dry cloth. Use compressed air to clear dust from fan vents and internal components. Ensure the PC is powered off and unplugged before cleaning.

2. Software Updates

Keep your operating system, drivers (especially graphics drivers), and applications updated to ensure system stability, security, and optimal performance.

3. Airflow and Cooling

Ensure the PC is placed in a well-ventilated area, away from obstructions that could block airflow. The iBUYPOWER AC5 Tower Air Cooler and case fans are designed to maintain optimal temperatures. Periodically check for dust buildup on fans and heatsinks.



iBUYPOWER AC5 - Tower Air Cooler

Cool your PC in style with the new 2026 iBUYPOWER AC5 Tower Air Fan, adding new aRGB flair on top of high airflow cooling performance.

Image: The iBUYPOWER AC5 Tower Air Cooler, featuring RGB lighting, designed to keep the CPU cool during operation.

TROUBLESHOOTING

No Power

- Verify the power cable is securely connected to both the PC and the electrical outlet.
- Ensure the power switch on the PSU (located on the rear of the PC) is in the 'ON' position.
- Test the outlet with another device to confirm it is functional.

Display Issues

- Check that the monitor is powered on and the video cable is securely connected to the graphics card (not the motherboard's video output).
- Ensure the correct input source is selected on your monitor.
- Try a different video cable or monitor if available.

Performance Problems

- Close unnecessary background applications.
- Ensure drivers, especially graphics drivers, are up to date.
- Monitor system temperatures to prevent thermal throttling.

Connectivity Issues

- For wired connections, check the Ethernet cable and router status.
- For Wi-Fi, ensure the antenna is properly attached and the Wi-Fi adapter is enabled in Windows settings.
- Restart your router and modem.

SPECIFICATIONS

Component	Specification
Model Number	SWI9N5703
Operating System	Windows 11 Home
CPU	Intel Core Ultra 9 285 (2.5 GHz, up to 5.5 GHz)
GPU	NVIDIA GeForce RTX 5070 12GB GDDR7
RAM	32GB DDR5 5200MHz (16GB x 2)
Storage	2TB NVMe SSD
Connectivity	Wi-Fi (802.11AC), Bluetooth, Ethernet (10/100/1000), USB (6 x USB 3.1, 4 x USB 2.0), HDMI
Audio	On-board audio
Case	Tempered Glass RGB Gaming Case (White)
Cooling	iBUYPOWER AC5 Tower Air Cooler, RGB Fans
Dimensions (L x W x H)	19.5 x 8.7 x 19.3 inches (495 x 220 x 490 mm)
Max Display Resolution	3840x2160



Image: A diagram illustrating the physical dimensions of the iBUYPOWER Slate Gaming PC case.

WARRANTY AND SUPPORT

Warranty Information

Your iBUYPOWER Slate Gaming PC SWI9N5703 comes with a **1 Year Manufacturer Warranty**. This warranty covers defects in materials and workmanship under normal use. For specific terms and conditions, please refer to the warranty documentation included with your product or visit the official iBUYPOWER website.

Technical Support

For technical assistance, troubleshooting, or warranty claims, please contact iBUYPOWER customer support. Contact information can typically be found on the iBUYPOWER official website or in the documentation provided with your PC.

