Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Audizio Laredo

Audizio Laredo Turntable with Speakers & Bluetooth - User Manual

Model: Laredo | Brand: Audizio

1. Important Safety Instructions

Please read these instructions carefully before using the device and keep them for future reference. Follow all warnings and instructions marked on the product.

- Do not use this apparatus near water.
- Clean only with a dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way.

2. Package Contents

Carefully unpack your Audizio Laredo turntable and ensure all items are present and in good condition. If any items are missing or damaged, please contact your retailer.

- Audizio Laredo Turntable
- Audio Technica Cartridge (pre-installed)
- Dust Cover
- 45 RPM Adapter for singles
- User Manual (this document)

3. Product Overview

The Audizio Laredo is a fully automatic turntable with integrated 160W speakers, Bluetooth connectivity (sender and receiver), and a high-quality Audio Technica cartridge. It features a stylish wooden housing and supports 33 and 45 RPM playback.



Figure 3.1: Front view of the Audizio Laredo Turntable with the dust cover open, showcasing the platter, tonearm, and integrated speaker grille.

Key Features:

- **Integrated 160W Speakers:** Powerful 2-way sound system with adjustable treble and bass.
- **Bluetooth 5.4:** Functions as both a receiver (stream music from your smartphone) and a sender (connect wireless headphones or Bluetooth speakers).
- **High-Quality Audio Technica Cartridge:** Ensures accurate and detailed vinyl playback.
- **Fully Automatic Tonearm:** Features auto-lift and auto-return for ease of use and record protection.

- **Belt Drive System:** Provides stable and vibration-free platter rotation.
- **Adjustable Sound:** Independent controls for Volume, Bass, and Treble.
- **Connectivity:** RCA Line Out for external Hi-Fi systems and 3.5mm AUX In.



Figure 3.2: Illustration of the turntable's Bluetooth capabilities, showing a smartphone connected for streaming and wireless headphones for private listening.



Figure 3.3: Detailed view of the premium Audio Technica AT3600L cartridge, highlighting its design and placement on the tonearm.



Figure 3.4: View of the automatic tonearm mechanism and controls, including the adjustable counterweight and speed selector (33/45 RPM).

4. Setup

4.1 Unpacking and Placement

1. Carefully remove the turntable from its packaging. Retain the packaging for future transport or storage.
2. Place the turntable on a stable, level surface away from direct sunlight, heat sources, and excessive dust or vibrations.
3. Ensure there is adequate space around the unit for ventilation and to fully open the dust cover.

4.2 Dust Cover Installation

The transparent dust cover protects the turntable from dust and damage. Gently align the hinges of the dust cover with the slots on the back of the turntable and push down until it clicks into place.

4.3 Stylus Protection Removal

Before first use, carefully remove the clear plastic stylus protector from the cartridge. Be gentle to avoid damaging the stylus.

4.4 Connecting Power

Plug the power cord into the AC inlet on the rear of the turntable, then plug the other end into a suitable wall outlet (220V AC).

4.5 External Connections (Optional)

- **RCA Line Out:** To connect to an external amplifier or powered speakers, use an RCA cable (not included) to connect the "LINE OUT" jacks on the turntable to the corresponding input on your audio system.
- **AUX In:** To play audio from an external device (e.g., smartphone, MP3 player) through the turntable's speakers, connect a 3.5mm audio cable (not included) from your device's headphone jack to the "AUX IN" port on the turntable.



Figure 4.1: Rear view of the turntable, detailing the RCA stereo output, 3.5mm AUX input, and the switch to select between internal speakers and line output.

5. Operating Instructions

5.1 Powering On/Off

Press the "MODE/POWER" knob to turn the unit on or off. The LED indicator will illuminate when the unit is on.

5.2 Playing a Record

1. Open the dust cover.
2. Place a record on the platter. If playing a 7-inch single, place the 45 RPM adapter over the spindle.
3. Select the correct speed (33 or 45 RPM) using the speed selector switch located near the tonearm base.
4. Ensure the tonearm is unlocked from its rest.
5. Press the "PLAY/PAUSE" button. The tonearm will automatically lift, move to the beginning of the record, and lower onto the groove.
6. Adjust the volume using the "VOLUME" knob and fine-tune the sound with the "BASS" and "TREBLE" knobs.
7. At the end of the record, the tonearm will automatically lift, return to its rest, and the platter will stop spinning (Auto-Return function).
8. To stop playback mid-record, press the "PLAY/PAUSE" button again. The tonearm will lift and return to its rest.

SPIELT ALLE VINYLS

audizio



Geeignet für 7-, 10- und 12-Zoll

2 Geschwindigkeiten, 33 und 45 U/min

Figure 5.1: The turntable playing a vinyl record, demonstrating its compatibility with 7, 10, and 12-inch records at 33 or 45 RPM.



Figure 5.2: Detailed view of the sound control panel, allowing users to adjust volume, bass, and treble to their preference.

5.3 Bluetooth Functionality

The Audizio Laredo can act as both a Bluetooth receiver and a Bluetooth sender.

5.3.1 Bluetooth Receiver Mode (Stream to Turntable)

1. Turn on the turntable.
2. Press the "MODE/POWER" knob repeatedly until "BT IN" is displayed (or indicated by a specific LED pattern). The unit will enter pairing mode.
3. On your smartphone or other Bluetooth device, enable Bluetooth and search for "Audizio Laredo".
4. Select "Audizio Laredo" to pair. Once connected, you can stream music from your device through the turntable's speakers.

5.3.2 Bluetooth Sender Mode (Stream from Turntable)

1. Turn on the turntable.
2. Ensure your Bluetooth headphones or speaker are in pairing mode.
3. Locate the "BT OUT" switch on the rear panel near the tonearm. Set it to "ON". The turntable will automatically

search for nearby Bluetooth devices.

4. Once connected, audio from your vinyl records will be streamed to your Bluetooth headphones or speaker.

5.4 AUX Input

To play audio from an external device connected to the AUX IN port:

1. Connect your external device to the "AUX IN" port using a 3.5mm audio cable.
2. Press the "MODE/POWER" knob repeatedly until "AUX" mode is selected.
3. Play audio from your external device. The sound will be output through the turntable's speakers.

6. Maintenance

6.1 Cleaning the Stylus

The stylus (needle) is delicate. Use a soft brush (not included) to gently brush the stylus from back to front to remove any dust or debris. Do not use liquids or excessive force.

6.2 Cleaning the Unit

Wipe the turntable cabinet and dust cover with a soft, dry, lint-free cloth. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.

6.3 Dust Cover Care

The dust cover can be cleaned with a soft, damp cloth. Avoid using harsh chemicals. If scratched, specialized plastic polish may be used.

7. Troubleshooting

Problem	Possible Cause	Solution
No power	Power cord not connected; outlet not active.	Ensure power cord is securely plugged in; try a different outlet.
No sound from speakers	Volume too low; wrong input mode; external speakers connected via RCA.	Increase volume; select correct mode (Phono, BT IN, AUX); ensure "Speaker ON/OFF" switch is set to ON if using internal speakers.
Record skips	Record is dirty or scratched; stylus is dirty or worn; turntable not level.	Clean record; clean stylus; ensure turntable is on a level surface.
Bluetooth pairing fails	Device too far; device not in pairing mode; interference.	Move device closer; ensure device is in pairing mode; turn off other Bluetooth devices.
Sound distortion	Volume too high; dirty stylus; damaged record.	Reduce volume; clean stylus; try a different record.

8. Specifications

Feature	Detail
Brand	Audizio
Model Name	Laredo
Speeds	33 1/3, 45 RPM
Drive Type	Belt Drive
Cartridge Type	Audio Technica (AT3600L)
Output Power	160 Watts (integrated speakers)
Bluetooth Version	5.4 (Sender & Receiver)
Connectivity	RCA Line Out, 3.5mm AUX In
Special Features	Auto-Lift, Auto-Return, Auto-Stop, Adjustable Bass/Treble
Material	Wood (Housing)
Dimensions (L x W x H)	43.2 x 37.5 x 21 cm (approx. 17 x 14.8 x 8.3 inches)
Weight	7.65 kg (approx. 16.86 lbs)
Power Supply	220V AC



Figure 8.1: Visual representation of the turntable's dimensions, including width, depth, and height with the dust cover closed.

9. Warranty and Support

9.1 Product Warranty

This Audizio Laredo turntable comes with a**24-month warranty** from the date of purchase. This warranty covers manufacturing defects and faults under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.
Please retain your proof of purchase for warranty claims.

9.2 Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact your retailer or visit the official Audizio website for support information.
Website: www.audizio.com

© 2026 Audizio. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GS1XKC33

More documents and user manuals: **https://manuals.plus/**