



Manuals.plus /

› Audizio /

› Audizio Laredo Bluetooth Turntable with HiFi Speakers - Instruction Manual

Audizio Laredo

Audizio Laredo Bluetooth Turntable Instruction Manual

Model: Laredo (101.537)

Brand: Audizio

1. INTRODUCTION

Thank you for purchasing the Audizio Laredo Bluetooth Turntable. This manual provides essential information for the safe and correct operation of your device. Please read it thoroughly before use and keep it for future reference.

Key Features:

- Integrated HiFi speakers with 160W total power output.
- Bidirectional Bluetooth for wireless audio streaming (in and out).
- High-quality Audio Technica cartridge for precise playback.
- Supports 7, 10, and 12-inch vinyl records at 33 and 45 RPM.
- Adjustable counterweight on the aluminum tonearm.
- RCA Line Out for external amplifier/speakers.
- AUX Input for connecting external audio sources.
- Elegant bamboo finish.

What's in the Box:

- Audizio Laredo Turntable Unit
- Instruction Manual
- Power Adapter
- 45 RPM Adapter for singles



Figure 1.1: Audizio Laredo Turntable, overall view.

2. SAFETY INSTRUCTIONS

Please read and follow these safety instructions carefully to prevent damage to the unit and ensure your safety.

- Do not expose the unit to rain or moisture to prevent fire or electric shock.
- Do not open the casing. There are no user-serviceable parts inside. Refer all servicing to qualified personnel.
- Place the unit on a stable, level surface to prevent it from falling.
- Keep the unit away from direct sunlight, heat sources, and excessive dust.
- Ensure proper ventilation around the unit. Do not block ventilation openings.
- Only use the provided power adapter.
- Unplug the unit during lightning storms or when unused for long periods.

3. PRODUCT OVERVIEW

Familiarize yourself with the components and controls of your Audizio Laredo turntable.

Main Components:

- **Platter:** Supports the vinyl record.
- **Tonearm:** Holds the cartridge and stylus.
- **Cartridge & Stylus:** Reads the grooves of the record. (Audio Technica ATN-3600)
- **Dust Cover:** Protects the platter and tonearm from dust.
- **Integrated Speakers:** For direct audio playback.
- **Control Panel:** For power, volume, tone, and mode selection.
- **Rear Connections:** RCA Line Out, AUX In, Power Input.



Figure 3.1: Top view of the turntable with key components visible.



| Ajuste el volumen, los agudos y los graves

Figure 3.2: Control Panel for volume, bass, and treble adjustments.



Entrada auxiliar

Sistema de altavoces internos conmutables / Salida de línea (RCA)

Figure 3.3: Audio Technica ATN-3600 Cartridge and Stylus.

BRAZO BALANCEADO



- | Presión de aguja ajustable
- | Elevación y retorno automático

Figure 3.4: Tonearm base with speed and auto-stop controls.

TRANSMISIÓN BT 5.4

audizio



Transmite música a tus auriculares

Reproduce música de forma inalámbrica desde tu dispositivo

Figure 3.5: Rear connection panel.

4. SETUP

4.1 Unpacking

- Carefully remove the turntable from its packaging.
- Remove all protective materials, including the stylus guard.
- Retain the packaging for future transport or storage.

4.2 Placement

- Place the turntable on a stable, level surface to prevent vibrations and ensure proper playback.
- Avoid placing the unit near strong magnetic fields, heat sources, or areas with high humidity.

4.3 Dust Cover Installation

- Align the hinges of the dust cover with the slots on the back of the turntable.
- Gently push down until the cover is securely in place.
- The dust cover can be removed for playback if desired.



Figure 4.1: Turntable with dust cover.

4.4 Power Connection

- Connect the power adapter to the DC IN port on the rear of the turntable.
- Plug the adapter into a suitable wall outlet (220V).

4.5 Tonearm and Cartridge Setup

- The Audio Technica cartridge is pre-installed.
- The tonearm features an adjustable counterweight. Refer to the detailed instructions in the included manual for precise counterweight adjustment to optimize tracking force.

5. OPERATING INSTRUCTIONS

5.1 Playing a Record

- Place a vinyl record on the platter. If playing a 7-inch single, use the included 45 RPM adapter.
- Select the appropriate speed (33 or 45 RPM) using the speed selector switch near the tonearm base.
- Gently lift the tonearm using the cueing lever.
- Position the tonearm over the desired track of the record.
- Slowly lower the tonearm using the cueing lever. The stylus will make contact with the record, and playback will begin.
- At the end of the record, the auto-stop function will automatically stop the platter rotation. Lift the tonearm and return it to its rest.

REPRODUCE TODOS TUS DISCOS



reproduce discos de 7", 10" y 12"

2 velocidades: 33 y 45 RPM

Figure 5.1: Playing a vinyl record.

5.2 Bluetooth Operation (Bidirectional)

The Laredo turntable supports both Bluetooth input (receiving audio from a device) and Bluetooth output (sending audio to a Bluetooth speaker/headphones).

Bluetooth Input (BT IN):

- Press the MODE/POWER button to select Bluetooth mode. The LED indicator will flash.
- On your smartphone or tablet, enable Bluetooth and search for 'Audizio Laredo'.
- Select the turntable to pair. Once connected, the LED will glow solid.

- You can now stream audio from your device to the turntable's integrated speakers.

Bluetooth Output (BT OUT):

- Ensure your Bluetooth headphones or speaker are in pairing mode.
- Set the BT OUT switch (located near the tonearm base) to 'ON'.
- The turntable will automatically search for and connect to the nearest Bluetooth audio device.
- Once connected, the audio from your vinyl record will be transmitted to your Bluetooth device.



Figure 5.2: Bidirectional Bluetooth functionality.

5.3 AUX Input

- Connect an external audio device (e.g., MP3 player, CD player) to the AUX IN port on the rear of the turntable using a 3.5mm audio cable.
- Press the MODE/POWER button to select AUX mode.
- Audio from the external device will play through the turntable's speakers.

5.4 RCA Line Out

- To connect the turntable to an external amplifier or powered speakers, use an RCA cable (not included) to connect

the LINE OUT ports on the rear of the turntable to the corresponding input on your audio system.

- Ensure the 'Speaker ON/OFF' switch on the rear is set to 'OFF' if you only want sound from external speakers.

5.5 Volume and Tone Control

- Use the VOLUME knob on the control panel to adjust the overall playback volume.
- Adjust the BASS and TREBLE knobs to fine-tune the audio output to your preference.

6. MAINTENANCE

6.1 Cleaning the Unit

- Wipe the dust cover and cabinet with a soft, dry cloth.
- Do not use abrasive cleaners, waxes, or solvents.
- For the platter, use a slightly damp cloth and dry thoroughly.

6.2 Stylus Care and Replacement

- The stylus is a delicate component. Handle it with care.
- Clean the stylus regularly using a soft brush designed for stylus cleaning, brushing from back to front.
- A stylus typically lasts for approximately 300-500 hours of playback. If you notice a decrease in sound quality or increased skipping, it may be time to replace the stylus.
- Replacement styli (e.g., Audio Technica ATN-3600L or compatible) can be purchased from authorized dealers. Refer to the detailed instructions provided with the replacement stylus for installation.

7. TROUBLESHOOTING

If you encounter issues with your turntable, please consult the following table before contacting support.

Problem	Possible Cause	Solution
No power	Power adapter not connected; Power outlet not working.	Ensure power adapter is securely connected to the unit and a working outlet.
No sound from speakers	Volume too low; Speaker ON/OFF switch is OFF; Incorrect mode selected.	Increase volume; Set 'Speaker ON/OFF' switch to ON; Select correct input mode (Phono, BT IN, AUX).
Skipping records	Record is dirty or damaged; Stylus is worn or dirty; Turntable not level; Tracking force incorrect.	Clean record; Clean or replace stylus; Place turntable on a level surface; Adjust tonearm counterweight.
Bluetooth pairing issues	Device too far; Turntable not in pairing mode; Interference.	Ensure devices are within range; Re-enter pairing mode; Turn off other Bluetooth devices.
Sound distortion	Volume too high; Stylus worn; Record damaged.	Reduce volume; Replace stylus; Try a different record.

8. SPECIFICATIONS

Technical specifications for the Audizio Laredo Turntable.

Feature	Specification
Model Name	Laredo (101.537)
Dimensions (L x W x H)	43.2 x 43.2 x 21 cm (17 x 17 x 8.3 inches)
Product Weight	7.65 kg (16.86 lbs)
Material	Wood (Bamboo finish)
Rotation Speeds	33 RPM, 45 RPM
Cartridge Type	Audio Technica (ATN-3600)
Motor Type	Belt Drive
Signal Format	Analog
Integrated Speakers	Yes, 160W total output
Bluetooth Version	5.4 (Bidirectional)
Connectivity	Bluetooth (In/Out), RCA Line Out, AUX In
Power Source	Wired Electric
Voltage	220 Volts
Compatible Devices	Speakers, Headphones, Smartphone, Tablet

9. WARRANTY AND SUPPORT

9.1 Warranty Information

This Audizio Laredo Turntable comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects and faults under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear (e.g., stylus wear).

Please retain your proof of purchase for warranty claims.

9.2 Customer Support

If you have any questions, require technical assistance, or need to make a warranty claim, please contact your retailer or visit the official Audizio website for support resources and contact information.

Official Audizio Website: www.audizio.com