Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Blue Tees Golf Captain Air

Blue Tees Golf Captain Air Rangefinder User Manual

Model: Captain Air (RF-CA-G-G)

Introduction

The Blue Tees Golf Captain Air Rangefinder is an advanced golf distance measuring device designed to provide precise yardage and enhance your game. It combines laser accuracy with GPS capabilities, environmental adjustments, and smart features to offer comprehensive course insights. This manual provides detailed instructions for setting up, operating, and maintaining your Captain Air Rangefinder.

What's in the Box

- Captain Air Connected Rangefinder
- Protective Rangefinder Carrying Case
- USB-C Charging Cable



Image: The Captain Air Rangefinder alongside its protective carrying case.

Setup

1. Charging the Device

Before first use, fully charge your Captain Air Rangefinder using the provided USB-C charging cable. Connect the USB-C end to the rangefinder's charging port and the other end to a compatible USB power source. The charging indicator will show the charging status.



Image: Close-up of the USB-C charging port on the rangefinder.

2. Powering On/Off

To power on the device, press and hold the power button located on the side. To power off, press and hold the power button again until the display turns off.

3. Connecting to the Blue Tees GAME App

For full functionality, including GPS distances, shot tracking, and the 'Find My Rangefinder' feature, download and connect to the Blue Tees GAME app on your smartphone. Follow the in-app instructions to pair your Captain Air Rangefinder via Bluetooth.

Operating Instructions

1. Basic Ranging (6X Magnification)

Look through the eyepiece and aim the reticle at your target. Press the power/fire button once to activate the laser. The distance to the target will be displayed instantly. The 6X optical magnification provides a clear view for precise targeting up to 1000 yards.




Image: The view through the rangefinder eyepiece, demonstrating 6X magnification and target acquisition.

2. Flag Lock with Pulse Vibration

When targeting a flagstick, the rangefinder will vibrate slightly to confirm that it has locked onto the flag, distinguishing it from background objects. This ensures you get the exact distance to the pin.

Image: Visual representation of the rangefinder's pulse vibration feature upon flag lock.

3. Tournament-Legal Slope Switch

The Captain Air features a physical switch to toggle the slope compensation function on or off. When slope is enabled, the device calculates and displays an adjusted distance based on elevation changes. For tournament play, ensure the slope function is switched off to comply with regulations.



Image: The rangefinder showing the tournament-legal slope switch in action, illustrating compensated vs. uncompensated distances.

4. Red / Black HD Display

The high-contrast display offers both red and black modes for optimal visibility in various lighting conditions. Switch between modes by quickly double-tapping the mode button to ensure clear readability of yardages and other information.



Image: The rangefinder's HD display demonstrating both red and black color modes for different lighting.

5. GPS Front, Center, Back Distances

When connected to the Blue Tees GAME app, the rangefinder can display GPS distances to the front, center, and back of the green, providing comprehensive course awareness.



Image: The rangefinder display showing GPS distances to the front, center, and back of the green.

6. True Distance Technology & Club Recommendations

Leveraging the connected app, True Distance technology factors in environmental conditions like slope, wind, elevation, temperature, and humidity to provide highly accurate adjusted yardages. The device also offers AI-powered club recommendations based on your shot data and course conditions.



Image: The rangefinder display illustrating True Distance adjustments and club suggestions.

7. Find My Rangefinder (Anti-Loss Technology)

If you misplace your rangefinder, use the Bluetooth tracking feature within the Blue Tees GAME app to quickly locate it on the course, in your bag, or on your cart.



Image: A golfer using the 'Find My Rangefinder' feature on their smartphone to locate the device.

8. Shot Tracking & Performance Insights

Through the Blue Tees GAME app, you can track your shot distances and analyze your performance after each round. This data helps identify strengths and weaknesses, contributing to better decision-making and improved scores.

Key Features Overview

- **True Distance Technology:** Factors in slope, wind, elevation, temperature, and humidity for accurate yardages.
- **Built-in Club Recommendations:** AI-powered suggestions for smarter club selection.
- **GPS Front, Center, Back:** Provides comprehensive course awareness when connected to the app.
- **Find My Rangefinder:** Bluetooth tracking via the Blue Tees GAME app to prevent loss.
- **Shot Tracking & Performance Insights:** Analyze your game and improve scores over time.
- **6X Magnification with 1000-Yard Precision:** Fast, accurate laser measurements.
- **Red / Black HD Display:** High-contrast display for clear visibility in all lighting conditions.

- **Connected Golf with GAME App:** Syncs with 42,000+ courses worldwide.
- **Magnetic Cart Mount:** Built-in magnet for secure and quick access on golf carts.
- **Weather-Resistant Design (IP65):** Durable performance in various weather conditions.
- **USB-C Rechargeable:** Convenient and modern charging.



Image: The rangefinder securely attached to a golf cart frame using its integrated magnetic strip.

Maintenance

Cleaning

To clean the rangefinder, use a soft, lint-free cloth. For lenses, use a lens cleaning cloth and solution designed for optical surfaces. Avoid abrasive materials or harsh chemicals that could damage the device.

Storage

Store the rangefinder in its protective carrying case when not in use. Keep it in a cool, dry place, away from direct

sunlight and extreme temperatures.

Water Resistance

The Captain Air Rangefinder has an IP65 rating, meaning it is protected against dust ingress and low-pressure water jets from any direction. While it is weather-resistant, it is not designed for submersion in water. Ensure the USB-C port cover is securely closed to maintain water resistance.



Image: The rangefinder being splashed with water, demonstrating its IP65 weather-resistant design.

Troubleshooting

Device Not Powering On

- Ensure the device is fully charged. Connect it to the USB-C charger and wait for the charging indicator.
- Press and hold the power button for a few seconds to ensure it's not just a quick press.

Inaccurate Readings / Difficulty Locking On

- Ensure the lenses are clean and free from smudges or debris.
- Make sure you are targeting a clear object. Pin lock works best on flagsticks.
- Check if the slope function is enabled or disabled as desired.
- Environmental factors like heavy fog or rain can affect laser performance.

Display is Dim or Hard to Read

- Adjust the display brightness settings.
- Toggle between red and black display modes by quickly double-tapping the mode button to find the optimal contrast for current lighting conditions.

Bluetooth Connection Issues with GAME App

- Ensure Bluetooth is enabled on your smartphone.
- Make sure the rangefinder is powered on and within range of your phone.
- Restart both the rangefinder and your smartphone.
- Try unpairing and re-pairing the device in the app's settings.

Specifications

Brand	Blue Tees Golf
Model	Captain Air (RF-CA-G-G)
Color	Grey
Material	Plastic
Magnification	6x
Measuring Range	Up to 1000 yards
Water Resistance	IP65 (Dust and weather resistant)
Battery	USB-C Rechargeable
Connectivity	Bluetooth (for GAME App)
Display	Red / Black HD Display

Warranty

The Blue Tees Golf Captain Air Rangefinder comes with a**2-Year Manufacturer's Warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For specific terms and conditions, refer to the official Blue Tees Golf website or contact customer support.

Support

For further assistance, technical support, or to explore additional features, please refer to the following resources:

- **Blue Tees GAME App:** Download the official Blue Tees GAME app from your smartphone's app store for advanced features, course data, and device management.
- **Online Resources:** Visit the official Blue Tees Golf website for FAQs, updated manuals, and support contact information.

Video: An overview of the Blue Tees Golf Captain Series Rangefinders, highlighting key features and benefits.

© 2026 Blue Tees Golf. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GS2NSHRR

More documents and user manuals: **https://manuals.plus/**