

Husgw HL256R

Husgw HL256R Silent Pedestal Fan User Manual

Model: HL256R | Brand: Husgw

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using this appliance and retain for future reference. Failure to follow these instructions may result in electric shock, fire, or serious personal injury.

- Always ensure the fan is placed on a stable, flat surface.
- Do not insert fingers or any objects through the grille when the fan is operating.
- Keep the fan away from water or other liquids. Do not use in wet environments.
- Unplug the fan from the power outlet before cleaning, moving, or performing any maintenance.
- Do not operate the fan with a damaged cord or plug. Contact customer support for repairs.
- This appliance is for indoor use only.
- Keep out of reach of children and pets.

2. PACKAGE CONTENTS

Verify that all components are present in the package:

- Pedestal Fan x1
- Remote Control x1
- User Manual x1

3. PRODUCT OVERVIEW

The Husgw HL256R Silent Pedestal Fan is designed to provide efficient and quiet air circulation for various indoor environments. It features advanced functionalities for personalized comfort.

Key Features:

- **3D Automatic Oscillation:** Provides wide-angle air distribution with 90° horizontal and 90° vertical oscillation, ensuring comprehensive air circulation throughout the room.
- **Ultra-Quiet Operation:** Equipped with a silent DC motor, operating at a low noise level of 30 dB on its lowest setting, ideal for bedrooms and offices.
- **Adjustable Height:** Offers three height settings (50 cm, 80 cm, 110 cm) to adapt to different uses, from a desk fan to a full-size pedestal fan.
- **12 Speed Settings:** Choose from 12 fan speeds, ranging from a gentle breeze to a powerful airflow.
- **12-Hour Timer:** Program the fan to automatically turn off after a set period, up to 12 hours.
- **Remote Control & Touch Panel:** Conveniently control all functions using the included remote control or the integrated touch panel.
- **Powerful Airflow:** Delivers a maximum wind speed of 7.16 m/s and an air volume of 1699 m³/h, reaching up to 27.4 meters.
- **Energy-Efficient:** Designed for year-round use, helping to circulate air from air conditioners in summer and warm air from heaters in winter.

Couverture de la circulation d'air dans toute la pièce

Alimenté par un
moteur CC à
économie d'énergie

27,4m
Distance maximale

1699 m³/h
Volume d'air maximal

7,16 m/s
Vitesse maximale de l'air



Image: The fan effectively circulates air across a large open-plan living space, demonstrating its wide coverage.

Oscillation Multi-directionnelle



Image: A visual representation of the fan's multi-directional oscillation, showing both horizontal and vertical movement for comprehensive air distribution.

2 Façons de Contrôler

Le Contrôle au Bout des Doigts




Image: The fan is shown in a bedroom setting, illustrating its quiet operation at 30dB, comparable to a quiet library, ensuring undisturbed sleep.

4. SETUP AND ASSEMBLY

The Husgw HL256R fan is designed for quick and tool-free assembly, typically taking less than a minute.

Assembly Steps:

1. Carefully unpack all components from the box.
2. Attach the base to the main fan body. Ensure it clicks securely into place or is tightened as per the visual guide.
3. Connect the power cord.



Image: A visual guide demonstrating the simple, tool-free installation process for the fan's base.

Adjusting Height:

The fan offers three adjustable heights: 50 cm (desk), 80 cm (mid-height), and 110 cm (pedestal). To adjust the height, gently twist and pull/push the telescopic pole to the desired position until it locks into place. No tools are required for height adjustment.

Circulation d'air ultra-silencieuse

Vous garde au frais sans le bruit



Image: The fan is displayed at its three adjustable height settings (50cm, 80cm, 110cm), illustrating its versatility for various uses.

5. OPERATING INSTRUCTIONS

The fan can be controlled via the integrated touch panel or the included remote control.

Control Panel & Remote Control:

3 HAUTEURS RÉGLABLES



Image: A close-up of the fan's touch control panel and the remote control, highlighting the intuitive interface for operation.

Functions:

- **Power On/Off:** Press the power button on the touch panel or remote to turn the fan on or off.
- **Speed Adjustment:** Use the speed buttons (or +/- on remote) to cycle through 12 different fan speeds.
- **Oscillation:** Press the oscillation button to activate or deactivate the 3D automatic oscillation (90° horizontal and 90° vertical).
- **Timer Setting:** Press the timer button to set the automatic shut-off timer from 1 to 12 hours. Each press increases the timer by one hour.
- **Mode Selection:** The fan may feature different modes (e.g., Normal, Natural, Sleep). Refer to the remote control or touch panel icons for specific mode selection.

Confort Personnalisé avec Modes Multiples



Image: The fan's digital display illustrating the available 12 speed settings, 12-hour timer function, and 3D oscillation modes.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the lifespan of your fan.

Cleaning Steps:

1. Always unplug the fan from the power outlet before cleaning.
2. The front grille is removable for easy cleaning. Gently twist or unclip the front grille as indicated in the diagram to detach it.
3. Wipe the fan blades and interior surfaces with a soft, damp cloth. For stubborn dust, a mild detergent can be used.
4. Clean the exterior of the fan with a soft, dry cloth. Do not use abrasive cleaners or solvents.

5. Ensure all parts are completely dry before reassembling and plugging in the fan.



Image: A visual guide demonstrating the simple process of removing the front grille and fan blades for thorough cleaning.

7. TROUBLESHOOTING

If you encounter any issues with your fan, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply. Power button not pressed.	Check if the power cord is securely plugged into a working outlet. Press the power button on the fan or remote control.
Weak airflow.	Fan speed is too low. Grille is obstructed by dust.	Increase the fan speed setting. Clean the front grille and fan blades as described in the Maintenance section.
Fan is noisy.	Fan blades or grille are dirty. Fan is not on a stable surface.	Clean the fan blades and grilles. Ensure the fan is placed on a flat, stable surface.
Remote control not working.	Batteries are dead or incorrectly inserted. Obstruction between remote and fan.	Replace batteries with new ones, ensuring correct polarity. Remove any obstacles between the remote and the fan's receiver.

If the problem persists after trying these solutions, please contact customer support.

8. SPECIFICATIONS

Feature	Specification
Brand	Husgw
Model Number	HL256R
Color	Grey
Electric Fan Design	Floor Fan
Power Source	Electric Cord
Style	Modern
Product Dimensions (D x W x H)	13D x 55W x 33H centimeters
Special Features	12 speeds, 12-hour timer, 90° oscillation, 3 adjustable heights, remote control, 30 dB silent
Recommended Uses	Air circulation
Mounting Type	Floor Mount
Controller Type	Touchpad Control, Remote Control
Number of Speeds	12
Noise Level	30 Decibels
Airflow	1699 Cubic meters per hour
Voltage	220 Volts
Usage	Indoor
Control Method	Push Button, Remote Control
Material	Acrylonitrile Butadiene Styrene
Size (Height)	50-110 cm
Manufacturer	Cixi Zhongkang Electric Appliance Co., Ltd.

9. WARRANTY AND SUPPORT

This Husgw HL256R Silent Pedestal Fan comes with a **1-year warranty** from the date of purchase.

The warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.

For warranty claims, technical support, or any questions regarding your product, please contact Husgw customer service through your retailer or the official Husgw website. Please have your proof of purchase and model number (HL256R) ready when contacting support.

© 2026 Husgw. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question