

## LICAEVEY LICAEVEYhq1gp0s8ce-12

# LICAEVEY Portable Bluetooth Thermal Printer User Manual

Model: LICAEVEYhq1gp0s8ce-12

## 1. INTRODUCTION

---

This manual provides detailed instructions for the safe and efficient use of your LICAEVEY Portable Bluetooth Thermal Printer. Please read this manual thoroughly before operating the device. This compact and lightweight thermal printer is designed for on-the-go printing, offering seamless Bluetooth connectivity to your smartphone for various printing tasks.

Key features include:

- **Portable Design:** Lightweight and compact for easy transport.
- **Bluetooth Connectivity:** Quick connection to iOS and Android devices via the WalkPrint APP.
- **Versatile Functions:** Supports printing of labels, lists, messages, photos, and various templates.
- **Inkless Thermal Printing:** Produces crisp black and white prints without the need for ink cartridges or toner.

## 2. SETUP

---

### 2.1 Package Contents

Before you begin, please verify that all items are present in the package:

- 1 x Portable Printer
- 1 x User Manual
- 1 x Charging Cable (Type C)
- 1 x Printing Paper (Built-in)

### 2.2 Charging the Device

The printer is equipped with a built-in 1200mAh Lithium-Ion battery. For optimal performance, fully charge the device before first use.

1. Connect the provided Type-C charging cable to the printer's charging port.
2. Connect the other end of the cable to a standard USB power adapter (not included) or a computer's USB port.
3. The indicator light will show charging status (refer to device for specific light behavior).
4. Once fully charged, disconnect the charging cable.



Image: The LICAEVEY Portable Bluetooth Thermal Printer shown with its Type-C charging cable, illustrating the charging connection point.

## 2.3 Loading Thermal Paper

The printer uses thermal paper rolls. A roll is typically pre-installed. To replace or load new paper:

1. Gently open the printer's paper compartment cover.
2. Insert the new thermal paper roll, ensuring the printing side is facing the print head.
3. Pull a small length of paper out of the compartment.
4. Close the paper compartment cover firmly until it clicks into place.

## 2.4 App Installation and Bluetooth Connection

The printer connects to your smartphone via Bluetooth using the dedicated WalkPrint APP.

1. Download the **WalkPrint APP** from your device's app store (compatible with iOS and Android).
2. Ensure your printer is powered on and fully charged.
3. Enable Bluetooth on your smartphone.
4. Open the WalkPrint APP. The app will guide you through the pairing process. Select your printer from the list of available Bluetooth devices.
5. Once connected, the app will indicate a successful pairing.

# Wireless Pocket Printer

One-click printing for smartphone & tablet devices



Image: A smartphone displaying the WalkPrint application interface, demonstrating the wireless connection to the pocket printer. The image highlights compatibility with Android and the use of a USB cable for charging.

## 3. OPERATING INSTRUCTIONS

### 3.1 Power On/Off

To power on the printer, press and hold the power button located on the device until the indicator light illuminates. To power off, press and hold the power button again until the indicator light turns off.

### 3.2 Basic Printing Functions

The WalkPrint APP provides various options for printing:

- **Image Printing:** Select an image from your phone's gallery within the app and print it in black and white.
- **Text Printing:** Input text directly into the app or paste it from other sources to print notes, messages, or lists.
- **Templates:** Utilize pre-designed templates for labels, to-do lists, banners, and more.
- **Study Aid:** Print study materials, notes, or even mistakes for efficient review and organization.



Image: This image illustrates the printer's wireless connection capability, showing a smartphone connected to the printer via the WalkPrint app. Examples of image printing, text printing, and available free templates are displayed.

### 3.3 Creating Labels and Notes

The printer is ideal for creating custom labels and notes for various purposes.

- Open the WalkPrint APP and navigate to the 'Labels' or 'Templates' section.
- Choose a suitable template or design your own label/note.
- Enter the desired text or add images.
- Preview your print and then select 'Print'.



# Pocket Printer Create Labels Everywhere

Image: Various applications of the pocket printer are shown, including creating labels for organizing items in storage boxes, printing small black and white photos for an album, and addressing envelopes.

# Multi Function Thermal Instant Printer



Banners



To-do List



Notes



Black and White Picture



Post-it Notes



Label

Image: A collage demonstrating the multi-functional capabilities of the thermal printer, featuring examples of printed banners, to-do lists, study notes, black and white pictures, and product labels.

# Memorize Your Beautiful Life



Image: A user is shown printing a black and white photograph using the LICAEEVEY portable printer, then placing the printed photo onto a mood board, illustrating its use for personalizing and documenting memories.

## 4. MAINTENANCE

---

### 4.1 Cleaning the Printer

To ensure optimal print quality and prolong the life of your printer, regular cleaning is recommended.

- Ensure the printer is powered off and disconnected from any power source.
- Use a soft, dry, lint-free cloth to wipe the exterior of the printer.
- For the print head, use a cotton swab lightly dampened with isopropyl alcohol. Gently wipe the print head to remove any dust or paper residue. Allow it to dry completely before use.
- Do not use harsh chemicals, abrasive cleaners, or excessive moisture.

### 4.2 Paper Replacement

When the paper roll is depleted, replace it as described in Section 2.3. Always use thermal paper rolls compatible with your printer model to avoid damage and ensure proper function.

## 5. TROUBLESHOOTING

If you encounter issues with your printer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Printer does not power on	Low battery; Power button not pressed correctly	Charge the printer fully; Press and hold the power button for a few seconds
Cannot connect via Bluetooth	Bluetooth off on phone; Printer not in pairing mode; App issue	Ensure Bluetooth is enabled on your phone; Restart printer and app; Re-pair device in WalkPrint APP
No print output or blank pages	No paper; Paper loaded incorrectly; Print head dirty	Load new thermal paper; Ensure paper is facing the correct direction; Clean the print head (see Section 4.1)
Poor print quality	Low battery; Dirty print head; Low quality paper	Charge the printer; Clean the print head; Use recommended thermal paper
App crashes or freezes	Software glitch; Outdated app version	Restart the app; Check for app updates in your app store; Reinstall the app if necessary

## 6. SPECIFICATIONS

Detailed technical specifications for the LICAEVEY Portable Bluetooth Thermal Printer:

- **Product Material:** ABS
- **Printing Method:** Thermal Printing
- **Printing Resolution:** 203 DPI
- **Battery Type:** Lithium Ion Battery
- **Battery Capacity:** 1200mAh
- **Charging Interface:** Type C
- **Voltage Specification:** 5V1A
- **APP Name:** WalkPrint
- **Connection Method:** Bluetooth
- **Product Dimensions (D x W x H):** 4.33" x 3.94" x 1.97" (approximately 11cm x 10cm x 5cm)
- **Model Number:** LICAEVEYhq1gp0s8ce-12
- **Manufacturer:** LICAEVEY

- Resolution: **203DPI**
- Battery capacity: **1200MAh**
- Voltage specification: **5V1A**



Image: A visual representation of the printer's key specifications, including its 203DPI resolution, 1200mAh battery capacity, 5V1A voltage, and physical dimensions (3.7cm/1.46in height, 9.4cm/3.71in width, 9.3cm/3.67in depth).

## 7. WARRANTY INFORMATION

---

This LICAEEVEY Portable Bluetooth Thermal Printer is covered by a manufacturer's warranty for 90 days from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accident, unauthorized modification, or external causes. For warranty claims, please retain your proof of purchase and contact the seller or manufacturer's customer support.

## 8. SUPPORT

---

For further assistance, technical support, or inquiries regarding your LICAEEVEY Portable Bluetooth Thermal Printer, please:

- Refer to the help section within the WalkPrint APP.
- Contact the retailer from whom you purchased the product.
- Visit the official LICAEEVEY website for updated information or contact details.

