

GZJ00903

Olayks Portable Juicer User Manual

Model: GZJ00903

INTRODUCTION

Thank you for choosing the Olayks Portable Juicer. This compact and versatile personal blender is designed to help you prepare fresh juices, smoothies, and shakes conveniently, whether at home, in the office, at the gym, or while traveling. Made with durable, BPA-free Tritan material, it ensures safe and healthy blending. Please read this manual thoroughly before first use to ensure proper operation and maintenance.

SETUP

1. **Unboxing:** Carefully remove all components from the packaging. Ensure you have the Blender Base, Tritan Cup, Charging Cable, and this User Manual.
2. **Initial Charge:** Before first use, fully charge the juicer. Connect the charging cable to the charging port on the blender base and plug it into a suitable USB power source. The indicator light will show charging status.
3. **Initial Cleaning:** Wash the Tritan Cup and the blade assembly with warm, soapy water. Rinse thoroughly and dry. **Do not immerse the blender base (motor unit) in water.** Wipe the base with a damp cloth.
4. **Assembly:** Ensure the blade assembly is securely attached to the Tritan Cup. Align the cup with the blender base and twist clockwise until it locks into place.



Image: The blade assembly being prepared for attachment to the juicer cup. Ensure the blades are clean and securely fastened.

OPERATING INSTRUCTIONS

1. **Prepare Ingredients:** Cut fruits and vegetables into small pieces (approximately 1 inch or 2.5 cm). For best results, do not overfill the cup.
2. **Add Ingredients:** Place your prepared ingredients into the Tritan Cup. Add liquid (water, milk, juice) up to the maximum fill line (700ml).



Image: An apple being placed into the juicer cup. Ensure ingredients are cut into small, manageable pieces.

3. **Secure Lid:** Ensure the blade assembly is tightly screwed onto the cup, and the cup is securely locked onto the blender base.
4. **Start Blending:** Press the power button on the blender base to start blending. The 18,000 RPM motor will quickly process your ingredients. Blend until desired consistency is achieved.



Image: A user pressing the power button to activate the blending function. Ensure the cup is securely attached before operating.

5. **Pour and Enjoy:** Once blending is complete, turn off the juicer, remove the cup, and pour your fresh drink.



Image: Freshly blended juice being poured from the Olayks Portable Juicer. The wide mouth allows for easy pouring.

Important Safety Precautions:

- Do not operate the juicer without ingredients or liquid.
- Ensure the cup and blade assembly are securely fastened before blending.
- Keep hands and utensils away from the blades during operation.
- Do not blend hot liquids.

- Avoid overfilling the cup beyond the maximum fill line.

MAINTENANCE AND CLEANING

1. **Immediate Cleaning:** After each use, rinse the Tritan Cup and blade assembly immediately to prevent food residue from drying.
2. **Hand Wash Only:** The Tritan Cup and blade assembly are **not dishwasher safe**. Wash them by hand with warm, soapy water. Use a brush to clean around the blades carefully.
3. **Blender Base:** Wipe the blender base with a damp cloth. **Never immerse the blender base in water or any other liquid.**
4. **Charging Port:** Keep the charging port dry and free from debris.
5. **Storage:** Store the juicer in a clean, dry place when not in use.



Image: A visual guide demonstrating the process of adding ingredients, liquid, and the ease of cleaning the juicer's wide mouth.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Juicer does not turn on.	Battery is low or depleted. Cup is not securely attached.	Charge the juicer fully. Ensure the cup is twisted clockwise until it locks into place.
Ingredients are not blending smoothly.	Too many ingredients. Not enough liquid. Ingredients are too large.	Reduce the amount of ingredients. Add more liquid. Cut ingredients into smaller pieces.
Juicer stops during operation.	Overload protection activated. Battery is low.	Turn off, remove some ingredients, and restart. Charge the juicer.
Leakage from the cup.	Lid not properly sealed. Gasket is damaged or missing.	Ensure the blade assembly is tightly screwed onto the cup. Check if the silicone gasket is correctly seated and undamaged.

SPECIFICATIONS

Feature	Detail
Model Number	GZJ00903
Brand	Generic (Olayks)
Capacity	1 Liter (1000ml)
Material	Tritan Plastic (BPA-Free)
Power Source	Cordless Electric
Wattage	150 watts
Voltage	36 Volts
Motor Speed	18,000 RPM
Product Dimensions (D x W x H)	5.9"D x 6.7"W x 12.2"H
Dishwasher Safe	No
Included Components	Blender Base, Tritan Cup, Charging Cable, User Manual

WARRANTY INFORMATION

This Olayks Portable Juicer is covered by a standard manufacturer's warranty against defects in materials and workmanship. The specific duration and terms of the warranty may vary. Please retain

your proof of purchase for warranty claims. For detailed warranty information, refer to the documentation provided at the time of purchase or contact the seller.

CUSTOMER SUPPORT

If you encounter any issues or have questions regarding your Olayks Portable Juicer that are not addressed in this manual, please contact the seller or manufacturer for assistance. Provide your model number (GZJ00903) and a detailed description of the issue when seeking support.