

[Manuals.plus](#) /

> [Composad](#) /

> Composad ESPRESSO Low Multipurpose Cabinet with 2 Doors and 1 Shelf, Model BSA426K76804 User Manual

Composad BSA426K76804

Composad ESPRESSO Low Multipurpose Cabinet User Manual

Model: BSA426K76804

1. INTRODUCTION

The Composad ESPRESSO Low Multipurpose Cabinet is a versatile and functional addition to any environment. With compact dimensions of 72x86.9x35.3 cm (Width x Height x Depth), it integrates harmoniously into various settings, from the office to the dining room, bedroom, or entrance. Despite its compact size, this cabinet offers ample storage space. The two doors open to reveal an adjustable internal shelf, allowing you to organize items of various sizes. Whether you need to store documents, dishes, clothes, or personal items, this cabinet is designed to meet your storage needs.

Key Features:

- **Made in Italy:** This furniture is designed and produced in Italy, ensuring quality craftsmanship.
- **Ecological Panel:** Constructed from FSC 100% recycled wood certified ecological panel, known for its low CO2 emissions, practicality, and resistance.
- **Ample Storage:** Features two doors and an adjustable internal shelf for flexible organization of various items.
- **Versatile Functionality:** Suitable for multiple uses, including office archiving, entrance storage, dining room dish storage, or bedroom linen storage.
- **Modern Design:** The White Lacquered finish provides a clean and contemporary aesthetic, complementing diverse interior decors.

2. SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- Ensure all parts are present and undamaged before beginning assembly.
- Assemble the cabinet on a soft, clean surface to prevent scratches.
- Always use appropriate tools and follow the assembly steps in order.
- Do not overtighten screws, as this may damage the material.

- For stability, ensure the cabinet is placed on a level surface.
- If wall mounting is required, use appropriate hardware for your wall type and seek professional assistance if unsure.
- Keep small parts away from children during assembly.

3. ASSEMBLY INSTRUCTIONS

The Composad ESPRESSO cabinet is designed for easy and fast assembly, with clear, step-by-step illustrated instructions provided in the packaging. Please refer to the detailed assembly manual included with your product for specific diagrams and hardware lists.

General Assembly Steps:

1. **Unpack and Identify Parts:** Carefully unpack all components and verify against the parts list in your included manual.
2. **Assemble the Base:** Attach the cabinet legs or base frame as instructed.
3. **Construct the Frame:** Connect the side panels, back panel, and top panel to form the main cabinet structure.
4. **Install Shelves:** Insert the adjustable shelf supports and place the shelf at your desired height.
5. **Attach Doors:** Mount the two doors using the provided hinges, ensuring they align correctly and open/close smoothly.
6. **Final Adjustments:** Check all connections for tightness and stability. Adjust door hinges if necessary for perfect alignment.

For a visual overview of the Composad Espresso line, which includes this cabinet, please watch the video below. This video highlights the design and quality of the furniture, including its easy assembly.

Your browser does not support the video tag.

Video: Composad Espresso Line Overview. This video showcases the design and features of the Espresso furniture line, including the ease of assembly.

4. OPERATING INSTRUCTIONS

The Composad ESPRESSO Low Multipurpose Cabinet is designed for straightforward use.

- **Opening and Closing Doors:** Gently pull the door handles to open and push to close. Avoid slamming the doors to prevent damage to hinges and the cabinet structure.
- **Adjusting Shelves:** The internal shelf is adjustable. To change its height, carefully remove all items from the shelf, lift the shelf, remove the shelf supports from their current holes, and reinsert them into the desired new holes. Then, place the shelf back onto the supports. Ensure the shelf is level and securely seated before placing items on it.
- **Loading Capacity:** Distribute weight evenly on the shelf. Avoid overloading the cabinet to maintain stability and prevent structural damage.



Image: The Composad Espresso Low Multipurpose Cabinet with its two doors open, revealing the adjustable internal shelf. This image demonstrates the storage capacity and shelf adjustability.

5. MAINTENANCE AND CARE

Proper care will ensure the longevity and appearance of your Composad ESPRESSO cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Use mild soap if necessary, then dry immediately with a clean, dry cloth. Avoid abrasive cleaners, harsh chemicals, or solvents, as these can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the material.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration over time.
- **Heat and Moisture:** Keep the cabinet away from direct heat sources and excessive moisture to prevent warping or damage.
- **Hardware Check:** Periodically check all screws and fittings to ensure they remain tight. Retighten if necessary, but do not overtighten.



Image: The Composad Espresso Low Multipurpose Cabinet with its doors closed, showcasing its clean white lacquered finish and compact form factor.

6. TROUBLESHOOTING

If you encounter any issues with your cabinet, please refer to the following common solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Cabinet is wobbly or unstable.	Uneven floor; loose screws; incorrect assembly.	Ensure the cabinet is on a level surface. Check and tighten all assembly screws. Review assembly instructions to ensure all parts are correctly installed.
Doors do not close properly or are misaligned.	Hinges are loose or incorrectly adjusted; cabinet not level.	Adjust the door hinges according to the instructions in your assembly manual. Ensure the cabinet is on a level surface. Tighten hinge screws.
Shelf is not sitting securely.	Shelf supports not fully inserted; shelf not placed correctly.	Ensure all four shelf supports are fully inserted into the corresponding holes. Place the shelf carefully onto all supports.

If the problem persists, please contact Composad customer support for further assistance.

7. SPECIFICATIONS

Feature	Detail
Brand	Composad
Model Name	BSA426K76804
Product Dimensions (WxHxD)	72W x 86.9H x 35.3D cm
Mounting Type	Floor Mount
Door Style	Slab
Base Type	Legs
Material	Ecological Panel (FSC 100% recycled wood)
Color	White Lacquered
Origin	Made in Italy

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Composad website. Keep your proof of purchase for any warranty claims.

Manufacturer: Composad srl

Manufacturer Part Number: BSA426K76804

ASIN: B0GS768C5M



