

iCan ISM-1

iCan iSmart Home Desktop Computer ISM-1 User Manual

Model: ISM-1 (Q15 Mini Tower)

1. INTRODUCTION

This manual provides essential information for the proper setup, operation, and maintenance of your iCan iSmart Home Desktop Computer, Model ISM-1. Please read this manual thoroughly before using the product to ensure optimal performance and safety.

2. SAFETY INFORMATION

- Ensure the computer is placed on a stable, flat surface with adequate ventilation.
- Do not block ventilation openings. Overheating can damage the system.
- Keep the computer away from water, moisture, and direct sunlight.
- Use only the provided power cord and connect it to a grounded electrical outlet.
- Do not attempt to open the computer case unless instructed by qualified personnel.
- Disconnect the power cord before cleaning or performing any maintenance.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- iCan iSmart Home Desktop Computer (ISM-1)
- Power Cord

4. PRODUCT OVERVIEW

Familiarize yourself with the physical components and ports of your desktop computer.


Front Panel



A clear front-side view of the iCan iSmart Mini Tower desktop computer, showcasing its sleek design and front panel access.

- **Power Button:** Press to turn the computer on or off.
- **HDD LED Indicator:** Indicates hard drive activity.
- **USB 2.0 Port:** For connecting USB 2.0 devices.
- **USB 3.2 Port:** For connecting USB 3.2 compatible devices for faster data transfer.

Rear Panel Ports



A detailed view of the desktop computer's rear panel, showing the power switch, power input, PS/2 ports, VGA, DisplayPort, HDMI, USB 2.0, USB 3.2, Gigabit Ethernet/LAN, microphone, line out, and line in ports. The front panel power button and USB ports are also indicated.

- **Power Switch:** Main power cut-off switch.
- **Power Input:** Connect the power cord here.
- **PS/2 Ports (x2):** For legacy keyboard and mouse connections.
- **VGA Port:** Video output for older monitors.
- **DisplayPort (DP):** Digital video output for high-resolution displays.
- **HDMI Port:** Digital video and audio output.

- **USB 2.0 Ports (x2):** For connecting USB 2.0 devices.
- **USB 3.2 Ports (x2):** For connecting USB 3.2 compatible devices.
- **Gigabit Ethernet / LAN:** For wired network connection.
- **Microphone (x1):** Audio input for microphones.
- **Line Out (x1):** Audio output for speakers or headphones.
- **Line In (x1):** Audio input for external audio sources.

5. SETUP

5.1 Connecting Peripherals

1. **Connect Monitor:** Plug your monitor's video cable into one of the available video output ports on the rear panel (HDMI, DisplayPort, or VGA).
2. **Connect Keyboard and Mouse:** Plug your keyboard and mouse into the available USB ports on either the front or rear panel. PS/2 ports are also available for compatible devices.
3. **Connect Network (Optional):** For a wired internet connection, connect an Ethernet cable from your router/modem to the Gigabit Ethernet port on the rear panel.
4. **Connect Audio (Optional):** If using external speakers or headphones, connect them to the Line Out port.
5. **Connect Power:** Plug the power cord into the power input on the rear panel of the computer, then plug the other end into a grounded electrical outlet.

5.2 Initial Power On

1. Ensure all connections are secure.
2. Flip the power switch on the rear panel to the 'ON' position (if applicable).
3. Press the power button on the front panel of the computer.
4. The computer will boot up, and you will see the Windows 11 Home setup screen or desktop. Follow the on-screen instructions for initial Windows setup if prompted.

6. OPERATING INSTRUCTIONS

6.1 Windows 11 Home Basics

Your iCan iSmart desktop computer comes with Windows 11 Home pre-installed. For detailed instructions on using Windows 11, refer to Microsoft's official documentation or support resources.

6.2 Connectivity (Wi-Fi & Bluetooth)



An overview of the iCan iSmart desktop computer, detailing its core components including built-in Wi-Fi and Bluetooth.

- **Wi-Fi:** The computer has built-in Wi-Fi. To connect to a wireless network, click the Wi-Fi icon in the taskbar, select your network, and enter the password.
- **Bluetooth:** Built-in Bluetooth allows connection to wireless headphones, mice, keyboards, and other Bluetooth-enabled devices. Access Bluetooth settings via the Windows Settings menu.

6.3 Multi-Monitor Setup

Support Triple Screen Display

Meet all your daily needs, working & entertaining



This image demonstrates the iCan iSmart desktop computer's capability to support a triple screen display setup, suitable for multitasking, work, and entertainment.

The iCan iSmart desktop supports multiple display outputs (HDMI, DisplayPort, VGA). To set up multiple monitors:

1. Connect your monitors to the available video output ports on the rear panel.
2. Right-click on the desktop and select 'Display settings'.
3. Windows will detect the connected monitors. You can then arrange them, choose display modes (extend, duplicate, or show only on one), and adjust resolution.

7. MAINTENANCE

7.1 Cleaning

- Always power off the computer and disconnect the power cord before cleaning.
- Use a soft, dry cloth to wipe the exterior of the computer.
- For stubborn marks, lightly dampen the cloth with water (do not spray directly onto the computer).

- Use compressed air to gently clear dust from ventilation grilles and ports. Do not use strong solvents or abrasive cleaners.

7.2 Software Updates

- Regularly check for and install Windows updates to ensure system security and performance. Go to**Settings > Windows Update**.
- Keep your drivers updated. You can typically find driver updates through Windows Update or the manufacturer's website.

8. TROUBLESHOOTING

- **No Power:** Ensure the power cord is securely connected to both the computer and the electrical outlet. Check the power switch on the rear panel. Try a different outlet.
- **No Display:** Verify that the monitor is powered on and correctly connected to a video output port (HDMI, DisplayPort, or VGA) on the computer. Try a different video cable or monitor if possible.
- **No Internet Connection (Wired):** Check if the Ethernet cable is securely connected. Verify your router/modem is working correctly.
- **No Internet Connection (Wi-Fi):** Ensure Wi-Fi is enabled in Windows settings. Check if your Wi-Fi network is visible and you are entering the correct password.
- **Peripheral Not Working:** Ensure USB devices are properly plugged into a functional USB port. Try a different port or device. For PS/2 devices, ensure they are connected before powering on the PC.
- **System Slowdown:** Close unnecessary applications. Check for background processes in Task Manager. Ensure sufficient free storage space.

9. SPECIFICATIONS

Key technical specifications for the iCan iSmart Home Desktop Computer ISM-1:

Feature	Specification
Model	ISM-1 (Q15 Mini Tower)
Processor (CPU)	AMD Ryzen 5 5500GT (6 Cores, 12 Threads, up to 4.4GHz)
Graphics (GPU)	AMD Radeon Graphics (Integrated)
Memory (RAM)	16GB DDR4-3200MHz
Storage (SSD)	500GB NVMe M.2 Solid State Drive
Operating System	Windows 11 Home (64-bit)
Networking	Built-in Wi-Fi & Bluetooth, Gigabit Ethernet
Power Supply	350W
Video Output	HDMI, DisplayPort, VGA
USB Ports	2x USB 2.0 (front), 2x USB 3.2 (front), 2x USB 2.0 (rear), 2x USB 3.2 (rear)
Audio Ports	Microphone, Line Out, Line In
Dimensions (Approx.)	Mini Tower Form Factor

10. WARRANTY AND SUPPORT

Warranty information for this product is not provided in the product details. For specific warranty terms and conditions, please contact the retailer or manufacturer directly.

For technical support or further assistance, please refer to the contact information provided by your point of purchase or the manufacturer, iCan.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GS8LH2Y9>

More documents and user manuals: <https://manuals.plus/>