

MOFII 104 Keys Retro Typewriter Wireless Keyboard and Mouse Combo

MOFII 104 Keys Retro Typewriter Wireless Keyboard and Mouse Combo User Manual

Model: 104 Keys Retro Typewriter Wireless Keyboard and Mouse Combo (B0GS9259BQ)

INTRODUCTION

Thank you for choosing the MOFII 104 Keys Retro Typewriter Wireless Keyboard and Mouse Combo. This product is designed to provide a comfortable and efficient typing experience with its vintage aesthetic and modern wireless technology. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your new device.



Image: The MOFII Wireless Keyboard and Mouse Combo, highlighting its ergonomic design and wireless features.



Image: Close-up of the MOFII keyboard and mouse, emphasizing responsive keys and battery status.

SETUP INSTRUCTIONS

Follow these steps to set up your wireless keyboard and mouse combo:

1. **Insert Batteries:** Open the battery compartments on both the keyboard and the mouse. Insert one AA battery into the keyboard and one AA battery into the mouse. Ensure correct polarity. (2 AA batteries are included).
2. **Locate USB Receiver:** The 2-in-1 nano USB receiver is typically stored within the mouse's battery compartment for convenience during shipping. Carefully remove it.
3. **Connect Receiver:** Plug the USB receiver into an available USB-A port on your computer. If your device only has Type-C ports, use the included Type-C adapter by plugging the USB receiver into it, then plugging the adapter into your device's Type-C port.
4. **Power On:** Turn on the power switches located on the underside of both the keyboard and the mouse.
5. **Automatic Connection:** The keyboard and mouse should automatically connect to your device. No additional drivers are typically required for Windows or Mac systems.



Image: Visual guide for inserting batteries and connecting the USB receiver, including the Type-C adapter.

USER GUIDE

Step 1

Insert the batteries on keyboard and mouse



Step 2

plug the usb-a receiver



Step 3

Waiting for automatic connection creation to be used successfully



Dual Connection Modes, If your devices don't have a USB port, please use a spare OTG adapter to connect the 2-in-1 nano receiver first, then connect your device.

Image: Illustration of the 2-in-1 nano receiver and how to use it with the Type-C adapter for broader compatibility.



Type-C Adapter

2 in1 nano receiver connects both the wireless



Image: The keyboard and mouse connected to a laptop, demonstrating the one-click plug-and-play functionality.

OPERATING INSTRUCTIONS

General Use

The keyboard features a full-size 104-key QWERTY layout with round retro-style keycaps, a numeric keypad, and function keys. The mouse is optical with a comfortable ergonomic design.

Multimedia Hotkeys

The keyboard includes 13 multi-functional shortcut keys accessible by pressing the **Fn** key in combination with the corresponding F-keys (F1-F12) or Esc key. These hotkeys provide quick access to multimedia controls and other functions:

- **Fn + Esc:** Music Player
- **Fn + F1:** Play/Pause
- **Fn + F2:** Previous Track
- **Fn + F3:** Next Track
- **Fn + F4:** Volume Up

- **Fn + F5:** Volume Down
- **Fn + F6:** Mute
- **Fn + F7:** Web Home
- **Fn + F8:** Search
- **Fn + F9:** My Favorite
- **Fn + F10:** Mail
- **Fn + F11:** Key Lock
- **Fn + F12:** My Computer

Note for Mac users: Some hotkeys may not function as described, but core typing and mouse functions are supported.



Image: The keyboard layout highlighting the 13 multi-functional shortcut keys for enhanced convenience.

Power Management

Both the keyboard and mouse feature independent power switches and an auto-sleep mode. After 30 minutes of inactivity, the devices will enter sleep mode to conserve battery life. To wake them up, simply double-click any key on the keyboard or move the mouse.



Image: Diagram illustrating the smart power management features, including auto-sleep mode and long battery life.

Ergonomic Design

The keyboard is designed with an ergonomic tilt, featuring built-in stands to provide a comfortable typing angle. The mouse is shaped to minimize wrist strain during extended use.



Ergonomic Tilt with Built-In Stands, Comfortable Typing Angle, Anytime

Image: Close-up of the keyboard's adjustable tilt legs, designed for a comfortable typing angle.



Image: The keyboard and mouse in use, illustrating effortless and efficient typing with reduced wrist pressure.

MAINTENANCE

To ensure the longevity and optimal performance of your MOFII keyboard and mouse, regular cleaning is recommended.

Cleaning the Keyboard

The keyboard features removable keycaps, making cleaning easier. Gently pull the keycaps upwards to remove them. Use the included long-handled stiff bristle brush to clean dust and debris from between the keys and the keyboard base. The dense bristle texture and extended handle allow for effective cleaning without effort. After cleaning, carefully press the keycaps back into place until they click.

Cleaning the Mouse

Use a soft, dry cloth to wipe the exterior of the mouse. For the optical sensor, use a cotton swab lightly dampened with rubbing alcohol to gently clean the sensor area. Ensure no liquid enters the mouse's internal components.



Image: The included long-handled stiff bristle brush, ideal for cleaning between keyboard gaps.

TROUBLESHOOTING

If you encounter issues with your MOFII Wireless Keyboard and Mouse Combo, please refer to the following common solutions:

- **No Connection / Disconnecting Frequently:**

- Ensure both the keyboard and mouse are powered on.
- Check if the batteries are correctly inserted and have sufficient charge. Replace batteries if necessary.
- Verify that the USB receiver is securely plugged into a working USB port on your computer or the Type-C adapter.
- Try plugging the USB receiver into a different USB port.
- Move the keyboard and mouse closer to the USB receiver to rule out range issues (maximum range is 33 feet).
- Avoid using the devices near strong electromagnetic interference sources (e.g., other wireless devices, large metal objects).

- **Keys Sticking or Not Responding:**

- Clean the keyboard thoroughly, especially around the affected keys, using the provided brush or by removing keycaps.
- Ensure no debris is lodged under the keycaps.
- If a specific key consistently sticks, it might indicate a mechanical issue.

- **Mouse Cursor Jumps or is Erratic:**

- Clean the optical sensor on the underside of the mouse.
- Ensure you are using the mouse on a suitable surface. Optical mice perform best on non-reflective, uniform surfaces.
- Check battery level and replace if low.

- **Hotkeys Not Working on Mac:**

- As noted, some hotkeys may not be fully supported on Mac OS due to system differences. Core functions will still operate.

SPECIFICATIONS

Brand	MOFII
Model	104 Keys Retro Typewriter Wireless Keyboard and Mouse Combo
Color	Coffee Brown
Connectivity Technology	2.4GHz Wireless
Compatible Devices	Personal Computer (Windows, Mac, Chrome OS, Linux)
Keyboard Layout	QWERTY, Full-size with Numeric Keypad
Number of Keys	104
Mouse Movement Detection	Optical
Power Source	Battery Powered (1 AA for keyboard, 1 AA for mouse, included)
Wireless Range	Up to 33 feet (10 meters)
Item Weight	1.8 pounds



Image: Detailed dimensions of the keyboard and mouse for reference.

WARRANTY AND SUPPORT

This MOFII Wireless Keyboard and Mouse Combo comes with a **2-Year Manufacturer Warranty**. For warranty claims, technical support, or any product-related inquiries, please contact MOFII customer service through the retailer where you purchased the product or visit the official MOFII website for support contact information. A free replacement for a damaged receiver is also offered.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question