BassBloom ROAR 3

BassBloom Roar 3 Portable Bluetooth Speaker User Manual

Model: ROAR 3

Introduction Safety Information Package Contents Product Overview Setup Operating Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Thank you for purchasing the BassBloom Roar 3 Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker. Please read it thoroughly before use to ensure optimal performance and longevity of your device.



Image: The BassBloom Roar 3 speaker, showcasing its portable design.

2. Safety Information

- Do not expose the speaker to extreme temperatures (hot or cold) or direct sunlight for extended periods.
- Avoid dropping or subjecting the speaker to strong impacts.
- Keep the speaker away from water and liquids, except for its intended IPX6 water resistance. Ensure all port covers

are securely closed before exposure to water.

- Do not attempt to disassemble, repair, or modify the speaker yourself. Contact authorized service personnel for any repairs.
- Use only the provided charging cable or a certified equivalent.
- Keep out of reach of children.

3. Package Contents

Please check the package for the following items:

- BassBloom Roar 3 Portable Bluetooth Speaker
- Power Cable (USB-C)
- User Manual (this document)

4. Product Overview

4.1 Speaker Components



Image: Internal view of the speaker, illustrating the 20W audio engine for powerful sound.

The BassBloom Roar 3 features a powerful 20W audio engine designed to deliver clear and deep bass sound. It incorporates advanced acoustic design for an immersive listening experience.

4.2 Controls and Ports

Familiarize yourself with the buttons and ports on your speaker:



Image: Detailed view of the speaker's control panel, including the LED battery readout and function buttons.

- **Power Button:** Press and hold to turn on/off. Short press to check battery status.
- **Volume Up (+):** Short press to increase volume.
- **Volume Down (-):** Short press to decrease volume.
- **Play/Pause Button:** Short press to play/pause music. Press and hold for voice assistant.
- **Bluetooth Button:** Short press to enter pairing mode. Press and hold to disconnect current device.
- **Light Mode Button:** Short press to cycle through RGB light modes. Press and hold to turn lights off/on.

- **EQ Button:** Short press to cycle through equalizer presets.
- **USB-C Charging Port:** For charging the speaker.
- **LED Battery Display:** Shows current battery percentage.

5. Setup

5.1 Charging the Speaker

1. Open the protective cover on the charging port.
2. Connect the provided USB-C charging cable to the speaker's charging port.
3. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
4. The LED battery display will show the charging progress. A full charge is indicated by "100" on the display.
5. Close the protective cover securely after charging to maintain IPX6 water resistance.



Image: The speaker demonstrating its 24-hour playtime capability after a full charge.

5.2 Powering On/Off

- **To Power On:** Press and hold the Power button for approximately 2-3 seconds until you hear an audible prompt and the LED lights illuminate.
- **To Power Off:** Press and hold the Power button for approximately 2-3 seconds until you hear an audible prompt and the LED lights turn off.

5.3 Bluetooth Pairing

1. Ensure the speaker is powered on and within 10 meters (33 feet) of your Bluetooth device.
2. The speaker will automatically enter Bluetooth pairing mode, indicated by a flashing blue light (or similar indicator). If not, short press the Bluetooth button.
3. Enable Bluetooth on your device (smartphone, tablet, computer).
4. Search for "BassBloom Roar 3" in the list of available Bluetooth devices.
5. Select "BassBloom Roar 3" to connect. Once connected, you will hear a confirmation sound, and the Bluetooth indicator light will become solid.

5.4 True Wireless Stereo (TWS) Pairing

TWS allows you to pair two BassBloom Roar 3 speakers together for a stereo sound experience.



Image: Two BassBloom Roar 3 speakers connected via TWS for an enhanced audio experience.

1. Ensure both BassBloom Roar 3 speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be the primary speaker), press and hold the Bluetooth button for 3 seconds. You will hear a prompt indicating TWS pairing mode.
3. The primary speaker will automatically search for the secondary speaker. Once connected, you will hear a confirmation sound.

4. Now, connect your device to the primary speaker via Bluetooth as described in section 5.3. Both speakers will play audio in stereo.

6. Operating Instructions

6.1 Playing Music

- Once connected via Bluetooth, open your music player application on your device and start playing music.
- **Play/Pause:** Short press the Play/Pause button on the speaker.
- **Next Track:** Double-press the Play/Pause button.
- **Previous Track:** Triple-press the Play/Pause button.

6.2 Controlling Volume

- **Increase Volume:** Short press the Volume Up (+) button.
- **Decrease Volume:** Short press the Volume Down (-) button.

6.3 Managing Calls

- **Answer/End Call:** Short press the Play/Pause button.
- **Reject Call:** Press and hold the Play/Pause button for 2 seconds.
- **Voice Assistant:** Press and hold the Play/Pause button for 2 seconds when not on a call to activate your device's voice assistant.

6.4 RGB Light Modes

The BassBloom Roar 3 features dynamic RGB lighting. Short press the Light Mode button to cycle through various lighting effects:




Image: The speaker showcasing its various RGB light modes, synchronizing with music.

- Cycle
- Pulse
- Blink
- Vary
- Circle
- Press and hold the Light Mode button to turn the lights off or on.

6.5 EQ Modes

Short press the EQ button to switch between different equalizer presets, optimizing the sound for various music genres or listening preferences. The speaker utilizes an exclusive JIKE Bass Algorithm for enhanced low-frequency performance.



Image: Representation of the JIKE Bass Algorithm chip, responsible for deep bass optimization.

7. Maintenance

7.1 Cleaning

- Wipe the speaker with a soft, damp cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Ensure the charging port cover is closed before cleaning with a damp cloth.

7.2 Storage

- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, charge the battery to approximately 50% every three months to prolong battery life.

7.3 Water Resistance (IPX6)

The BassBloom Roar 3 is IPX6 water-resistant, meaning it can withstand powerful water jets. This makes it suitable for outdoor use and environments where it might be exposed to splashes or rain. However, it is not designed for submersion in water.

- Always ensure the charging port cover is securely closed before exposing the speaker to water.
- Do not intentionally submerge the speaker in water.
- After exposure to water, wipe the speaker dry with a soft cloth before charging.

8. Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.
Cannot pair via Bluetooth.	Speaker not in pairing mode; device Bluetooth off; too far from device.	Ensure speaker is in pairing mode (flashing light). Turn on device Bluetooth. Move speaker closer to device. Forget "BassBloom Roar 3" on your device and try pairing again.
No sound.	Volume too low; speaker not connected; audio source paused.	Increase speaker and device volume. Reconnect Bluetooth. Check if music is playing on your device.
Poor sound quality.	Low battery; interference; speaker too far from device.	Charge the speaker. Move speaker closer to device. Avoid obstacles between speaker and device.
TWS pairing fails.	Speakers already connected to other devices; incorrect pairing procedure.	Ensure both speakers are disconnected from all devices. Follow TWS pairing steps carefully (Section 5.4).

9. Specifications

Brand	BassBloom
Model Name	BassBloom ROAR 3

Model Number	ROAR 3
Speaker Maximum Output Power	30 Watts
Connectivity Technology	Bluetooth 5.4
Mounting Type	Tabletop Mount
Speaker Type	Portable Speaker
Colour	Sky Blue
Speaker Size	52 Millimetres
Signal-to-Noise Ratio	80 dB
Item Dimensions (D x W x H)	20.3D x 7.6W x 7.6H Centimeters
Water Resistance	IPX6
Playtime	Up to 24 Hours
Batteries Required	1 Nonstandard Battery (included)
Box Contents	Power Cable, User Manual

10. Warranty & Support

The BassBloom Roar 3 Portable Bluetooth Speaker comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions, including warranty duration and coverage. For technical support, troubleshooting assistance, or warranty claims, please contact BassBloom customer service through the contact information provided on the product packaging or the official BassBloom website. Please have your model number (ROAR 3) and proof of purchase ready when contacting support.

© 2026 BassBloom. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Can you use Alexa commands on the BassBloom Roar 3 speaker when it is connected via Bluetooth to an iPhone?

Yes, you can use Alexa commands with the BassBloom Roar 3, but because it is a Bluetooth speaker and not a standalone Wi-Fi smart speaker, it relies on your iPhone's voice assistant integration. To...

Read full answer