

Aoxun G18001-3GR-AXUS

Aoxun Outdoor Porch Swing with Stand and Canopy - Instruction Manual

Model: G18001-3GR-AXUS

1. INTRODUCTION

Thank you for choosing the Aoxun Outdoor Porch Swing. This manual provides essential information for the safe assembly, operation, and maintenance of your new porch swing. Please read all instructions carefully before use and retain this manual for future reference.

2. SAFETY INFORMATION

- **Weight Capacity:** Do not exceed the maximum weight recommendation of 800 pounds (approximately 360 kg). This swing is designed for up to 3 adults.
- **Assembly:** Ensure all parts are correctly assembled and tightened according to the instructions. Regularly check all bolts and nuts for tightness.
- **Placement:** Place the swing on a flat, stable surface to prevent tipping. Avoid placing it near open flames, heaters, or sharp objects.
- **Children:** Supervise children at all times when they are using the swing.
- **Weather Conditions:** While the canopy is splash-proof, it is recommended to secure or remove the canopy during strong winds or heavy rain to prevent damage. Store cushions indoors during adverse weather.
- **Maintenance:** Regularly inspect the swing for any signs of wear, damage, or loose components. Do not use if damaged.

3. PRODUCT COMPONENTS

Your Aoxun Porch Swing includes the following main components:

- Durable Metal Frame (Powder Coated)
- 3-Seat Cushioned Fabric Seating
- Adjustable Canopy

- Heavy-duty Springs and Reinforced Metal Hooks
- 2 Cylindrical Pillows
- Foldable Side Tables with Cup Holders
- Assembly Hardware (bolts, nuts, tools)

4. ASSEMBLY INSTRUCTIONS

Assembly is required for this product. Please follow the detailed instructions provided in the separate assembly guide included with your purchase. Ensure all parts are accounted for before beginning assembly. It is recommended to have at least two adults for assembly.

Key Assembly Features:

- **Sturdy Frame:** The swing features a robust metal frame for stability.
- **Spring Suspension:** Heavy springs connect the swing seat to the frame for a smooth rocking motion.
- **Canopy Attachment:** The adjustable canopy attaches to the top frame.



Figure 4.1: Product dimensions for the Aoxun Outdoor Porch Swing.

Superior Stability & Safety



Figure 4.2: Illustration of the durable steel stand and frame material.

5. OPERATING INSTRUCTIONS

5.1 Using the 3-Seat Swing

The swing is designed to comfortably seat up to three individuals. Gently push off the ground to initiate a smooth, gentle rocking motion. The heavy-duty springs ensure a quiet and stable experience.



Figure 5.1: The Aoxun porch swing provides a spacious and secure seating area.

5.2 Converting to a 2-in-1 Swing Bed

To convert the swing into a flat bed for lounging or napping:

1. Locate the spring locks on both sides of the swing's backrest.
2. Release these spring locks.
3. Gently push the backrest down until it lies flat, aligning with the seat cushions to form a continuous bed surface.
4. Ensure the sturdy locking system engages to secure the bed position.

2-In-1 Design to Meet Your Needs



Relaxing



Sleeping

Figure 5.2: The swing easily converts into a comfortable bed.

Your browser does not support the video tag.

Video 5.1: Demonstration of converting the swing into a daybed. This video shows the ease of transformation from a seated swing to a flat lounging bed.

5.3 Adjusting the Canopy

The canopy can be adjusted up to 60 degrees to provide optimal shade throughout the day. Simply loosen the adjustment knobs on the sides of the canopy, position it as desired, and then tighten the knobs to secure it.

3-Seats Swing Adds Joy to Outdoor Living



Figure 5.3: The canopy offers adjustable shade and is splash-proof.

5.4 Using the Foldable Side Tables

The swing includes built-in foldable side tables with deep cup holders on both sides. These can be extended for holding beverages, phones, or small items, and folded away when not in use to save space.



Foldable Sidetable

Conveniently to hold drinks and phones

Figure 5.4: Foldable side table with cup holders for convenience.

6. MAINTENANCE

- **Cleaning Frame:** Wipe the metal frame with a damp cloth and mild soap. Dry thoroughly to prevent rust.
- **Cushions and Canopy:** The cushions and canopy are made of cushioned fabric. Spot clean with a mild detergent and water. Allow to air dry completely. For prolonged life, store cushions indoors when not in use or during inclement weather.
- **Hardware:** Periodically check all bolts, nuts, and connections to ensure they are tight. Tighten as necessary.
- **Storage:** During off-season or extended periods of non-use, it is recommended to store the swing in a dry, protected area to extend its lifespan.

7. TROUBLESHOOTING

- **Squeaking Noise:** If the swing makes squeaking noises, apply a silicone-based lubricant to the springs and pivot points.

- **Instability:** Ensure the swing is placed on a level surface. Check all frame connections and tighten any loose bolts.
- **Canopy Not Holding Position:** Ensure the adjustment knobs on the canopy are fully tightened after positioning.

8. SPECIFICATIONS

Feature	Detail
Brand	Aoxun
Model Number	G18001-3GR-AXUS
Color	Grey
Material	Metal (Frame), Cushioned Fabric (Seat/Canopy)
Product Dimensions (D x W x H)	120.1D x 194.3W x 174.5H Centimetres
Item Weight	88 Pounds (approximately 39.9 kg)
Maximum Weight Recommendation	800 Pounds (approximately 362.8 kg)
Maximum Number of Compatible Seats	3
Assembly Required	Yes

9. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the documentation included with your purchase or contact Aoxun customer service directly. Keep your proof of purchase for any warranty claims.