

BOOX Go 10.3 Gen2 Lumi

BOOX Go 10.3 Gen2 Lumi E-Paper E-Reader User Manual

INTRODUCTION

This manual provides comprehensive instructions for the BOOX Go 10.3 Gen2 Lumi E-Paper E-Reader. It covers device setup, operation, maintenance, and troubleshooting to ensure optimal use of your device. The BOOX Go 10.3 Gen2 Lumi is a 10.3-inch E-Ink tablet featuring a monochrome backlight, 300 DPI resolution, 64GB of storage, and runs on Android 15, designed for a paper-like reading and writing experience.

WHAT'S IN THE BOX

Upon unboxing your BOOX Go 10.3 Gen2 Lumi, please verify that all the following items are included:

- BOOX Go 10.3 Gen2 Lumi E-Paper E-Reader
- USB-C Charging Cable
- InkSense Plus Stylus

SETUP

1. **Charging the Device:** Before first use, fully charge your BOOX Go 10.3 Gen2 Lumi using the provided USB-C cable and a compatible power adapter (not included). Connect the USB-C cable to the device's charging port and the other end to a power source. The charging indicator will show the charging status.
2. **Powering On/Off:** Press and hold the power button (usually located on the side or top edge) for a few seconds until the BOOX logo appears to power on. To power off, press and hold the power button until a power-off menu appears, then select 'Power Off'.
3. **Initial Setup:** Follow the on-screen prompts to complete the initial setup, which includes selecting your language, connecting to Wi-Fi, and logging into your BOOX account or Google account.
4. **Stylus Pairing:** The InkSense Plus Stylus is typically pre-paired. If not, follow the device's instructions to pair it via Bluetooth or by simply touching the screen with the stylus.

OPERATING INSTRUCTIONS

Basic Navigation

The BOOX Go 10.3 Gen2 Lumi features a responsive E-Ink touchscreen. Use your finger to tap, swipe, and pinch to navigate through menus, open applications, and interact with content.

Reading Documents

Open your desired document or e-book from the library. Swipe left or right on the screen to turn pages. Tap the center of the screen to bring up reading settings, allowing you to adjust font size, contrast, and backlight.



Image: A user comfortably reading on the BOOX Go 10.3 Gen2 Lumi, demonstrating its portability and clear display for outdoor use.

enough to move it far away. Weena I had resolved to bring with me to our own time. And turning such schemes over in my mind I pursued our way towards the building which my fancy had chosen as our dwelling.

XI

The Palace of Green Porcelain

“I found the Palace of Green Porcelain, when we approached it about noon, deserted and falling into ruin. Only ragged vestiges of glass remained in its windows, and great sheets of the green facing had fallen away from the corroded metallic framework. It lay very high upon a turfy down, and looking north-eastward before I entered it, I was surprised to see a large estuary, or even creek, where I judged Wandsworth and Battersea must once have been. I thought then—though I never followed up the thought—of what

might have happened, or might be happening, to the living things in the sea.

“The material of the Palace proved on examination to be indeed porcelain, and along the face of it I saw an inscription in some unknown character. I thought, rather foolishly, that Weena might help me to interpret this, but I only learnt that the bare idea of writing had never entered her head. She always seemed to me, I fancy, more human than she was, perhaps because her affection was so human.

“Within the big valves of the door—which were open and broken—we found, instead of the customary hall, a long gallery lit by many side windows. At the first glance I was reminded of a museum. The tiled floor was thick with dust, and a remarkable array of miscellaneous objects was shrouded in the same grey covering. Then I perceived, standing strange and gaunt in the centre of the hall, what was clearly the lower part of a huge skeleton. I recognised by the oblique feet that it was some extinct creature after the fashion of the Megatherium. The skull and the upper bones lay beside it in the thick dust, and in one

Image: The BOOX Go 10.3 Gen2 Lumi displaying an e-book, highlighting the clear E-Ink display and comfortable reading experience.




Image: The BOOX Go 10.3 Gen2 Lumi's reading settings menu, illustrating customizable options for an optimized reading experience.

Note-Taking and Sketching

Utilize the InkSense Plus Stylus for precise note-taking, annotations, and freehand sketching. Open the 'Notes' application or use the annotation features within documents. The stylus offers a natural writing feel on the E-Ink screen.



Image: A user actively writing on the BOOX Go 10.3 Gen2 Lumi with the InkSense Plus Stylus, showcasing its note-taking capabilities.



Image: The BOOX Go 10.3 Gen2 Lumi being used for creative tasks like sketching, highlighting its versatility and portability for various environments.

Connectivity

The device supports USB connectivity for data transfer and charging. Connect your device to a computer using the USB-C cable to transfer files such as e-books, documents, and notes.

Android 15 Features

Leverage the Android 15 operating system to install compatible applications from the BOOX App Store or other authorized sources, expanding the functionality of your e-reader beyond basic reading and writing.

Product Overview Video

Your browser does not support the video tag. Please update your browser or try a different one.

Video: A comprehensive overview of the BOOX Go 10.3 Gen2 Lumi E-Paper E-Reader, demonstrating its key features, design, and user experience. This video highlights the device's capabilities for reading, writing, and general use. (Note: A valid video URL is required for playback.)

MAINTENANCE

- **Cleaning the Screen:** Use a soft, lint-free cloth specifically designed for electronics to gently wipe the E-Ink screen. Avoid using harsh chemicals or abrasive materials.
- **Battery Care:** To prolong battery life, avoid exposing the device to extreme temperatures. Charge the device regularly, but avoid leaving it fully discharged for extended periods.
- **Software Updates:** Regularly check for and install software updates to ensure optimal performance and access to the latest features and security enhancements.

TROUBLESHOOTING

- **Device Not Turning On:** Ensure the device is sufficiently charged. Connect it to a power source and wait a few minutes before attempting to power on again. If the issue persists, try a hard reset (refer to the device's specific hard reset instructions, usually involving holding the power button for a longer duration).
- **Screen Freezing:** If the screen becomes unresponsive, perform a soft reset by holding the power button until the device restarts.
- **Stylus Not Responding:** Check if the stylus is properly paired. Ensure there is no physical obstruction on the screen or stylus tip. If the stylus uses a battery, ensure it is charged or replaced.
- **Wi-Fi Connectivity Issues:** Verify that your Wi-Fi network is active and you have entered the correct password. Try restarting both your device and your Wi-Fi router.

SPECIFICATIONS

Brand	BOOX
Model Name	Go 10.3 Gen2 Lumi
Display Technology	E-Ink
Connectivity Technology	USB
Screen Size	10.3 Inches
Memory Storage Capacity	64 GB
Included Components	Charging Cable, Stylus
Product Dimensions (L x W x H)	23.5 x 0.4 x 18 cm
Item Weight	365 Grams
Human Interface Input	Touchscreen
Country of Origin	China



ENERG ⚡



BOOX

Go 10.3 (Gen II)



37 h **43** min




Image: EU Energy Label for the BOOX Go 10.3 (Gen II) series, indicating its energy efficiency and other environmental specifications. For more details, scan the QR code or visit eprel.ec.europa.eu/qr/266643.

WARRANTY AND SUPPORT

Warranty Information

The BOOX Go 10.3 Gen2 Lumi E-Paper E-Reader comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. Please retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, warranty claims, or further inquiries, please visit the official BOOX support website or contact their customer service. Refer to the packaging or the BOOX website for the most up-to-date contact information.