

[Manuals.plus](#) /

› [FABULETTA](#) /

› FABULETTA Stainless Steel Slow-Close Toilet Seat Hinge Instruction Manual

FABULETTA C8474UV3P3I0DA56VPEZXF8S03

FABULETTA Stainless Steel Slow-Close Toilet Seat Hinge Instruction Manual

Model: C8474UV3P3I0DA56VPEZXF8S03

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your FABULETTA Stainless Steel Slow-Close Toilet Seat Hinge. Please read these instructions carefully before installation and retain this manual for future reference. This product is designed to provide a slow-closing action for toilet seats, preventing slamming and reducing noise.

PACKAGE CONTENTS

Before beginning installation, verify that all components are present in the package. If any parts are missing or damaged, please contact customer support.

- 2 x Slow-Close Toilet Seat Hinges (Stainless Steel)
- 2 x Rubber Expansion Bolts (for top-mount installation)
- 2 x Metal Washers
- 2 x Plastic Washers
- 2 x Chrome Cover Caps
- 2 x Rubber Gaskets (for hinge base)
- 2 x Metal Plates (for hinge base)



Image: All components included in the FABULETTA slow-close toilet seat hinge kit, including two hinges, two rubber expansion bolts, washers, cover caps, gaskets, and metal plates.

SETUP AND INSTALLATION

This section details the steps required to install the slow-close toilet seat hinges. Ensure you have a screwdriver (Phillips head recommended) and a clean cloth before starting.

Step 1: Remove Old Hinges (if applicable)

1. Open the toilet seat and lid.
2. Locate the existing hinge fasteners. These are typically bolts or screws accessible from the top or bottom of the toilet bowl.
3. Unscrew and remove the old hinges, seat, and lid. Clean the area around the mounting holes.

Step 2: Prepare New Hinges

1. Take one new hinge. Ensure the quick-release button is functional.
2. Place a rubber gasket (if provided) onto the bottom of the hinge base, followed by a metal plate.



Image: A detailed view of one FABULETTA slow-close toilet seat hinge, highlighting its quick-release mechanism and mounting points.

Step 3: Install Hinges onto Toilet Bowl

1. Insert the rubber expansion bolt through the hole in the hinge base (with gasket and plate if used).
2. Align the hinge assembly with one of the mounting holes on the toilet bowl.
3. Insert the rubber expansion bolt into the toilet bowl mounting hole.
4. Using a screwdriver, tighten the screw on top of the rubber expansion bolt. As you tighten, the rubber will expand, securing the hinge firmly in place. Do not overtighten.
5. Repeat for the second hinge on the other mounting hole.
6. Ensure both hinges are aligned and parallel.



Image: The individual components used for mounting the hinge to the toilet bowl, including the rubber expansion bolts, metal washers, and plastic washers.

Step 4: Attach Toilet Seat and Lid

1. Align the mounting posts of the toilet seat and lid with the hinges installed on the toilet bowl.
2. Gently press the seat and lid down onto the hinges until they click into place. The quick-release mechanism should engage.
3. Test the slow-close function by lifting the seat and lid and letting them go. They should lower slowly and silently.



Image: Two FABULETTA slow-close toilet seat hinges displayed, illustrating their design and how they would appear when installed on a toilet bowl.

OPERATING INSTRUCTIONS

The FABULETTA slow-close toilet seat hinges are designed for simple operation and maintenance.

Slow-Close Function

Simply lift the toilet seat or lid to the desired open position. When released, the integrated slow-close mechanism will gently lower the seat and lid back to the closed position without slamming. This feature operates automatically.

Quick-Release Feature

For easy cleaning or replacement, the toilet seat and lid can be quickly detached from the hinges. Locate the two quick-release buttons on the back of each hinge (typically small, black buttons). Press both buttons simultaneously and lift the entire toilet seat assembly straight up. To reattach, align the seat posts with the hinges and press down until they click into place.



Image: A complete view of the FABULETTA slow-close toilet seat hinge kit, showing all components including the two hinges, rubber expansion bolts, washers, and chrome caps.

MAINTENANCE AND CARE

Proper maintenance ensures the longevity and optimal performance of your FABULETTA slow-close toilet seat hinges.

- **Cleaning:** Use a soft, damp cloth and mild soap to clean the hinges. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the stainless steel finish.
- **Inspection:** Periodically check the tightness of the mounting screws. If the seat feels loose, gently retighten the screws on the rubber expansion bolts.
- **Slow-Close Mechanism:** The slow-close mechanism is sealed and requires no lubrication or internal maintenance. If the slow-close function degrades, ensure the hinges are clean and properly installed.



Image: An alternative perspective of the FABULETTA slow-close toilet seat hinge kit, showcasing the two hinges and all associated mounting hardware.

TROUBLESHOOTING

If you encounter issues with your slow-close toilet seat hinges, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Seat/Lid slams shut.	Slow-close mechanism not engaging or damaged.	◦ Ensure hinges are clean and free of debris. ◦ Verify the seat is correctly attached to the hinges. Detach and reattach if necessary. ◦ If the issue persists, the mechanism may be damaged. Contact customer support for replacement.
Seat/Lid is loose or wobbly.	Mounting screws are loose.	◦ Gently tighten the screws on the rubber expansion bolts. Do not overtighten. ◦ Ensure the rubber expansion bolts are fully engaged in the toilet bowl holes.
Seat/Lid difficult to remove with quick-release.	Buttons not pressed simultaneously or seat misaligned.	◦ Ensure both quick-release buttons are pressed firmly and simultaneously. ◦ Lift the seat straight up without twisting.

SPECIFICATIONS

Feature	Detail
Product Name	Slow-Close Toilet Seat Hinge
Model Number	C8474UV3P3I0DA56VPEZXF8S03
Material	Stainless Steel
Opening Angle	115°
Closing Angle	-5°
Slow Fall Effect	115° to 75° fast, 75° to 0° slow
Product Dimensions	3.94 x 3.94 x 1.97 inches (per hinge)
Item Weight	12.9 ounces (total package)

WARRANTY AND SUPPORT

For warranty information or technical support, please contact FABULETTA customer service. Details regarding product warranty are typically provided with your purchase documentation or can be found on the official FABULETTA website. When contacting support, please have your product model number (C8474UV3P3I0DA56VPEZXF8S03) and purchase date available.



