

Hurom H80-ST

Hurom H80-ST Slowjuicer Instruction Manual

Model: H80-ST

1. INTRODUCTION

Thank you for choosing the Hurom H80-ST Slowjuicer. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new appliance. Please read all instructions carefully before first use and retain this manual for future reference.

The Hurom H80-ST is an electric cold press juicer designed to extract juice from a variety of fruits and vegetables, featuring a 2.2L capacity and automatic juice extraction. It is constructed with BPA-free materials for your safety.

2. IMPORTANT SAFETY INFORMATION

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before using the appliance.
- Do not immerse the motor base in water or other liquids.
- Keep hands and utensils out of the feed chute during operation to prevent injury. Use the food pusher provided.
- Ensure the appliance is properly assembled before operation.
- Unplug from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- This appliance is for household use only.
- Like all other Hurom slow juicers, the H80-ST slow juicer is made from BPA-free materials.

3. PRODUCT COMPONENTS

Familiarize yourself with the parts of your Hurom H80-ST Slowjuicer:



Figure 3.1: Front view of the Hurom H80-ST Slowjuicer in matte titanium gray. Shows the main body, the transparent hopper, and the juice outlet.



Figure 3.2: Back view of the Hurom H80-ST Slowjuicer, highlighting the power cord connection point and ventilation.



Figure 3.3: Cross-section view illustrating the internal spiral pressing screw technology and juicing process.



Figure 3.4: The juicer in action, showing juice being extracted into a clear collection container.

Key Components:

- **Motor Base:** The main unit containing the motor and controls.
- **Hopper:** The top section where ingredients are fed. Features an extra-large feed chute.
- **Auger (Pressing Screw):** The spiral component that crushes and presses ingredients.
- **Fine Screen:** For clear, pulp-free juice.
- **Coarse Screen:** For juice with more pulp or for softer fruits.
- **Ice Cream Screen:** For making frozen desserts.
- **Juice Cup:** Collects the extracted juice.
- **Pulp Container:** Collects the discarded pulp.
- **Cleaning Brushes:** For easy cleaning of parts.

4. SETUP INSTRUCTIONS

Follow these steps to assemble your Hurom H80-ST Slowjuicer before first use:

1. **Unpack:** Carefully remove all components from the packaging.

2. **Clean:** Wash all removable parts (hopper, auger, screens, juice cup, pulp container) with warm, soapy water. Rinse thoroughly and dry. The main unit should be wiped with a damp cloth.
3. **Assemble Juicing Chamber:** Place the desired screen (fine, coarse, or ice cream) into the juicing chamber. Insert the auger into the center of the screen.
4. **Attach Hopper:** Align the hopper with the juicing chamber and twist until it locks securely into place.
5. **Place on Motor Base:** Position the assembled juicing chamber and hopper onto the motor base, ensuring it clicks into place.
6. **Position Containers:** Place the juice cup under the juice outlet and the pulp container under the pulp outlet.
7. **Connect Power:** Plug the power cord into a grounded electrical outlet.

5. OPERATING INSTRUCTIONS

Operating your Hurom H80-ST Slowjuicer is straightforward:

1. **Prepare Ingredients:** Wash fruits and vegetables thoroughly. For optimal juicing, cut ingredients into pieces that fit easily into the extra-large feed chute. Remove hard pits, large seeds, and thick skins (e.g., pineapple, melon).
2. **Select Screen:** Choose the appropriate screen (fine for smooth juice, coarse for more pulp, or ice cream for frozen desserts) based on your recipe.
3. **Start Juicer:** Turn the power switch to the 'ON' position.
4. **Feed Ingredients:** Gradually feed the prepared ingredients into the feed chute. The auger will automatically pull them down. Use the food pusher only if necessary to gently guide ingredients. Do not force ingredients.
5. **Juice Extraction:** The juicer's spiral pressing screw technology will process the ingredients, separating juice into the juice cup and pulp into the pulp container.
6. **Reverse Function:** If ingredients get jammed, switch the juicer to the 'REV' (Reverse) position for a few seconds to clear the blockage, then switch back to 'ON'.
7. **Finish Juicing:** Once all ingredients are processed, allow the juicer to run for a few more seconds to extract any remaining juice.
8. **Turn Off:** Switch the power to the 'OFF' position and unplug the appliance.



Figure 5.1: The extra-large feed chute filled with a variety of

fruits and vegetables, demonstrating its capacity for easy juicing.



Figure 5.2: A user pouring freshly extracted green juice from the juicer, showcasing the clean juice outlet.

6. MAINTENANCE AND CLEANING

Proper cleaning ensures the longevity and hygiene of your slow juicer. All removable parts, except the main unit, are dishwasher safe.

1. **Disassemble:** After unplugging the juicer, disassemble all removable parts: hopper, auger, screen, juice cup, and pulp container.
2. **Rinse:** Rinse all parts under running water to remove large pulp residues.
3. **Wash:** Wash the removable parts with warm, soapy water using the provided cleaning brushes to remove stubborn pulp from the screen. Alternatively, place them in the dishwasher.
4. **Clean Main Unit:** Wipe the motor base with a damp cloth. Never immerse the motor base in water.
5. **Dry:** Ensure all parts are completely dry before reassembling or storing.
6. **Storage:** Store the clean and dry juicer in a cool, dry place.



Figure 6.1: Juicer components placed in a dishwasher rack, demonstrating their dishwasher-safe design for easy cleaning.

7. TROUBLESHOOTING

If you encounter issues with your Hurom H80-ST Slowjuicer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in, power switch off, or improper assembly.	Ensure the power cord is securely plugged in. Check the power switch. Reassemble the juicer, ensuring all parts are correctly locked.
Ingredients are not juicing or getting stuck.	Too many ingredients at once, ingredients are too large, or hard ingredients are jamming the auger.	Use the 'REV' (Reverse) function for a few seconds, then switch back to 'ON'. Cut ingredients into smaller pieces. Feed ingredients slowly.
Excessive vibration or noise.	Improper assembly or hard ingredients causing strain.	Disassemble and reassemble the juicer, ensuring all parts are correctly aligned and locked. Avoid juicing extremely hard items like whole nuts or ice cubes (unless using the ice cream screen for specific recipes).
Juice leakage.	Parts not properly assembled or seals are damaged.	Check that the juicing chamber and hopper are securely locked onto the motor base. Inspect seals for damage; contact support if damaged.

8. SPECIFICATIONS

Feature	Detail
Brand	Hurom
Model Number	H80-ST
Color	Matte Titanium Gray
Special Feature	Extra-large feed chute
Product Dimensions (D x W x H)	26.3D x 24.5W x 45.7H centimeters
Finish Type	Matte
Recommended Uses	Vegetables and Fruit
Product Care Instructions	Dishwasher safe (removable parts)
Capacity	2.2 liters

Feature	Detail
Maximum Power	200 Watts
Wattage	220 Watts
Power Source	Corded Electric
Voltage	220 Volts
Item Weight	6.1 Kilograms
BPA-free	Yes

9. WARRANTY AND SUPPORT

Warranty Information:

The Hurom H80-ST Slowjuicer comes with a **15-year warranty** on the motor and a 2-year warranty on parts, covering manufacturing defects under normal household use. Please retain your proof of purchase for warranty claims.

Customer Support:

For technical assistance, warranty claims, or spare parts, please contact Hurom Customer Support:

- **Website:** www.hurom.com/support
- **Email:** support@hurom.com
- **Phone:** +1-800-XXX-XXXX (Please check your regional Hurom website for local contact numbers)

When contacting support, please have your model number (H80-ST) and purchase date available.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question