ChooChoo PT2503

ChooChoo PT2503 Narrow Kitchen Pantry Storage Cabinet User Manual

Model: PT2503 | Brand: ChooChoo

1. Introduction

Thank you for choosing the ChooChoo PT2503 Narrow Kitchen Pantry Storage Cabinet. This freestanding storage unit is designed to maximize space in kitchens, dining rooms, or bathrooms, offering versatile storage solutions with adjustable shelves and door racks. This manual provides essential information for safe assembly, proper use, and maintenance of your new cabinet.



Figure 1: Fully assembled ChooChoo PT2503 Narrow Kitchen Pantry Storage Cabinet in a kitchen setting.



Figure 2: Overview of key features: space-saving design, large capacity, sturdy construction, and versatility.

2. Safety Information

Please read and understand all safety warnings and instructions before assembling and using this product. Failure to follow these instructions may result in injury or damage to the product.

- **Anti-Tip Safety Kit:** An anti-tip safety kit is included for added stability. It is crucial to install this kit to prevent the cabinet from tipping over, especially in households with children or pets.
- **Weight Distribution:** Distribute items evenly across shelves. Avoid placing heavy items on upper shelves to maintain stability.
- **Assembly:** Assemble the cabinet on a soft, clean surface to prevent scratches. Ensure all fasteners are securely tightened before use.
- **Supervision:** Keep children and pets away from the assembly area.

3. Package Contents

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Cabinet Panels (Side panels, back panels, top, bottom)
- Adjustable Shelves (4 included)
- Door with 3 built-in door racks
- Metal Handle
- Bottom Support Wheel
- Magnetic Door Catch
- Assembly Instruction Manual
- Anti-Tip Safety Kit
- Hardware Pack (screws, dowels, cam locks, etc.)

4. Assembly Instructions

Assembly typically requires two adults. Follow the detailed step-by-step instructions provided in the included assembly manual.

1. **Prepare the Area:** Clear a spacious, clean, and soft area for assembly to prevent damage to components.
2. **Identify Parts:** Lay out all components and hardware. Refer to the parts list in your assembly manual to identify each piece.
3. **Assemble the Frame:** Connect the side panels to the base and top panels using the provided hardware. Ensure all connections are secure.
4. **Install Back Panel:** Secure the back panel to the frame.
5. **Insert Shelves:** Place the adjustable shelves into the desired positions. The cabinet features four adjustable shelves for flexible storage.
6. **Attach Door:** Mount the door to the cabinet frame. Install the metal handle and magnetic door catch.
7. **Install Bottom Support Wheel:** Attach the bottom support wheel to the base of the cabinet for easier movement and stability.
8. **Install Anti-Tip Kit:** Securely attach the anti-tip safety kit to the cabinet and to a wall stud according to the instructions. This step is critical for safety.



Figure 3: Key features for assembly and use, including the anti-tip safety kit and adjustable shelves.

5. Operation and Usage

The ChooChoo PT2503 cabinet is designed for versatile storage in various rooms.

- **Adjustable Shelves:** Customize the interior space by repositioning the four adjustable shelves to accommodate items of different heights.
- **Door Racks:** Utilize the three built-in door racks for storing smaller items like spices, bottles, or condiments, keeping them easily accessible.
- **Space-Saving Design:** Its narrow profile allows it to fit into tight spaces, corners, or gaps, making it ideal for maximizing storage in compact areas.
- **Magnetic Closure:** The door features a smooth magnetic closure for secure and easy operation.



Figure 4: Detail of the extra door storage with three shelves.



Figure 5: The cabinet integrated into a kitchen, demonstrating its storage capacity.



Figure 6: The cabinet's versatile design allows use in various spaces, such as a bathroom.

6. Maintenance

To ensure the longevity and appearance of your ChooChoo storage cabinet, follow these maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood material.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.

7. Troubleshooting

If you encounter any issues with your cabinet, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cabinet feels wobbly or unstable.	Loose fasteners; uneven floor; anti-tip kit not installed.	Ensure all screws are tightened. Place shims under the base if the floor is uneven. **Install the anti-tip safety kit as instructed.**
Door does not close properly.	Misaligned hinges; magnetic catch not aligned.	Adjust the hinges to align the door. Check the position of the magnetic door catch and adjust if necessary.
Shelves are not level.	Shelf pins not fully inserted; uneven placement.	Ensure all shelf pins are fully inserted into the corresponding holes. Re-seat the shelf.

8. Specifications

Detailed specifications for the ChooChoo PT2503 Narrow Kitchen Pantry Storage Cabinet:

Feature	Detail
Brand	ChooChoo
Model Number	PT2503
Color	White
Material	Engineered Wood (MDF), Plywood (door frames)
Product Dimensions (D x W x H)	39.9D x 39.9W x 179.8H centimetres (15.7"D x 15.7"W x 70.8"H)
Item Weight	40.79 Pounds
Number of Shelves	7 (including 4 adjustable interior shelves and 3 door racks)
Mounting Type	Freestanding (with anti-tip kit for wall attachment)
Special Features	Narrow design, adjustable shelves, 3 door racks, anti-tip safety kit, bottom support wheel, magnetic door catch.
Assembly Required	Yes



Figure 7: Dimensional overview of the ChooChoo PT2503 cabinet.



Figure 8: Authentic plywood core display detail on the door frame.

9. Warranty and Support

For specific warranty information, please refer to the documentation included with your purchase or contact the retailer. If you have any questions regarding assembly, missing parts, or product functionality, please contact ChooChoo customer support for assistance.

You can typically find contact information on the manufacturer's website or through your purchase platform.

© 2026 ChooChoo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question