

[Manuals.plus](#) /

› [Luxell](#) /

› Luxell Electric Over-Blanket User Manual - Model SS01A(160\*120)-1X

## Luxell SS01A(160\*120)-1X

# Luxell Electric Over-Blanket User Manual

Model: SS01A(160\*120)-1X

### IMPORTANT SAFETY INSTRUCTIONS

---

Please read all instructions carefully before using your Luxell Electric Over-Blanket. Retain this manual for future reference. Failure to follow these instructions may result in electric shock, fire, or injury.

- Do not use with infants, children, incapacitated persons, or persons insensitive to heat.
- Do not use if the blanket is wet.
- Do not use if folded, rucked, or creased.
- Do not insert pins or other sharp objects into the blanket.
- Do not use with adjustable beds unless the blanket is designed for such use and the cable is not subject to kinking or trapping.
- Always disconnect the blanket from the power supply before cleaning.
- Regularly inspect the blanket, cord, and controller for any signs of wear or damage. If damaged, do not use and contact customer support.
- This appliance is not intended for medical use in hospitals.
- Keep the control unit away from water or other liquids.
- Ensure the blanket is used only with the detachable control unit provided.

### PRODUCT OVERVIEW

---

The Luxell Electric Over-Blanket provides warmth and comfort with adjustable heat and timer settings. It features a soft, double-sided flannel fabric and is designed for safe and convenient use.



**Figure 1:** Luxell Electric Over-Blanket with detachable controller, highlighting 160W power, 9 heat settings, and 160x120cm size.

### Key Features:

- **Size:** 160 x 120 cm
- **Material:** 100% Double-sided flannel fabric
- **Heat Settings:** 9 levels with indicator
- **Timer Settings:** 9 options (1-9 hours)
- **Power:** 160W
- **Safety:** Overheating protection
- **Convenience:** Removable cable for washing



**Figure 2:** Visual representation of key features including overheating protection, washability, and eco-friendly design.

## SETUP

---

1. **Unpack:** Carefully remove the electric over-blanket from its packaging. Retain packaging for storage if desired.
2. **Inspect:** Before first use, inspect the blanket, power cord, and control unit for any signs of damage. Do not use if any damage is observed.
3. **Connect Controller:** Locate the connector on the blanket and the corresponding plug on the control unit. Ensure they

are aligned correctly and push firmly until the connection is secure.

4. **Position Blanket:** Place the electric over-blanket on your bed or desired surface. Ensure it lies flat and is not folded, rucked, or creased. Do not cover the control unit with the blanket or other materials.
5. **Plug In:** Insert the power plug into a suitable electrical outlet. Ensure the outlet voltage matches the specifications of the blanket (220-240V).

## OPERATING INSTRUCTIONS

---

### Control Unit Overview:

The control unit features a display, a power button, heat setting buttons, and timer setting buttons.

### Turning On/Off:

- To turn on, press the **Power** button. The display will illuminate, and the blanket will start heating at a default setting.
- To turn off, press the **Power** button again. The display will turn off, and the blanket will cease heating.

### Adjusting Heat Settings:

- With the blanket on, press the **Heat Setting** button (often marked with a temperature or up/down arrows) to cycle through the 9 available heat levels.
- The current heat level will be displayed on the control unit.
- Start with a lower setting and adjust upwards to find your preferred comfort level.

### Setting the Timer:

- With the blanket on, press the **Timer Setting** button (often marked with a clock icon or up/down arrows) to select the desired operating duration.
- You can choose from 1 to 9 hours. The selected time will be displayed.
- The blanket will automatically turn off once the set time has elapsed.

### Overheating Protection:

The blanket is equipped with an advanced overheating protection system. In the event of overheating, the blanket will automatically shut off to prevent damage or injury. If this occurs, unplug the blanket, allow it to cool down, and inspect for any visible damage before attempting to use it again. If the issue persists, contact customer support.

## MAINTENANCE AND CARE

---

### Cleaning Instructions:

1. **Disconnect Power:** Always unplug the blanket from the wall outlet before cleaning.
2. **Detach Control Unit:** Carefully disconnect the control unit from the blanket by pressing the release tab (if present) and pulling the connector apart. Ensure the connector is completely dry before reattaching.
3. **Machine Wash:** The blanket is machine washable. Use a gentle cycle with cold water (maximum 30°C) and a mild detergent. Do not bleach.
4. **Rinse:** Rinse thoroughly to remove all detergent residue.

5. **Tumble Dry:** Tumble dry on a low heat setting or line dry. Ensure the blanket is completely dry before reconnecting the control unit and plugging it back in. Do not iron.

6. **Spot Cleaning:** For minor spills, spot clean with a damp cloth and mild detergent.

**Storage:**

When not in use, store the blanket in a cool, dry place. Avoid folding it tightly or placing heavy objects on top, which could damage the internal heating elements.

**TROUBLESHOOTING**

| Problem                                  | Possible Cause                                                                                                            | Solution                                                                                                                                                                                                                                            |
|------------------------------------------|---------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Blanket does not heat up.                | Not plugged in.<br>Control unit not connected securely.<br>Power outlet not working.<br>Overheating protection activated. | Ensure the power cord is securely plugged into a working outlet.<br><br>Check that the control unit is firmly connected to the blanket.<br><br>Test the outlet with another appliance.<br><br>Unplug, allow to cool for 30 minutes, then try again. |
| Blanket heats unevenly.                  | Blanket is folded or bunched.                                                                                             | Ensure the blanket is spread out flat and not folded or creased during use.                                                                                                                                                                         |
| Control unit display is off or flashing. | Power interruption.<br>Internal fault.                                                                                    | Unplug the blanket for a few minutes, then plug it back in and try again.<br><br>If the issue persists, discontinue use and contact customer support.                                                                                               |

If you experience any problems not listed here, or if the suggested solutions do not resolve the issue, please contact Luxell customer support.

**SPECIFICATIONS**

|                    |                                              |
|--------------------|----------------------------------------------|
| Model Number       | SS01A(160*120)-1X                            |
| Dimensions (L x W) | 160 cm x 120 cm                              |
| Power              | 160W                                         |
| Material           | 100% Double-sided flannel fabric (Polyester) |
| Heat Settings      | 9 levels                                     |
| Timer Settings     | 1-9 hours                                    |
| Safety Features    | Overheating Protection                       |
| Care Instructions  | Machine Washable (with detachable cable)     |

|       |       |
|-------|-------|
| Color | Beige |
|-------|-------|

## WARRANTY AND SUPPORT

Your Luxell Electric Over-Blanket is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details.

For technical assistance, troubleshooting, or warranty claims, please contact Luxell customer support. Contact information can typically be found on the product packaging or the official Luxell website.

When contacting support, please have your model number (SS01A(160\*120)-1X) and purchase date available.