Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PUTORSEN B0GSQ5Q61F

PUTORSEN Triple Monitor Stand User Manual

Model: B0GSQ5Q61F

1. Introduction

Thank you for choosing the PUTORSEN Triple Monitor Stand. This product is designed to enhance your workspace by providing a stable and adjustable mounting solution for up to three monitors. This manual provides essential information for safe installation, operation, and maintenance of your monitor stand.

The PUTORSEN Triple Monitor Stand (Model B0GSQ5Q61F) features gas spring arms for smooth adjustments, supporting monitors from 17 to 49 inches, with a weight capacity of 2 to 20 kg (4.4 to 44 lbs) per arm. It is compatible with VESA 75x75mm and 100x100mm mounting patterns.



Image 1.1: The PUTORSEN Triple Monitor Stand in a typical multi-monitor setup, showcasing its ergonomic design.

2. Safety Information

Please read all instructions carefully before assembly and use. If you do not understand these instructions or have doubts

about the safety of the installation, please contact qualified personnel.

- **Weight Capacity:** Do not exceed the maximum weight capacity of 20 kg (44 lbs) per arm. Exceeding this limit may result in serious injury or product damage.
- **Monitor Size:** Ensure your monitors are within the recommended size range of 17 to 49 inches.
- **Desk Stability:** The desk or mounting surface must be capable of supporting the combined weight of the stand and all mounted equipment.
- **Children:** Keep small parts away from children. This product contains small parts that could be a choking hazard.
- **Proper Installation:** Ensure all screws are securely tightened. Do not overtighten screws to avoid stripping threads.
- **Movement:** Adjust the gas spring tension correctly to ensure monitors remain stable in their desired position. Improper tension can cause monitors to fall or spring up unexpectedly.

3. Package Contents

Please verify that all components are present and undamaged before proceeding with installation. If any parts are missing or damaged, please contact customer support.

(Note: A detailed parts list is typically included in the product packaging. This section provides a general overview.)

- Central Pole Assembly
- Gas Spring Monitor Arms (x3)
- VESA Plates (x3)
- Desk Clamp (C-clamp)
- Grommet Mount Hardware
- Cable Management Clips
- Hardware Kit (screws, washers, Allen keys)

4. Setup and Installation

Before you begin, ensure your desk meets the requirements and your monitors are VESA compatible.

4.1 Pre-Installation Checks

- **Desk Thickness:**
  - C-Clamp: 10-45 mm (0.39"-1.77")
  - Grommet Mount: 10-40 mm (0.39"-1.57")
- **Grommet Hole Diameter (if using):** 10-60 mm (0.39"-2.36")
- **VESA Compatibility:** 75x75 mm or 100x100 mm.



Image 4.1: Compatibility overview for monitor size, weight, VESA, and desk mounting options.

4.2 Desk Mounting Options

Choose either the C-clamp or grommet mount method based on your desk type.

4.2.1 C-Clamp Installation

1. Attach the C-clamp base to the bottom of the central pole.
2. Position the central pole assembly on the edge of your desk.
3. Tighten the C-clamp screw until the stand is securely fastened to the desk. Ensure it is stable and does not wobble.

4.2.2 Grommet Mount Installation

1. If your desk has a grommet hole, insert the central pole through it.
2. From underneath the desk, secure the pole using the grommet plate and tightening knob/nut.
3. Ensure the stand is firmly secured and stable.



Image 4.2: The robust C-clamp design with an anti-slip pad for enhanced stability.

4.3 Attaching Monitor Arms and Monitors

1. Slide the monitor arms onto the central pole at your desired heights. Secure them with the provided clamps/screws.
2. Attach the VESA plates to the back of your monitors using the appropriate screws from the hardware kit. Ensure the screws are not overtightened.

3. Carefully slide the VESA plate with the attached monitor onto the monitor arm's mounting head until it clicks into place. Ensure it is securely locked.
4. Repeat for all three monitors.

4.4 Adjusting Gas Spring Tension

The gas spring tension needs to be adjusted for each monitor's weight to ensure smooth movement and stable positioning.

1. With a monitor attached, use the provided Allen key to adjust the tension screw located on the arm joint.
2. Turn **clockwise (-)** to reduce tension for lighter monitors (if the monitor springs up).
3. Turn **counter-clockwise (+)** to increase tension for heavier monitors (if the monitor sags).
4. Adjust until the monitor stays in position when moved up or down with minimal effort.



Image 4.3: Each arm is designed to support up to 20kg (44 lbs) with reinforced joints for long-term stability.

4.5 Cable Management

Route your monitor cables through the integrated cable management channels on the arms and central pole to maintain a tidy workspace.



Image 4.4: Integrated cable management system keeps cables organized and out of sight.

5. Operating Instructions

The PUTORSEN Triple Monitor Stand offers extensive adjustability to achieve your optimal viewing experience.

- **Height Adjustment:** Loosen the clamp on the central pole to slide the arms up or down, then re-tighten.
- **Tilt:** Adjust the monitor screen vertically from +50° to -20°.
- **Swivel:** Pivot the monitor horizontally up to 180° (90° left/right).
- **Rotation:** Rotate the monitor 360° (portrait to landscape orientation).
- **Arm Extension:** Extend or retract the monitor arms to adjust the viewing distance.



Image 5.1: Visual representation of the tilt, swivel, and rotation capabilities.



Image 5.2: Examples of multiple setup options for different monitor sizes and orientations.

6. Maintenance

- **Cleaning:** Wipe the stand with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Check Connections:** Periodically check all screws and connections to ensure they remain tight and secure. Re-tighten if necessary.
- **Gas Spring:** The gas spring is maintenance-free. If you notice issues with adjustment, re-check the tension setting.

7. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Monitor sags or falls	Gas spring tension is too low for monitor weight.	Increase gas spring tension by turning the adjustment screw counter-clockwise (+).
Monitor springs up	Gas spring tension is too high for monitor weight.	Decrease gas spring tension by turning the adjustment screw clockwise (-).
Stand is wobbly/unstable	Desk clamp/grommet mount is not tight enough.	Ensure the C-clamp or grommet mount is securely tightened to the desk. Check desk stability.
Monitor does not stay in desired position (tilt/swivel)	Tilt/swivel joint screws are loose.	Tighten the screws on the respective tilt or swivel joints using the provided Allen key.

8. Specifications

Feature	Detail
Model	B0GSQ5Q61F
Monitor Size Compatibility	17 - 49 inches
Weight Capacity per Arm	2 - 20 kg (4.4 - 44 lbs)
VESA Compatibility	75x75 mm, 100x100 mm
Mounting Type	Desk Mount (C-Clamp or Grommet)
C-Clamp Desk Thickness	10 - 45 mm (0.39" - 1.77")
Grommet Desk Thickness	10 - 40 mm (0.39" - 1.57")
Grommet Hole Diameter	10 - 60 mm (0.39" - 2.36")
Tilt Range	+50° / -20°
Swivel Range	180°
Rotation Range	360°
Material	High-grade Aluminum and Steel

9. Warranty Information

The PUTORSEN Triple Monitor Stand (Model B0GSQ5Q61F) comes with a**2-year manufacturer warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by improper installation, misuse, accidents, or unauthorized modifications.

Please retain your proof of purchase for warranty claims.

10. Customer Support

If you have any questions, require assistance with installation, or encounter any issues with your PUTORSEN Triple Monitor Stand, please contact the seller or PUTORSEN customer support through the platform where you purchased the product.

For more information and support, you may visit the official PUTORSEN brand store:PUTORSEN Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GSQ5Q61F

More documents and user manuals: **https://manuals.plus/**