

[Manuals.plus](#) /

› [GOBOULT](#) /

› GOBOULT Y1 v2.0 Wireless Earbuds User Manual

GOBOULT Y1 v2.0

GOBOULT Y1 v2.0 Wireless Earbuds User Manual

Model: Y1 v2.0

INTRODUCTION

Thank you for choosing the GOBOULT Y1 v2.0 Wireless Earbuds. This manual provides essential information for setting up, operating, and maintaining your earbuds to ensure optimal performance and longevity. Please read it carefully before use.



Image: GOBOULT Y1 v2.0 Wireless Earbuds and their charging case, showcasing the sleek design.

WHAT'S IN THE BOX

- GOBOULT Y1 v2.0 Wireless Earbuds
- Charging Case
- USB Type-C Charging Cable
- Ear Cushions (various sizes)
- User Manual
- Warranty Card

PRODUCT FEATURES

The GOBOULT Y1 v2.0 earbuds are designed with advanced features for an enhanced audio experience:

- **Extended Playtime:** Up to 60 hours of total playtime with the charging case.
- **Bluetooth 6.0:** Ensures fast, stable, and efficient wireless connectivity.
- **Zen Quad Mic ENC:** Environmental Noise Cancellation with four microphones for clear calls.
- **Low Latency:** 45ms ultra-low latency for gaming and video synchronization.

- **Touch Control:** Intuitive touch sensors for managing music, calls, and voice assistant.
- **Dual Device Pairing:** Connect and switch seamlessly between two devices.
- **13mm Bass Driver:** Delivers powerful bass and clear audio.
- **AMP App Support:** Customize audio settings and controls via the dedicated application.
- **IPX5 Water Resistance:** Protection against sweat and light splashes.
- **Fast Charging:** Type-C port for quick charging of the case.



Image: Overview of GOBOULT Y1 v2.0 features including sleek design, AMP App support, Bluetooth 6.0, 60 hours battery life, and dual device pairing.

SETUP GUIDE

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated.
2. Connect the USB Type-C charging cable to the charging port on the case and to a power source.
3. The LED indicator on the case will show charging status. A full charge typically takes approximately 1.5-2 hours.

PLAYS ON
AND ON.



10 min charge = 120 min playtime

Stays powered up for a week of action

Image: The GOBOULT Y1 v2.0 earbuds and charging case, highlighting the 60-hour battery life and Type-C fast charging capability.

2. Initial Pairing (Single Device)

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for available Bluetooth devices and select "GOBOULT Y1 v2.0".
4. Once connected, you will hear a confirmation tone.

3. Dual Device Pairing

The Y1 v2.0 supports connecting to two devices simultaneously.

1. Pair the earbuds with your first device as described in "Initial Pairing".
2. Disable Bluetooth on the first device. The earbuds will re-enter pairing mode.
3. Pair the earbuds with your second device.
4. Re-enable Bluetooth on the first device. The earbuds should automatically connect to both devices.
5. To switch between devices, simply play audio on the desired device.

DOUBLE THE Indulgence



Image: The GOBOULT Y1 v2.0 earbuds connected to both a laptop and a smartphone, illustrating the dual device pairing feature.

OPERATING INSTRUCTIONS

1. Touch Controls

The earbuds feature intuitive touch controls on their stems:

Action	Function
Single Tap (Left/Right)	Play/Pause Music, Answer/End Call
Double Tap (Right)	Next Track
Double Tap (Left)	Previous Track
Triple Tap (Left/Right)	Activate Voice Assistant
Long Press (Left/Right)	Reject Call

Action	Function
Long Press (Right)	Volume Up
Long Press (Left)	Volume Down



Image: Visual representation of touch controls for music playback and call management, along with the IPX5 water resistance rating.

2. Voice Assistant

Activate your device's voice assistant (Siri, Google Assistant) by triple-tapping either earbud. You can then issue commands like making calls or playing music.



Image: The GOBOULT Y1 v2.0 earbuds highlighting Bluetooth 6.0 for stable connection and integration with AI voice assistants like Siri and Google Assistant.

3. Gaming Mode (Low Latency)

For an optimized gaming experience, activate the 45ms ultra-low latency gaming mode. Refer to the AMP App or specific touch control gestures (if available) for activation.

Gaming Mode



Image: The GOBOULT Y1 v2.0 earbuds illustrating the 45ms ultra-low latency Gaming Mode.


4. AMP App Support

Download the GOBOULT AMP App to unlock advanced customization options:

- Adjust Equalizer (EQ) settings for personalized sound.
- Customize touch controls.
- Access additional features like Water Ejection mode.

GOBOULT AMP APP

Customize your listening
according to your taste



From
Treble to
Bass
to Equalizer

Custom EQ modes

Water Ejection

Rename your buds

Multiple Music Modes

Image: Screenshot of the GOBOULT AMP App interface, demonstrating equalizer adjustments and other customization features.

MAINTENANCE

1. Cleaning

Regular cleaning helps maintain sound quality and hygiene.

- Use a soft, dry, lint-free cloth to wipe the earbuds and charging case.
- Gently remove any earwax or debris from the ear tips and speaker mesh using a small brush or cotton swab.
- Do not use abrasive cleaners, alcohol, or chemical solvents.

2. Water Resistance (IPX5)

The GOBOULT Y1 v2.0 earbuds are rated IPX5 water resistant, meaning they are protected against low-pressure water jets from any direction. This makes them suitable for workouts and light rain.

- Do not submerge the earbuds in water.
- The charging case is not water resistant.
- Ensure earbuds are dry before placing them back in the charging case to prevent damage.

TROUBLESHOOTING

Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on Bluetooth on your device. Forget the device in Bluetooth settings and re-pair.
Only one earbud working	Place both earbuds back in the case, close it, then open again. Ensure both are charged. Reset earbuds if issue persists.
Low volume or poor sound quality	Clean earbud speaker mesh. Adjust volume on both earbuds and connected device. Try different ear tip sizes for a better seal.
Charging case not charging	Check USB Type-C cable and power adapter. Ensure connections are secure.

SPECIFICATIONS

Feature	Detail
Brand	GOBOULT
Model Name	Y1 v2.0 (Airbass)
Ear Placement	In Ear
Noise Control	Environmental Noise Cancellation (ENC)
Bluetooth Version	6.0
Bluetooth Range	10 Metres
Battery Life (Total)	Up to 60 Hours
Audio Driver Size	13 Millimetres
Audio Latency	45 Milliseconds (Gaming Mode)
Frequency Response	20 Hz - 20,000 Hz
Water Resistance Level	IPX5
Control Method	Touch Control, App
Compatible Devices	Android, iOS, Desktops, Laptops, Tablets
Item Weight	50 Grams

Witness the
UPGRADE

Description	Y1 v2.0 Specs
BASS DRIVERS	13 MM
MICS	4
PLAYTIME	60H
BLUETOOTH	6
LATENCY	45MS
THICKNESS	1.4CM

Description	Y1 Specs
BASS DRIVERS	10 mm
MICS	2
PLAYTIME	50H
BLUETOOTH	5.3
LATENCY	Normal
THICKNESS	2cm

Image: A detailed comparison table showing the specifications of GOBOULT Y1 v2.0 versus the previous Y1 model, highlighting improvements.

WARRANTY AND SUPPORT

The GOBOULT Y1 v2.0 Wireless Earbuds come with a **1-Year Manufacturer's Warranty** from the date of purchase. This warranty covers manufacturing defects.

For warranty claims, technical support, or any product-related inquiries, please refer to the contact information provided on your warranty card or visit the official GOBOULT support website.