

TEMOLA TN10S

TEMOLA TN10S Car Jump Starter and Tire Inflator User Manual

Model: TN10S

1. IMPORTANT SAFETY INFORMATION

Read all safety warnings and instructions before using this product. Failure to follow the warnings and instructions may result in electric shock, fire, and/or serious injury.

- **Do not** operate the jump starter if it is damaged or modified.
- **Do not** jump start a frozen battery.
- **Do not** allow the positive and negative clamps to touch each other.
- **Do not** expose the device to rain or wet conditions.
- Keep out of reach of children.
- Ensure proper ventilation during use.
- Wear eye protection when operating the device.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- TEMOLA TN10S Jump Starter with Air Compressor
- Inflator Hose
- Smart Jumper Cables
- USB Charging Cable
- Inflator Nozzles (various types)
- Instruction Manual (this document)

3. PRODUCT OVERVIEW

The TEMOLA TN10S is a portable multi-function device combining a 12V car jump starter and a 150PSI tire inflator. It features an LCD display, LED light, and smart jumper cables for safe operation.



An image showing the TEMOLA TN10S portable car jump starter and tire inflator, highlighting its compact design and integrated features.

Key Components:

- **Power Button:** Turns the device on/off and cycles through modes.
- **LCD Display:** Shows battery level, inflation pressure, and operational status.
- **USB Output Port:** For charging external devices.
- **USB-C Input Port:** For charging the jump starter.

- **Jump Start Port:** Connects to smart jumper cables.
- **Air Hose Port:** Connects to the inflator hose.
- **LED Light:** Provides illumination with multiple modes.

4. CHARGING THE DEVICE

Before initial use, fully charge the TEMOLA TN10S. It is recommended to recharge the device every 3-6 months to maintain battery health.

1. Connect the provided USB charging cable to the USB-C input port on the jump starter.
2. Connect the other end of the USB cable to a 5V/2A or higher USB wall adapter (not included).
3. The LCD display will show the charging status. The device is fully charged when the battery indicator shows 100%.

5. OPERATING THE JUMP STARTER

Use this function to start 12V cars, trucks, and SUVs with a dead battery.

1. Ensure the jump starter is at least 50% charged.
2. Connect the smart jumper cables to the jump start port on the device. The LCD display will show 'READY'.
3. Attach the **red (+) clamp** to the positive terminal of the vehicle's battery.
4. Attach the **black (-) clamp** to the negative terminal of the vehicle's battery.
5. Ensure the clamps have a good connection. The smart cable indicator should show a solid green light, indicating it's safe to proceed. If it shows red or flashes, refer to the troubleshooting section.
6. Start the vehicle's engine.
7. Once the engine starts, immediately remove the smart jumper cables from the vehicle battery (black first, then red), and then disconnect from the jump starter.

Note: Do not crank the engine for more than 3 seconds. Wait at least 30 seconds between attempts if the engine does not start on the first try.

6. OPERATING THE TIRE INFLATOR

The built-in 150PSI air compressor can inflate car tires, motorcycle tires, bicycle tires, sports balls, and inflatable toys.

1. Connect the inflator hose to the air hose port on the device.
2. Press the power button to turn on the device. The LCD display will show the current pressure.
3. Press the 'UNIT' button to select the desired pressure unit (PSI, BAR, KPA, KG/CM²).
4. Use the '+' and '-' buttons to set the target pressure.
5. Screw the inflator hose onto the tire valve stem or attach the appropriate nozzle for other inflatables.
6. Press the 'START/STOP' button to begin inflation. The compressor will automatically stop when the preset pressure is reached.

7. Disconnect the inflator hose from the tire valve or inflatable.

Caution: The inflator hose may become hot during prolonged use. Handle with care.

7. USING THE LED LIGHT

The device includes an LED light with three modes for emergency situations.

- **To turn on:** Press and hold the LED light button (usually a dedicated button or a long press on the power button, refer to device markings).
- **To cycle modes:** Press the LED light button briefly to switch between Constant, Flashing, and SOS modes.
- **To turn off:** Press and hold the LED light button again.

8. MAINTENANCE

- Clean the device with a dry, soft cloth. Do not use harsh chemicals or abrasives.
- Store the jump starter in a cool, dry place away from direct sunlight and extreme temperatures (-4°F to 140°F).
- Recharge the device every 3-6 months to prevent deep discharge and prolong battery life.
- Inspect cables and connections for damage before each use.

9. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device fully.
Vehicle does not start.	Poor clamp connection; vehicle battery too low; jump starter battery too low.	Ensure clamps are securely connected. Recharge jump starter. Consult a mechanic if vehicle issues persist.
Smart cable shows red light/flashes.	Reverse polarity; short circuit; over-voltage/under-voltage.	Check clamp connections for correct polarity. Disconnect and reconnect. If error persists, do not use.
Tire inflator not working.	Hose not connected properly; target pressure not set; device battery low.	Ensure hose is securely attached. Set target pressure. Charge the device.

10. SPECIFICATIONS

- **Model Number:** TN10S
- **Voltage:** 12 Volts
- **Amperage:** 250 Amps (Peak)

- **Tire Inflator Pressure:** Up to 150 PSI
- **Product Dimensions:** 3.03"D x 6.97"W x 2.24"H
- **Operating Temperature:** -4°F to 140°F (-20°C to 60°C)
- **Compatible Vehicle Type:** 12V Gas and Diesel Engines, ATV
- **UPC:** 797541314535

11. WARRANTY AND SUPPORT

The TEMOLA TN10S comes with a **1 Year Manufacturer Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

For warranty claims or technical support, please contact TEMOLA customer service through the retailer where the product was purchased or visit the official TEMOLA website.

12. OFFICIAL PRODUCT VIDEOS

No official product videos from the seller were found in the provided data. If available, relevant videos demonstrating product features or usage would be embedded here with a maximum width of 420px and a detailed text description.