

Veise VE001

Veise VE001 Keyless Entry Door Lock Instruction Manual

1. INTRODUCTION AND OVERVIEW

This manual provides detailed instructions for the installation, operation, maintenance, and troubleshooting of your Veise VE001 Keyless Entry Door Lock. The VE001 offers enhanced security and convenience with features such as multiple user codes, automatic locking, and a durable, weather-resistant design.

- **Keyless Entry:** Program up to 20 unique user codes.
- **Smart Locking:** Features auto-lock (10-99 seconds) and one-touch locking.
- **Temporary Passcodes:** Create single-use codes for guests or service providers.
- **Durable Design:** ANSI Grade 3 security and IP55 weather resistance.
- **User-Friendly:** Backlit keypad and anti-peeping password function.

2. SETUP AND INSTALLATION

The Veise VE001 Keyless Entry Door Lock is designed for easy DIY installation with minimal tools. A screwdriver is typically the only tool required. Ensure your door meets the specified dimensions for proper fit.

2.1 Door Compatibility

- **Door Hole Diameter:** Suitable for 1-1/2" or 2-1/8" (38mm or 54mm) holes.
- **Door Thickness:** Fits doors from 1-3/8" to 2" (35mm to 50mm).
- **Backset:** Adjustable for 2-3/8" or 2-3/4" (60mm or 70mm).
- **Door Handing:** Automatically detects left or right-handed doors after reset.

Note: This lock is not compatible with mortise, integrated, or rim cylinder doors. It is designed for standard single-cylinder deadbolt applications.

Confirm Size Before Purchasing



Image: Diagram illustrating door hole diameter, thickness, and backset measurements for installation.

2.2 Installation Steps

1. Prepare the door and frame according to the provided template.
2. Install the latch into the door edge.
3. Install the exterior keypad assembly.
4. Install the interior mounting plate.
5. Connect the cable and install the interior assembly.
6. Install batteries and perform the door handing process.

For a visual guide, please refer to the official installation video:

Video: *Official Veise VE001 Installation Guide*. This video demonstrates the step-by-step process for installing the keyless entry door lock.

3. OPERATING INSTRUCTIONS

The Veise VE001 offers various access methods and security features for convenient and secure operation.

3.1 Programming User Codes

You can program up to 20 unique user codes for family members or regular access. Each code should be 4-10 digits long.



Image: The Veise VE001 lock with an overlay graphic illustrating the ability to store up to 20 unique access codes for various users.

3.2 Auto-Lock and One-Touch Locking

- **Auto-Lock:** The lock can be set to automatically lock after a delay of 10-99 seconds. This feature is disabled by default and can be configured.
- **One-Touch Lock:** To instantly lock the door from the outside, press and hold any key on the keypad for 2 seconds.

Auto Lock & One-Touch Lock

Easily Manage Access for Family & Guests



Image: The Veise VE001 lock demonstrating its auto-lock feature with a timer and the one-touch lock function.

3.3 Temporary Passcodes

Generate one-time use codes for temporary access. These codes are automatically deleted after a single use, providing secure, short-term entry for visitors or service personnel.



Image: A scenario depicting the use of a one-time code for temporary access, suitable for various service providers.

3.4 Anti-Peeping Password and Backlit Keypad

- **Anti-Peeping Password:** To prevent others from guessing your code, you can enter random digits before or after your actual passcode. The lock will still open as long as the correct sequence is embedded within the entered digits.
- **Backlit Keypad:** The keypad illuminates for clear visibility and easy operation in low-light conditions or at night.



Image: The backlit keypad and anti-peeping password feature in use, showing how random digits can be added for privacy.

3.5 Other Modes

- **Mute Mode:** Silence keypad tones for quiet operation.
- **Vacation Mode:** A security feature that disables all user codes except the master code, ideal for extended absences.

For detailed programming steps, refer to the official programming guide:

Video: Official Veise VE001 Programming Guide. This video provides instructions on how to program various features and user codes for the lock.

4. MAINTENANCE

4.1 Battery Installation and Life

The lock requires 4 AA batteries (not included). Under normal use, batteries can last up to 13 months.

4.2 Low Battery Indicator

A low-battery indicator will alert you when the battery level drops below 20%, providing ample time for replacement.

4.3 Emergency Access

Two backup keys are included for emergency manual access in case of battery depletion or electronic malfunction.

13-Month Battery Life & Backup Access

Upgraded Smart Lock for Modern Living

Powered by 4 AA batteries (not included)

Low Battery Alert
Red Light Flashes Below 20%

2 Backup Keys For
Emergency Access

*Door Handle are Not Included.

Image: Visual representation of the lock's battery compartment, low battery alert on the keypad, and the included backup keys.

5. TROUBLESHOOTING

5.1 Wrong Entry Limit

After 10 consecutive incorrect code entries, the lock will temporarily disable the keypad for 3 minutes to prevent unauthorized access.

5.2 Resetting the Lock

If you encounter issues or need to clear all programmed settings, you can perform a factory reset:


1. Remove one battery from the interior assembly.
2. Press and hold the Reset Button (located inside the battery compartment) for 5 seconds using the Reset Tool.
3. While still holding the Reset Button, reinsert the battery.
4. Continue holding the Reset Button until you hear a long beep and the latch bolt extends automatically. This indicates a successful reset.

Video: Official Veise VE001 Reset Video. This video demonstrates the procedure for resetting the lock to its factory default settings.

6. SPECIFICATIONS

Feature	Detail
Brand	Veise
Model Number	VE001
Lock Type	Combination Lock, Deadbolt, Keypad
Dimensions (L x W x H)	5.12 x 2.95 x 1.3 inches
Material	Aluminum, Metal
Security Standard	ANSI/BHMA Grade 3 Certified
Weather Resistance	IP55 Waterproof
Power Source	4 AA Batteries (not included)
Battery Life	Up to 13 months (normal use)
User Codes Capacity	Up to 20 individual codes
Special Features	Anti-peeping Password, Vacation Mode, Mute Mode, Wrong Entry Limit, Auto-Lock, Back-Lit Keypad, Battery Indicator, One-Touch Lock

Built for Strength & Security



IP55
Waterproof

BHMA/ANSI
Certified

Mute Mote Wrong Entry Limit Vacation Mode

*Door Handle are Not Included.

Image: The Veise VE001 lock highlighting its IP55 waterproof rating and ANSI/BHMA Grade 3 security certification.

7. WARRANTY AND SUPPORT

Veise is committed to providing reliable products and excellent customer service.

- **Warranty:** The Veise VE001 Keyless Entry Door Lock comes with a 2-year full product warranty.
- **Lifetime Component Support:** Enjoy lifetime support for product components.
- **US-Based Phone Support:** Available Monday-Friday, 9 AM-5 PM PST, and Saturday, 7 AM-3 PM PST.
- **24/7 Email Assistance:** For any inquiries or support needs, email assistance is available around the clock.

Please refer to the product packaging or official Veise website for specific contact details.

