

## iBUYPOWER KM10

# iBUYPOWER Chimera KM10 RGB Gaming Keyboard and Mouse Combo User Manual

Model: KM10

## INTRODUCTION

---

This manual provides essential information for the setup, operation, maintenance, and troubleshooting of your iBUYPOWER Chimera KM10 RGB Gaming Keyboard and Mouse Combo. Please read these instructions carefully before using the product to ensure proper functionality and longevity.

## SETUP

---

### Package Contents

- iBUYPOWER Chimera KM10 RGB Gaming Keyboard
- iBUYPOWER Chimera KM10 RGB Gaming Mouse
- User Manual (this document)

### Connecting the Devices

1. Locate an available USB port on your computer.
2. Plug the USB connector of the iBUYPOWER Chimera KM10 Keyboard into the USB port.
3. Plug the USB connector of the iBUYPOWER Chimera KM10 Mouse into another available USB port.
4. Your operating system should automatically detect and install the necessary drivers. No additional software installation is typically required for basic functionality.



Image: Top-down view of the iBUYPOWER Chimera KM10 RGB Gaming Keyboard, showing the full 104-key layout and the integrated USB cable. This image illustrates the keyboard ready for connection.

## OPERATING THE DEVICES

### Keyboard Functions

The iBUYPOWER Chimera KM10 keyboard features a standard 104-key membrane layout designed for gaming and general use.

- **Standard Keys:** All standard alphanumeric, symbol, and function keys (F1-F12) are present.
- **Volume Roller:** A dedicated volume roller is located on the top right of the keyboard for convenient audio control. Rotate the roller to adjust volume up or down.
- **Media Control Keys:** Dedicated media keys (Play/Pause, Previous Track, Next Track) are located near the volume roller for easy access to media playback.
- **RGB Backlighting:** The keyboard features RGB backlighting. Specific key combinations or software (if available, refer to manufacturer's website) may be used to cycle through lighting modes or adjust brightness.



Image: A close-up view of the upper right section of the iBUYPOWER Chimera KM10 keyboard, highlighting the volume roller and media control buttons. This illustrates the dedicated controls for audio and media playback.

### Mouse Functions

The iBUYPOWER Chimera KM10 mouse is designed to complement the keyboard, offering responsive control for gaming.

- **Standard Buttons:** Left-click, right-click, and scroll wheel with click function.
- **DPI Adjustment:** The mouse typically includes a button to cycle through different DPI (dots per inch) settings, allowing for on-the-fly sensitivity adjustments.
- **RGB Lighting:** The mouse features 3D RGB lighting, which illuminates the mouse body. Lighting effects are usually pre-programmed and may cycle automatically or be adjustable via software (if available).

## MAINTENANCE

---

### Cleaning Instructions

- **Keyboard:** Disconnect the keyboard from your computer. Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe down the keycaps and surface. Avoid spraying liquids directly onto the keyboard. For debris between keys, use compressed air.
- **Mouse:** Disconnect the mouse from your computer. Use a soft, dry cloth to clean the surface. For optical sensor cleaning, use a cotton swab lightly dampened with isopropyl alcohol, ensuring no liquid enters the sensor opening.

### General Care

- Avoid exposing the devices to extreme temperatures, humidity, or direct sunlight.
- Do not drop or subject the devices to strong impacts.
- Keep liquids away from the keyboard and mouse to prevent damage.

## TROUBLESHOOTING

---

### Keyboard or Mouse Not Responding

- Ensure the USB cables are securely plugged into your computer's USB ports.
- Try plugging the devices into different USB ports on your computer.
- Restart your computer.
- Test the devices on another computer to determine if the issue is with the devices or your computer's setup.

### RGB Lighting Not Working

- Ensure the devices are properly connected and powered.
- Check if there are any specific key combinations on the keyboard to toggle or adjust RGB lighting (e.g., Fn + a specific key).
- Verify if any software is required for advanced RGB control and if it is installed and running correctly.

### Keys Not Registering or Mouse Cursor Jumps

- Clean the keyboard keys or mouse sensor as described in the Maintenance section.
- Ensure there are no obstructions under the keys or blocking the mouse sensor.
- For the mouse, try using it on a different surface.

## SPECIFICATIONS

---

Feature	Detail
---------	--------

Feature	Detail
Brand	iBUYPOWER
Model Number	KM10
Connectivity Technology	USB
Keyboard Type	104-Key Membrane
Special Features	Volume Roller, RGB Backlighting
Compatible Devices	Personal Computer
Batteries Required	No
UPC	848604053585

## WARRANTY INFORMATION

---

The iBUYPOWER Chimera KM10 RGB Gaming Keyboard and Mouse Combo is covered by a **1-Year Manufacturer Warranty**. This warranty covers defects in materials and workmanship under normal use. For warranty claims or detailed terms and conditions, please refer to the official iBUYPOWER website or contact their customer support.

## SUPPORT

---

If you encounter any issues not covered in the troubleshooting section or require further assistance, please visit the official iBUYPOWER support website or contact their customer service department. Have your product model number (KM10) and any relevant purchase information ready when seeking support.