

Aoxun G30067

Aoxun 12x10 Gazebo with Netting and Curtains User Manual

Model: G30067

INTRODUCTION

Thank you for choosing the Aoxun 12x10 Gazebo. This manual provides essential information for the safe assembly, operation, and maintenance of your gazebo. Please read these instructions carefully before beginning assembly and retain them for future reference.

SAFETY INFORMATION

- Ensure all parts are present and undamaged before assembly. Do not proceed with assembly if any parts are missing or damaged.
- Assembly requires at least two adults.
- Do not use the gazebo in extreme weather conditions such as heavy winds, snow, or thunderstorms. Disassemble or secure the gazebo appropriately during such conditions.
- Keep children and pets away from the assembly area.
- Always anchor the gazebo securely to the ground using the provided stakes, expansion bolts, and wind ropes.
- Do not hang heavy objects from the gazebo frame.

PACKAGE CONTENTS


Verify that all components listed in the manual are present before starting assembly. The package includes:

- Frame components (legs, beams, roof structure)
- Main canopy and top canopy
- Mosquito netting and privacy curtains
- Hardware kit: 4 spiral ground stakes, 8 short stakes, 8 expansion bolts, 4 wind ropes, 2 S-hooks, and other fasteners.

Product Dimension

aoxun

12X10 FT



Long Tent
Stakes x4

Short Tent
Stakes x8

Expansion
Bolts x8

Guy
Ropes x4

S-
hooks x2

Figure 1: Product dimensions and a visual representation of included accessories such as stakes, expansion bolts, guy ropes, and S-hooks.

SETUP INSTRUCTIONS

Follow these steps for proper assembly of your Aoxun 12x10 Gazebo. Refer to the detailed assembly diagrams in the included printed manual for visual guidance.

- 1. Site Selection:** Choose a flat, level area for installation. Ensure adequate clearance around the gazebo.
- 2. Frame Assembly:** Begin by assembling the base frame, connecting the leg posts and horizontal beams. Ensure all connections are secure. The robust structure features 50x50mm powder-coated steel legs for durability.
- 3. Roof Structure:** Attach the roof support beams and the double-roof frame.
- 4. Canopy Installation:** Drape the main canopy over the roof structure, ensuring it is centered and taut. Install the smaller top canopy onto the upper roof frame. The canopy is made from 160g PU-coated polyester fabric.
- 5. Netting and Curtains:** Attach the full-perimeter mosquito netting and privacy curtains to the designated tracks or hooks on the frame. Ensure the Velcro-sealed edges of the netting are properly aligned to keep insects out.

6. **Anchoring:** Secure the gazebo to the ground using the 8 expansion bolts for hard surfaces or the 4 spiral ground stakes and 8 short stakes for soft ground. Utilize the 4 wind ropes and reinforced D-rings on all four corners for multi-point anchoring to enhance stability. The gazebo is rated to withstand Level 7 winds.



45%
Reinforced And
Thickened Design

Supported By
Multi-ribs
More Stable Structure

Figure 2: Detail of the reinforced and thickened leg design with expansion bolts for secure ground attachment, and the multi-rib support structure for enhanced stability.

Your browser does not support the video tag.

Video 1: An official product video demonstrating the assembly and features of the Aoxun Outdoor Gazebo with Double Roof.

OPERATING YOUR GAZEBO

Versatile Usage Options

The Aoxun Gazebo offers flexible configurations to suit your needs:

- **Fully Open:** Curtains and netting tied back for maximum airflow and an unobstructed view.

- **Semi-Open:** Mosquito netting deployed to protect against insects while maintaining ventilation.
- **Fully Closed:** Privacy curtains drawn for seclusion, wind protection, and enhanced UV blockage.

3 WAYS TO USE

Fully Open

Breathing & ventilation



Semi Open

Mosquito & insect control



Fully Close

Privacy & UV protection

Figure 3: Visual guide illustrating the three primary ways to configure your gazebo: Fully Open for breathing and ventilation, Semi Open for mosquito and insect control, and Fully Closed for privacy and UV protection.

Insect Protection

The gazebo features full-perimeter mosquito netting with Velcro-sealed edges to effectively keep insects out. Additionally, the top ventilation duct is equipped with a mosquito-proof net, ensuring good airflow without allowing pests to enter.

High-efficiency Insect-proof Netting



Figure 4: The high-efficiency insect-proof netting deployed, demonstrating how it creates a protected space while allowing ventilation.

Weather Protection

The dual-layer roof design enhances airflow and provides shade. It is equipped with 8 dedicated leakage holes to prevent water accumulation, reduce fabric stress, and extend the canopy's lifespan. The 160g PU-coated polyester fabric offers UPF 50+ sun protection and reliable water resistance, making it suitable for various outdoor conditions.



Figure 5: The water leakage holes on the gazebo roof, designed to prevent water accumulation and ensure proper drainage.

Anti-UV



Durable



Quick-Drying



PU Coating



High-precision Weaving



Waterproof



Tear-Resistant



Figure 6: The high-precision weaving of the PU-coated fabric, demonstrating its durable, quick-drying, waterproof, tear-resistant, and Anti-UV properties (UVA and UVB protection).

Additional Features

The gazebo includes top hooks for hanging lights or a fan, and 4 corner rings for decorative purposes, allowing you to customize your outdoor living space.




Figure 7: J-shaped hooks on the gazebo ceiling for hanging lights, fans, or plants, and corner rings for hanging decorations.

MAINTENANCE

Regular maintenance will extend the life and appearance of your gazebo.

- **Cleaning Fabric:** Clean the canopy, netting, and curtains with mild soap and water. Rinse thoroughly and allow to air dry completely before storage. Do not use harsh chemicals or abrasive cleaners.
- **Cleaning Frame:** Wipe the metal frame with a damp cloth. For stubborn dirt, use a mild detergent. Ensure the frame is dry to prevent rust.
- **Inspections:** Periodically check all bolts, screws, and connections to ensure they are tight and secure. Re-tighten as necessary.
- **Seasonal Storage:** During off-seasons or prolonged periods of non-use, it is recommended to disassemble the gazebo and store it in a dry, protected area to prevent damage from extreme weather or prolonged exposure.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Water pooling on roof	Canopy not taut; drainage holes blocked.	Ensure canopy is stretched tightly over the frame. Clear any debris from the 8 drainage holes.
Gazebo feels unstable	Improper anchoring; loose connections.	Verify all stakes, expansion bolts, and wind ropes are correctly installed and secured. Check and tighten all frame connections.
Insects entering gazebo	Netting not fully closed or damaged.	Ensure all zippers and Velcro seals on the mosquito netting are fully closed. Inspect netting for tears and repair if necessary.
Curtains/Netting not sliding smoothly	Debris in tracks; damaged hooks.	Clean tracks of any dirt or obstructions. Inspect hooks for damage and replace if needed.

SPECIFICATIONS

- **Brand:** Aoxun
- **Model Number:** G30067
- **Product Dimensions:** 144"L x 120"W x 111.6"H (12 ft x 10 ft x 9.3 ft)
- **Item Weight:** 102 Pounds
- **Frame Material:** Powder-coated Aluminum / Steel (50x50mm legs)
- **Canopy Material:** 160g PU-coated Polyester Fabric
- **Water Resistance Level:** Waterproof
- **Ultraviolet Light Protection:** Yes (UPF 50+)
- **Wind Resistance:** Rated to withstand Level 7 winds
- **Load Capacity:** Supports up to 250 lbs (on roof)
- **Assembly Required:** Yes




Figure 8: Visual representation of the gazebo's ability to withstand winds up to 38 mph and its top load-bearing capacity, supporting up to 4 inches of snow.

WARRANTY INFORMATION

Warranty details for your Aoxun Gazebo are typically provided with your purchase documentation or can be found on the official Aoxun website. Please refer to these resources for specific terms and conditions regarding your product's warranty.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Aoxun customer service. Refer to your purchase receipt or the Aoxun website for contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question