Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Aoxun 10' x 12' Outdoor Wood Gazebo

Aoxun 10' x 12' Outdoor Wood Gazebo Instruction Manual

Model: 10' x 12' Outdoor Wood Gazebo

Brand: Aoxun

1. Introduction

Thank you for choosing the Aoxun 10' x 12' Outdoor Wood Gazebo. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new gazebo. Please read these instructions carefully before beginning assembly and retain them for future reference.

Safety Information

- Always follow all assembly steps in the correct order.
- Ensure all parts are present before starting assembly.
- Assembly requires at least 2-3 adults. Do not attempt to assemble alone.
- Wear appropriate safety gear, such as gloves, during assembly.
- Check local building codes and regulations regarding gazebo installation before permanent placement.
- Securely anchor the gazebo to the ground to prevent wind damage.

2. Parts List

A complete and detailed list of all components, including hardware, is provided in the separate Instructions for Use (IFU) PDF document. Please refer to this document to verify all parts are included and undamaged before starting assembly.

You can access the official PDF instructions here.



Figure 2.1: Product Size Diagram (Approximate Dimensions: 142.9"L x 116.5"W x 106.1"H)

3. Setup and Assembly

The Aoxun 10' x 12' Outdoor Wood Gazebo is designed for straightforward assembly. It is recommended that 2-3 people work together to ensure a smooth and safe setup. All necessary hardware is included. For detailed, step-by-step instructions, please consult the comprehensive Instructions for Use (IFU) PDF document.

Important Assembly Notes:

- **Anchoring:** While concrete anchors are provided, some users have found it beneficial to acquire higher-quality anchors for enhanced stability, especially in windy conditions.
- **Instruction Clarity:** Refer to the official PDF manual for the most accurate and complete assembly steps. If any steps appear unclear or missing, cross-reference with the digital manual or contact customer support.
- **Part Verification:** Double-check all parts against the list in the manual. If any pieces are missing or incorrectly cut, contact Aoxun customer support for replacements.




Figure 3.1: Triangular Structure for Enhanced Stability



Figure 3.2: Wind Resistance Installation Options

Video 3.1: Official Aoxun video demonstrating the Outdoor Wood Gazebo with Galvanized Steel Hardtop Gable Roof, highlighting its features and structure.

Video 3.2: Official Aoxun video providing a brief overview of the Aoxun Outdoor Wood Gazebo.

4. Operating and Usage Guidelines

Your Aoxun gazebo provides a spacious and versatile outdoor area for various activities. It is designed to offer comfort and protection in your patio, garden, or backyard.

Key Features for Use:

- **Spacious Design:** The 10' x 12' area offers ample space for entertaining, dining, or creating a relaxing lounge area.
- **Multi-Purpose Hooks:** Integrated ceiling hooks are available for hanging fans, decorative lights, or other accessories.
- **Weather Protection:** The galvanized steel hardtop roof provides anti-UV protection and is waterproof, ensuring comfort during various weather conditions. The gable roof design facilitates quick rainwater drainage, preventing accumulation.
- **Wind Resistance:** Constructed with a prime cedar wood frame and reinforced foundation, the gazebo offers superior durability and wind resistance (rated Level 9).



Figure 4.1: Ultra-Spacious Leisure Area



Figure 4.2: Ceiling Hooks for Accessories



Figure 4.3: Slope Drainage System in Action

5. Maintenance

The Aoxun gazebo is designed for low maintenance, utilizing sustainable cedar wood and a galvanized steel roof. Regular care will ensure its longevity and aesthetic appeal.

Care Instructions:

- **Cleaning:** Periodically clean the roof and wooden frame with mild soap and water. Avoid harsh chemicals or abrasive cleaners that could damage the materials.
- **Fastener Checks:** Regularly inspect all bolts, screws, and connections to ensure they remain tight and secure. Tighten any loose fasteners as needed.
- **Drainage System:** Ensure the slope drainage system remains clear of debris (leaves, twigs) to allow for efficient rainwater runoff.
- **Winter Care:** The roof is designed to hold up to 15 inches of thick snow. However, it is advisable to remove excessive snow accumulation to prevent undue stress on the structure.



Figure 5.1: Gazebo Performance in Summer and Winter

6. Troubleshooting

This section addresses common issues you might encounter during assembly or use.

Common Issues and Solutions:

Problem	Possible Cause	Solution
Missing or damaged parts	Shipping damage or packaging error.	Verify against the parts list in the PDF manual. Contact Aoxun customer support for replacements.
Difficulty with assembly steps	Instructions unclear or complex.	Ensure 2-3 people are assisting. Refer to the official PDF manual for detailed diagrams. Contact support if persistent issues arise.
Gazebo feels unstable after assembly	Anchoring not secure or fasteners loose.	Ensure all fasteners are tightened. Verify the gazebo is properly anchored to the ground using appropriate methods (e.g., higher-quality concrete anchors if needed).
Water accumulation on roof	Drainage system blocked.	Clear any debris from the roof and drainage channels to ensure proper water runoff.

7. Specifications

Feature	Detail
Brand	Aoxun
Model	10' x 12' Outdoor Wood Gazebo
Material	Prime Cedar Wood Frame, Galvanized Steel Hardtop Roof
Style	Modern Gable Roof Design

Feature	Detail
Product Dimensions (L x W x H)	142.9" x 116.5" x 106.1"
Item Weight	130 Pounds
Water Resistance Level	Waterproof
Shape	Rectangular
Ultraviolet Light Protection	Yes (99% UV resistant)
Assembly Required	Yes (2-3 people recommended)
Floor Area	115.74 Square Feet
Wind Resistance Rating	Level 9
Snow Load Capacity	Up to 15 inches thick

8. Warranty and Support

Return Policy:

This product is eligible for a 30-day easy return policy. Please refer to your purchase platform's return guidelines for detailed information.

Customer Support:

For any questions, missing parts, or assistance with assembly, please contact Aoxun Direct customer support. You can typically find contact information on your purchase receipt or the seller's page where you bought the product.

Seller: Aoxun Direct

Protection Plans:

Optional protection plans may be available for purchase, such as a 3-Year Protection Plan or a Complete Protect monthly plan. These plans are typically offered by third-party providers and provide extended coverage beyond the standard return policy. Please review the terms and conditions of any protection plan before purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GSZ6D4NQ

More documents and user manuals: **https://manuals.plus/**