

[Manuals.plus](#) /

› [KLARSTEIN](#) /

› Klarstein Biggie Mechanical Preserving Cooker and Mulled Wine Dispenser, 25L

KLARSTEIN ZJ-28TD

Klarstein Biggie Mechanical Preserving Cooker and Mulled Wine Dispenser

Model: ZJ-28TD

INTRODUCTION

Thank you for choosing the Klarstein Biggie Mechanical Preserving Cooker and Mulled Wine Dispenser. This versatile 25-liter appliance is designed for efficient food preservation and beverage heating. With its 1800W power, adjustable temperature control, and integrated tap, it offers convenience and reliability for both home and commercial use. Please read this manual carefully before operation to ensure safe and optimal performance.

Key Features:

- 25-liter capacity
- 1800W heating power
- Adjustable temperature from 30°C to 110°C
- Integrated stainless steel tap
- Timer function (1-120 minutes)
- Keep-warm function
- Automatic shut-off and overheat protection
- Durable brushed stainless steel construction

PRODUCT COMPONENTS

Familiarize yourself with the parts of your Klarstein Biggie appliance:

- Main Unit (Stainless Steel Pot)
- Lid (Plastic)
- Integrated Stainless Steel Tap
- Temperature Control Knob

- Timer Control Knob
- Power Indicator Light
- Internal Grid Insert
- Heat-Resistant Plastic Handles
- Water Level Indicator

Pentola automatica per conserve & vin brulé



Scaldare
e pastorizzare



Pentola e rubinetto
in acciaio inox
di alta qualità



Stoccaggio
salvaspazio del cavo


KLARSTEIN



Image: The Klarstein Biggie preserving cooker, highlighting its stainless steel body, integrated tap, and control panel with power indicator.


KLARSTEIN

1800 W

Moderna
pentola
per conserve
automatica

25 litri




KLARSTEIN

Image: A side view of the Klarstein Biggie, showing the power cord connection and the robust handles.

SETUP

1. **Unpacking:** Carefully remove all packaging materials and inspect the appliance for any damage. Keep packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, clean the interior of the pot, the lid, and the grid insert with warm soapy water. Rinse thoroughly and dry.
3. **Placement:** Place the appliance on a stable, heat-resistant, and level surface. Ensure there is sufficient space around the unit for ventilation. Do not place it near flammable materials or heat sources.
4. **Power Connection:** Ensure the power cord is securely plugged into a grounded electrical outlet. The appliance operates on 220-240V, 50/60Hz.
5. **Insert Grid:** Place the internal grid insert at the bottom of the pot. This prevents jars from touching the heating element directly.

OPERATING INSTRUCTIONS

General Operation

1. Fill the pot with the desired liquid or place jars on the internal grid. Ensure the liquid level is appropriate for your task (e.g., covering jars for preserving). Do not exceed the MAX fill line.
2. Place the lid securely on the pot.
3. Plug the appliance into a power outlet. The power indicator light will illuminate.
4. Use the **Temperature Control Knob** to set the desired temperature (30°C - 110°C).
5. Use the **Timer Control Knob** to set the desired operating time (1-120 minutes). If you wish to operate continuously without a timer, set the timer to the 'ON' position.
6. The appliance will begin heating. Once the set temperature is reached, the heating element may cycle on and off to maintain the temperature.
7. When the timer expires, the appliance will automatically shut off. If operating continuously, manually turn the temperature and timer knobs to 'OFF' and unplug the unit.



Controllo intuitivo

Design di facile utilizzo con temperatura regolabile, timer e protezione dal surriscaldamento - facile controllo con le manopole intuitive


KLARSTEIN

shut-off feature.

Preserving (Canning)

This appliance is suitable for preserving fruits, vegetables, jams, sausages, and meat dishes.

1. Prepare your food and fill it into appropriate preserving jars. Seal the jars according to their instructions.
2. Place the internal grid insert at the bottom of the pot.
3. Carefully place the sealed jars onto the grid. Ensure jars do not touch each other or the sides of the pot.
4. Fill the pot with water until the jars are covered by at least 2-3 cm of water.
5. Set the desired temperature and timer according to your preserving recipe.
6. Once the preserving process is complete and the appliance has cooled, carefully remove the jars using appropriate tools.

Prelibatezze in vasetto


KLARSTEIN

Per conservare con
facilità frutta, verdura,
marmellata, insaccati
o piatti a base di carne

Incluso inserto a griglia
per la pastorizzazione



Image: The interior of the preserving cooker, illustrating the removable grid insert used to support jars during the canning process.

Mulled Wine and Hot Beverage Dispensing

The integrated tap makes this appliance ideal for heating and serving mulled wine, hot water, or other beverages.

1. Fill the pot with your desired beverage. Do not exceed the MAX fill line.
2. Set the temperature to your preferred serving temperature (e.g., 70-80°C for mulled wine).
3. Set the timer or use the 'ON' setting for continuous heating.
4. Once the beverage is heated, it can be dispensed directly from the stainless steel tap.
5. Always ensure the tap is closed when not dispensing to prevent spills.

Facile da utilizzare



Erogare bibite calde
o acqua bollente
direttamente dal rubinetto
- pulita, efficiente
e ideale per uso privato
o commerciale



Image: The Klarstein Biggie in use, dispensing a hot beverage into glasses, demonstrating its function as a mulled wine dispenser.

CLEANING AND MAINTENANCE

Regular cleaning ensures the longevity and hygienic operation of your appliance.

1. **Always unplug the appliance** from the power outlet and allow it to cool completely before cleaning.
2. **Exterior:** Wipe the exterior of the stainless steel pot with a damp cloth. For stubborn stains, use a mild detergent and then wipe with a clean, damp cloth. Do not use abrasive cleaners or scouring pads.
3. **Interior:** Clean the interior of the pot and the grid insert with warm soapy water. Rinse thoroughly and dry

completely.

- 4. **Tap:** To clean the tap, run warm water through it. For thorough cleaning, the tap can often be disassembled (refer to specific instructions if provided with the unit for tap removal). Ensure no food particles are lodged inside.
- 5. **Descaling:** Over time, mineral deposits may build up, especially if using hard water. Descale the appliance regularly using a commercial descaling solution or a mixture of water and vinegar. Follow the descaling product's instructions.
- 6. **Storage:** Store the appliance in a dry, clean place when not in use. The power cord can be wrapped for neat storage.

TROUBLESHOOTING

If you encounter issues with your Klarstein Biggie, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on	Not plugged in; Power outlet fault; Timer not set or set to 'OFF'	Check power cord connection; Test outlet with another device; Set timer to desired duration or 'ON'
Appliance not heating	Temperature knob set too low; Overheat protection activated	Increase temperature setting; Unplug and allow to cool for 30 minutes, then restart
Liquid leaking from tap	Tap not fully closed; Tap seal damaged or dirty	Ensure tap handle is fully closed; Clean tap thoroughly; Contact customer support if seal is damaged
Temperature not consistent	Normal cycling of heating element; Sensor issue	This is normal for mechanical thermostats; If fluctuations are extreme, contact customer support

TECHNICAL SPECIFICATIONS

- **Model:** ZJ-28TD
- **Brand:** KLARSTEIN
- **Capacity:** 25 Liters
- **Power:** 1800 W
- **Voltage:** 220-240V ~ 50/60Hz
- **Temperature Range:** 30°C - 110°C
- **Timer Range:** 1 - 120 minutes (or continuous 'ON')
- **Material:** Brushed Stainless Steel
- **Dimensions (WxHxD):** Approximately 38 x 47 x 45 cm (15 x 18.5 x 17.7 inches)
- **Weight:** 4.3 kg (9.5 lbs)



Image: The Klarstein Biggie appliance with its key dimensions (width, height, depth) and weight indicated for reference.

WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. If you require technical assistance, spare parts, or have any questions regarding the operation of your Klarstein Biggie, please contact Klarstein customer support. You can typically find contact details on the Klarstein website or through your purchase platform.

Online Resources: For additional information, FAQs, and product registration, please visit the official Klarstein website or the brand store on Amazon:

- [Klarstein Brand Store on Amazon](#)