Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CUBIMANA HG1015

CUBIMANA Tree House Building Set with LED Light

Model: HG1015

Introduction

Welcome to the CUBIMANA Tree House Building Set with LED Light. This exquisite 618-piece construction set allows you to build a detailed three-story tree house scene, complete with a living room, tool shed, dog house, and a vibrant cultivation area. Designed to stimulate imagination and enhance practical skills, this set provides an engaging building experience for children aged 6 and above.

The set includes an adorable puppy figure and a squirrel figure, adding to the forest adventure. With its interactive design and LED lighting feature, the tree house offers both daytime and nighttime play scenarios, fostering creativity and problem-solving abilities.

Safety Information

Warning: This product contains small parts and is intended for children aged 6-80 years. Adult supervision is recommended during assembly and play, especially for younger children, to prevent choking hazards.

- Keep all packaging materials away from children.
- Do not ingest any parts of the building set.
- Ensure all connections are secure to prevent parts from detaching during play.
- The LED light unit contains button cell batteries. Keep batteries out of reach of small children. If swallowed, seek immediate medical attention.

Package Contents

Upon opening the package, verify that all components are present:

- 618 building pieces, separated into numbered bags.
- Illustrated instruction manual (full-color).
- LED light unit with integrated battery.
- Two irregularly shaped green base plates.
- Accessory figures: 1 puppy, 1 squirrel.
- Small sticker sheet for additional decoration.

If any parts are missing or damaged, please contact CUBIMANA customer support.

Assembly Instructions

Follow these steps carefully to assemble your CUBIMANA Tree House Building Set:

1. **Preparation:** Unpack all components. Organize the building pieces by their numbered bags as indicated in the instruction manual. Lay out the two green base plates, which will form the foundation of your tree house.
2. **Follow the Manual:** Refer to the included full-color, illustrated instruction manual. The manual provides clear, step-by-step guidance for each building stage. Each step displays the required parts and shows how to connect them.
3. **Building Stages:** The assembly is typically divided into sections. Work through each section methodically. The pieces are made from high-quality ABS plastic, designed for a secure fit.
4. **Sticker Application:** Apply the decorative stickers as indicated in the manual. For best results, ensure surfaces are clean and dry before application. Adult assistance may be helpful for precise placement of smaller stickers.
5. **LED Light Installation:** The LED light unit consists of a transparent 1x4 plate with LED points, connected by a thin cable to a 2x4 battery brick with a small slide switch. Integrate this unit into the upstairs portion of the tree house as shown in the manual. Ensure the cable is routed correctly and the battery brick is securely placed.
6. **Final Touches:** Once the main structure is complete, add the accessory figures, plants, and other decorative elements to bring your tree house to life.



Image: An example of the assembled CUBIMANA Tree House Building Set. This image illustrates the overall structure and some details of the completed model.

Tip: The building blocks are compatible with other major brick brands, allowing for expanded creative possibilities.

Operating the LED Light

The CUBIMANA Tree House includes an integrated LED light feature for enhanced play experience.

- **Powering On/Off:** Locate the small slide switch on the 2x4 battery brick of the LED light unit. Slide the switch to the 'ON' position to illuminate the tree house. Slide it to the 'OFF' position when not in use to conserve battery life.
- **Battery Replacement:** The LED unit uses button cell batteries. When the light dims or stops working, the batteries need replacement. Carefully open the battery compartment on the 2x4 brick, replace the old batteries with new ones of the same type, ensuring correct polarity, and securely close the compartment.

Maintenance

To ensure the longevity and cleanliness of your CUBIMANA Tree House Building Set, follow these maintenance guidelines:

- **Cleaning:** Use a soft, damp cloth to gently wipe down the building blocks. For stubborn dirt, a mild soap solution can be used, followed by rinsing with clean water and air-drying. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the assembled tree house or individual blocks in a cool, dry place away from direct sunlight and extreme temperatures. Prolonged exposure to sunlight can cause colors to fade.
- **Handling:** Handle the assembled model with care to prevent parts from detaching.

Troubleshooting

If you encounter any issues during assembly or play, consider the following:

- **Missing Pieces:** Double-check all packaging and bags. If a piece is genuinely missing, contact CUBIMANA customer support with details of the missing part (as identified in the manual).
- **Difficulty Connecting Pieces:** Ensure the pieces are correctly oriented and aligned. Apply firm, even pressure. If a piece is unusually tight, check for any manufacturing defects.
- **LED Light Not Working:**
    a. Check if the slide switch on the battery brick is in the 'ON' position.
    b. Verify that the batteries are correctly installed with the correct polarity.
    c. Replace the batteries with new ones if they are depleted.
    d. Ensure all connections within the LED unit are secure.
- **Model Instability:** Ensure all connections are firm and that the base plates are on a flat, stable surface. Re-check the assembly steps for any missed or incorrectly placed pieces.

Specifications

Model Number:	HG1015
Brand:	CUBIMANA
Number of Pieces:	618
Recommended Age:	6 - 80 years
Material:	High-quality ABS Plastic
Product Dimensions:	Approximately 20 x 20 x 20 mm (individual pieces, overall dimensions not specified but implied by reviews to be larger for the assembled model)
Weight:	790 g
Power Source (LED):	1 Non-standard battery (button cell), included
Assembly Required:	Yes
Country of Origin:	China

Warranty and Support

CUBIMANA products are manufactured to high-quality standards. For any questions, concerns, or support regarding your Tree House Building Set, please contact CUBIMANA customer service through your retailer or the official CUBIMANA website. Please retain your proof of purchase for warranty claims, if applicable.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GT34JWW8

More documents and user manuals: **https://manuals.plus/**