



[Manuals.plus](#) /

› [Bellemave](#) /

› Bellemave Triple Metal Bunk Bed (Full Over Twin Over Twin) Instruction Manual

Bellemave W1580S00210

Bellemave Triple Metal Bunk Bed Instruction Manual

Model: W1580S00210

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Bellemave Triple Metal Bunk Bed. This bed features a Full or Full XL over Twin over Twin configuration, designed for space efficiency with integrated storage shelves and stairs. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: The Bellemave Triple Metal Bunk Bed, showcasing its design with two lower twin beds, an upper full bed, and integrated stairs with shelves.

SAFETY INFORMATION

Adherence to the following safety guidelines is crucial for preventing injuries and ensuring the longevity of your bunk bed.

- **Maximum Weight Capacity:** Do not exceed the recommended weight limits for each bunk. Consult the product specifications for exact details.
- **Upper Bunk Age Restriction:** The upper bunk is not suitable for children under 6 years of age.
- **Guardrails:** Always use the guardrails on the upper bunk. Ensure they are properly installed and secured.
- **Mattress Thickness:** Use only mattresses that comply with the specified thickness to ensure adequate guardrail height.
- **No Horseplay:** Prohibit jumping on the bed or any form of rough play on or under the bunk bed.
- **Ladder/Stairs Safety:** Always use the provided stairs for access to the upper bunk. Do not use alternative climbing

methods.

- **Assembly:** Ensure all connections are tight and secure before use. Periodically check and tighten hardware.
- **Ventilation:** Ensure adequate ventilation around the bed.



Image: Detailed view highlighting the heavy-duty metal construction, integrated shelves, and anti-slip features of the bunk bed, emphasizing safety and durability.

PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, contact customer support immediately.

- Metal Bed Frame Components (various beams, posts, and slats)
- Wooden Panels for Headboards and Shelves
- Staircase Components

- Hardware Pack (screws, bolts, washers, Allen wrench)
- Instruction Manual

All bed frame components are included as per the product description.

SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of the Bellemave Triple Metal Bunk Bed requires two adults. Follow the step-by-step installation manual provided in the package. Ensure you have sufficient space for assembly.

1. **Unpack Components:** Carefully unpack all parts and lay them out on a clean, soft surface (e.g., a carpet) to prevent scratches.
2. **Identify Parts:** Refer to the parts list in the separate installation manual to identify each component.
3. **Assemble Base Frames:** Begin by assembling the base frames for the lower twin beds and the full/full XL bed, following the diagrams.
4. **Attach Vertical Supports:** Connect the vertical support posts to the base frames.
5. **Install Upper Bunk Frame:** Secure the upper bunk frame to the vertical supports.
6. **Assemble Stairs and Shelves:** Construct the integrated storage stairs and attach them securely between the lower bunks. Install the middle storage shelf and the upper bunk headboard shelf.
7. **Install Slats:** Place and secure the mattress support slats for all three bunks.
8. **Final Tightening:** Once all components are in place, systematically tighten all bolts and screws. Do not overtighten.
9. **Safety Check:** Before use, ensure the bed is stable, all connections are secure, and guardrails are properly installed.

The bed features pre-drilled holes for straightforward assembly.




Image: A detailed view of the integrated stairs and the central desk/shelf area, illustrating the assembly points for these components.



Image: An overhead perspective of the bunk bed frame, showing the layout of the three sleeping areas and the central staircase structure.

OPERATING INSTRUCTIONS (USAGE)

This bunk bed is designed for efficient use of space and provides comfortable sleeping arrangements for three individuals, along with integrated storage and a functional workstation.

- **Accessing Upper Bunk:** Always use the integrated stairs to safely access and descend from the upper bunk.
- **Storage Shelves:** Utilize the middle section's long, medium-height storage shelf for books, decor, or personal items. The upper bunk also features a headboard shelf for convenient placement of daily items like phones or small books.
- **Workstation:** The central area with the storage shelf can function as a shared workstation or study area.
- **Mattress Placement:** Ensure mattresses are correctly sized for each bunk (Full/Full XL for upper, Twin for lower two) and are placed securely within the frame.



MULTIFUNCTIONAL HUB

This space saving bunk bed combines a shared workstation with safe stairs and ample storage.



SHARED WORKSTATION

Integrated desk for study or work.



SAFE STAIRS

Easy and secure access to the upper bunk.



AMPLE STORAGE

Space for books, decor, and more.



SHARED WORKSTATION

Integrated desk for study or work.



SAFE STAIRS

Easy and secure access to the upper bunk.



AMPLE STORAGE

Space for books, decor, and more.

Image: A graphic detailing the multifunctional aspects of the bunk bed, including the shared workstation, safe stairs, and various storage options.

TRIPLE SPACE EFFICIENCY

A smart sleep-and-study solution with heavy duty metal frame for three kids or teens.



Image: Illustrates the practical use of the bunk bed, showing an individual utilizing the central desk area and a child safely ascending the stairs.

Your browser does not support the video tag.

Video: An official product video demonstrating the features and overall design of the Bellemave Triple Metal Bunk Bed.

MAINTENANCE

Regular maintenance ensures the safety and longevity of your bunk bed.

- **Cleaning:** Wipe down metal surfaces with a soft, damp cloth. For wooden parts, use a dry or slightly damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Hardware Check:** Periodically (every 3-6 months) inspect all bolts, screws, and connections. Tighten any loose hardware to maintain structural integrity and prevent wobbling or squeaking.
- **Structural Integrity:** Check for any signs of wear, damage, or bending in the metal frame or wooden components. Address any issues promptly.

- **Rust Prevention:** The metal frame has a rust-resistant coating. Avoid prolonged exposure to moisture to prevent rust.

TROUBLESHOOTING

Refer to the following common issues and their solutions.

Problem	Possible Cause	Solution
Bed is wobbly or unstable.	Loose hardware connections.	Inspect and tighten all bolts and screws. Ensure all components are correctly aligned.
Squeaking noises during use.	Loose connections or friction between metal parts.	Tighten all hardware. Apply a small amount of lubricant (e.g., silicone spray) to connection points if squeaking persists.
Missing parts during assembly.	Packaging error or lost component.	Review the parts list in the manual. Contact Bellemave customer support with the specific part number.
Difficulty aligning holes during assembly.	Components are not oriented correctly.	Double-check the assembly diagrams. Ensure parts are facing the correct direction before tightening. Do not fully tighten screws until all parts are loosely assembled.

SPECIFICATIONS

Detailed product specifications for the Bellemave Triple Metal Bunk Bed.

- **Model Number:** W1580S00210
- **Product Dimensions (L x W x H):** 96.8" x 75.3" x 66"
- **Compatible Mattress Size:** Full (or Full XL) Over Twin Over Twin
- **Material:** Engineered Wood, Metal
- **Color:** Black
- **Style:** Modern
- **Item Weight:** 175.27 Pounds
- **Assembly Required:** Yes
- **Special Features:** Integrated Storage Shelves, Storage Stairs, Heavy Duty Metal Frame

