

[Manuals.plus](#) /

> [Bellemave](#) /

> Bellemave Full Over Twin & Twin Bunk Bed with Shelves (Model LSH-039-FTTtrip) Instruction Manual

Bellemave LSH-039-FTTtrip

Bellemave Full Over Twin & Twin Bunk Bed with Shelves (Model LSH-039-FTTtrip) Instruction Manual

INTRODUCTION

Thank you for choosing the Bellemave Full Over Twin & Twin Bunk Bed with Shelves. This manual provides essential information for the safe assembly, operation, and maintenance of your new bunk bed. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

This triple bunk bed features a full-size bed on top and two twin-size beds below, along with integrated shelves and a sturdy metal frame, designed for efficient space utilization and comfort.

IMPORTANT SAFETY INFORMATION

Failure to follow these warnings could result in serious injury.

- **Maximum Weight Capacity:** Do not exceed the maximum weight capacity of 300 pounds for any single sleeping surface.
- **Ladder Use:** Always use the provided ladder for safe access to the upper bunk. Do not use chairs or other items to climb onto the bunk.
- **Adult Supervision:** Adult supervision is recommended, especially for younger children using the bunk bed.
- **Guardrails:** Ensure all guardrails are properly installed and secured before use. The upper bunk is equipped with full-length guardrails for safety.
- **Mattress Size:** Use only mattresses of the specified size to prevent gaps that could lead to entrapment. Refer to the Specifications section for details.
- **No Horseplay:** Prohibit horseplay on or under the bed.
- **No Jumping:** Do not allow jumping on the bed.
- **Ventilation:** Ensure adequate ventilation around the bed.
- **Regular Checks:** Periodically check and ensure that all connectors are tight and secure.

PACKAGE CONTENTS

Before beginning assembly, please verify that all parts and hardware are present. Refer to the parts list included in your product packaging. If any items are missing or damaged, do not proceed with assembly. Contact Bellemave customer support immediately.

Typical components include:

- Metal frame components (legs, side rails, crossbars)
- Bed slats
- Guardrails
- Ladder components
- Integrated shelves/workstation components
- Hardware pack (screws, bolts, washers, Allen wrench)
- Instruction manual


SETUP AND ASSEMBLY

Assembly requires at least two adults. Clear a large area for assembly and keep all hardware out of reach of small children. Do not use power tools for assembly as this may overtighten fasteners and damage the frame.

Step 1: Unpack and Identify Parts

Carefully unpack all components and lay them out on a soft, clean surface to prevent scratches. Compare each part to the included parts list to ensure everything is present and undamaged.

Product Dimensions



Size: inch

Image: Overview of the Bellemave Full Over Twin & Twin Bunk Bed structure.

Step 2: Assemble Base Frames

Begin by assembling the base frames for the two twin beds and the full-size top bunk. Attach the side rails to the headboards and footboards using the provided hardware. Ensure all connections are finger-tight at this stage.



Image: The Bellemave Full Over Twin & Twin Bunk Bed fully assembled, showcasing its design and integrated shelves.

Step 3: Install Support Slats

Once the frames are assembled, install the metal support slats onto each bed frame. Ensure they are evenly spaced and securely fastened according to the instructions. These slats provide crucial support for your mattress and eliminate the need for a box spring.



Image: Angled view of the bunk bed, highlighting the metal slat support system and overall frame construction.

Step 4: Attach Ladder and Shelves

Connect the ladder and integrated shelves to the main structure as indicated in the assembly guide. These components are designed to interlock and provide additional stability. Ensure all bolts are securely tightened.



Image: Detailed view of the central integrated shelves and the sturdy ladder, which also serves as a workstation.

Step 5: Secure Guardrails and Final Tightening

Install the guardrails on the upper bunk. Once all components are in place, go back and securely tighten all bolts and fasteners using the provided Allen wrench. Do not overtighten. Double-check all connections for stability.



Image: Close-up of the bed's headboard/footboard design, showing the metal frame and wooden accents.

Refer to the detailed assembly instructions included in your product packaging for step-by-step diagrams and specific hardware identification.

OPERATING INSTRUCTIONS (USAGE)

To ensure safe and proper use of your Bellemave bunk bed, please adhere to the following guidelines:

- **Mattress Placement:** Place the full-size mattress on the top bunk and twin-size mattresses on the two lower bunks. Ensure mattresses fit snugly within the frame and do not exceed the maximum recommended thickness (refer to specifications).
- **Ladder Safety:** Always use the ladder to access the upper bunk. Face the ladder when climbing up or down. Ensure the ladder is stable before use.
- **Weight Limits:** Do not exceed the 300-pound weight limit for any individual sleeping surface.
- **Guardrail Integrity:** Regularly check that the guardrails on the upper bunk are securely attached and free from

damage.

- **Integrated Shelves:** The central shelves can be used for books, small electronics, or decorative items. Do not overload the shelves. The wider shelf can function as a small workstation.
- **Underbed Storage:** Utilize the space under the lower beds for storage bins or boxes to keep the room tidy.

MAINTENANCE

Proper maintenance will extend the life and safety of your bunk bed:

- **Cleaning:** Wipe down the metal frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish. For wooden shelf surfaces, use a mild wood cleaner.
- **Hardware Check:** Periodically (e.g., every 3-6 months) inspect all bolts, screws, and connections. Tighten any that have become loose. Do not overtighten.
- **Structural Integrity:** Check the bed frame for any signs of damage, bending, or cracks. If any damage is found, discontinue use immediately and contact customer support.
- **Squeak Prevention:** If the bed begins to squeak, identify the source of the noise. Often, tightening loose bolts or applying a small amount of lubricant (e.g., silicone spray) to metal-on-metal contact points can resolve the issue.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Bed is wobbly or unstable.	Loose hardware connections.	Check and tighten all bolts and screws. Ensure the bed is on a level surface.
Squeaking noises.	Loose connections or metal-on-metal friction.	Tighten all hardware. Apply a small amount of silicone lubricant to contact points if necessary.
Missing parts during assembly.	Packaging error or lost during unpacking.	Do not proceed with assembly. Contact Bellemave customer support with your parts list and purchase information.
Mattress does not fit properly.	Incorrect mattress size or improper assembly.	Verify mattress dimensions against specifications. Recheck assembly steps to ensure frame is correctly built.

SPECIFICATIONS

The following specifications apply to the Bellemave Full Over Twin & Twin Bunk Bed with Shelves (Model LSH-039-FTTtrip):



Image: Diagram showing the precise dimensions of the Bellemave Full Over Twin & Twin Bunk Bed.

Model Number: LSH-039-FTTtrip

Brand: Bellemave

Material: Metal

Color: Black

Overall Product Dimensions (L x W x H):96.8" x 75.3" x 66"

Upper Bunk Size: Full

Lower Bunk Size: Twin (x2)

Maximum Weight Recommendation (per bed):300 pounds

Special Features: Bunk Bed for 3, No Box Spring Needed, Space Saving, Squeak Resistant, Integrated Shelves, Guardrails, Storage Stairs (ladder with shelves)

Included Components: Guardrails, Shelves, Slats, Storage Stairs

Item Weight: Approximately 87 pounds

Compatible Mattress Size: Full (upper), Twin (lower)

WARRANTY AND SUPPORT

Bellemave stands behind the quality of its products. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Bellemave website. Keep your proof of purchase for any warranty claims. If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Bellemave customer support. Provide your model number (LSH-039-FTTtrip) and purchase date for faster service.

Bellemave Customer Support: Refer to your product packaging or the Bellemave brand store on Amazon for contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GT83Y82P>

More documents and user manuals: <https://manuals.plus/>