

Bextgoo M11-WP0301

Bextgoo 4K Sport Camera M11-WP0301 User Manual

Your comprehensive guide to setting up and using your Bextgoo 4K Sport Camera.

1. INTRODUCTION

Welcome to the Bextgoo 4K Sport Camera M11-WP0301 user manual. This guide provides detailed instructions to help you get started with your new camera, understand its features, and troubleshoot any issues. The Bextgoo 4K Sport Camera is designed to capture your adventures in stunning 4K Ultra HD, featuring a 150° wide-angle lens, Electronic Image Stabilization (EIS), and Wi-Fi connectivity for easy sharing. Its compact and waterproof design makes it ideal for various activities, from cycling and hiking to underwater exploration.

2. WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- 1 × Bextgoo 4K Sport Camera
- 1 × 64GB Memory Card
- 1 × USB Cable
- 1 × Full Accessory Kit (includes waterproof case, magnetic back cover, rear clip, 180° cap mount, H-mount for bike/motorcycle, camera support, rotating side connector, adjustable magnetic pendant, 45mm short screw, 55mm long screw, support with integrated nut, 360° adjustable adapter, adjustable silicone wristband, adhesive base A (flat), adhesive base B (curved), clip fixation)
- 1 × User Manual (this document)

Aucune Pièce Manquante. Pas de Trajets Supplémentaires



Figure 2.1: All included accessories for the Bextgoo 4K Sport Camera.

3. PRODUCT OVERVIEW

Familiarize yourself with the main components of your Bextgoo 4K Sport Camera:



Figure 3.1: Key components of the Bextgoo 4K Sport Camera.

- **Indicator Light:** Instantly shows if the camera is on, recording, or charging.
- **Power and Video Recording Button:** Press to turn on/off or start/stop video recording.
- **Photo and Wi-Fi Button:** Press to take photos or activate Wi-Fi for smartphone connection.
- **Magnetic Charging Contacts:** For secure and effortless charging.
- **Bottom Cover Area:** Contains the TF card slot, USB-C port, and reset button.

4. SETUP

4.1. Inserting the Memory Card

Your camera comes with a 64GB memory card already included. To access the slot, open the bottom cover. Ensure the card is inserted correctly with the gold contacts facing the camera's front. Gently push until it clicks into place.

4.2. Charging the Camera

Before first use, fully charge the camera. Connect the provided USB-C cable to the camera's USB-C port (located under the bottom cover) and to a USB power adapter (not included) or a computer. The indicator light will show charging status.

Vitesse USB-C, Sans Complication

Connectez-vous à un ordinateur via USB-C pour accéder instantanément à toutes vos photos et vidéos. Un accès facile pour passer plus de temps à revivre vos souvenirs.



Figure 4.1: Charging the camera via USB-C for fast data transfer and power.

4.3. Powering On/Off

- **To Power On:** Press and hold the Power/Video Recording Button for a few seconds until the indicator light turns on.
- **To Power Off:** Press and hold the Power/Video Recording Button for a few seconds until the indicator light turns off.

4.4. Connecting to the Mobile App (Wi-Fi)

Download the official Bextgoo app from your smartphone's app store. Once installed:

1. Turn on the camera.
2. Press the Photo/Wi-Fi Button to activate Wi-Fi mode. The indicator light will change to indicate Wi-Fi is active.
3. On your smartphone, go to Wi-Fi settings and connect to the camera's Wi-Fi network (usually named "Bextgoo_XXXX").
4. Open the Bextgoo app. You should now see a live preview from your camera and be able to control it remotely.

Vos Prises de vue, Instantanément sur Votre Téléphone

Sans câble, sans attente, le Wi-Fi transfère chaque image directement sur votre téléphone.
Voyez-la, téléchargez-la et partagez-la — en un instant.



Figure 4.2: Seamlessly transfer and share your footage to your smartphone via Wi-Fi.

5. OPERATING INSTRUCTIONS

5.1. Recording Video

With the camera powered on, press the Power/Video Recording Button once to start recording. The indicator light will flash to confirm recording is in progress. Press the button again to stop recording.

5.2. Taking Photos

In standby mode (camera on, not recording), press the Photo/Wi-Fi Button once to take a photo. The camera will emit a shutter sound (if enabled) and the indicator light will flash briefly.

5.3. Using the Waterproof Case

For underwater activities or protection against harsh weather, place the camera inside the included waterproof case. Ensure the case is properly sealed before submerging. The camera is waterproof up to 30 meters (100 feet) with the case.



Figure 5.1: The Bextgoo 4K Sport Camera is waterproof and weather-resistant, suitable for various environments.

5.4. Mounting Options

The full accessory kit provides versatile mounting options:

- **Magnetic Mount:** Attach the camera to metallic surfaces or use the magnetic back cover for hands-free recording on clothing.
- **Bike/Motorcycle H-Mount:** Securely attach the camera to handlebars.
- **Helmet Mounts:** Use adhesive bases (flat or curved) with the 360° adjustable adapter for helmet attachment.
- **Adjustable Silicone Wristband:** Wear the camera on your wrist for POV shots.
- **Clip Fixation:** Attach the camera to straps, pockets, or other gear.

Liberté à la Première Personne

Vivez votre histoire. Capturez le monde tel que vous le voyez — les mains libres — et transformez les moments du quotidien en souvenirs épiques.




Figure 5.2: Versatile mounting options for capturing every moment from your perspective.

6. KEY FEATURES

6.1. 4K Ultra HD Video & 150° Wide Angle

Capture your world in stunning 4K Ultra HD resolution with an enhanced 150° wide-angle lens. This ensures immersive footage with an expanded field of view, perfect for capturing vast landscapes and dynamic action.

L'action Prend vie en 4K

Plus net que le souvenir, plus clair que la réalité : la 4K capture tout.




Figure 6.1: Experience every detail with real 4K Ultra HD clarity.

Filmez à 140° Grand Angle. Un Résultat Époustouflant.

Immortalisez chaque instant de votre aventure grâce à l'objectif ultra grand angle de 140° : vos amis, les paysages et l'action, le tout dans un seul et même cadre épique et immersif. Rien ne vous échappe, tout prend vie.



Figure 6.2: Capture more of your surroundings with the 140° wide-angle lens.

6.2. Electronic Image Stabilization (EIS) & HDR

The integrated EIS technology ensures stable and smooth footage, even during dynamic activities. Combined with HDR, your videos will be bright, balanced, and full of life, capturing every moment with clarity.

Avec EIS Des Images d'une Stabilité à Toute Épreuve, à Chaque Mouvement

La stabilisation d'image électronique (EIS) garantit la stabilité de vos prises de vue, même lors d'actions rapides ou d'aventures mouvementées. Dites adieu au flou et aux tremblements : vos images restent nettes et fluides.

Avec la Technologie HDR Sublimez Chaque Instant

HDR ensures every shot is bright, balanced, and full of life—whether under harsh sunlight or in low-light settings.



Figure 6.3: Enjoy stable images with EIS technology, even during movement.

6.3. Extended Recording with 64GB Card & 1200mAh Battery

The included 64GB memory card allows you to start filming immediately, while the 1200mAh battery supports up to 220 minutes of continuous recording. You can also record while charging, making it a reliable companion for long trips and outdoor adventures.

Mémoire 64 Go Toujours Active

Stockage 64 Go prêt à l'emploi avec enregistrement en boucle intelligent. Les anciens fichiers sont automatiquement remplacés, pour capturer chaque nouveau moment sans interruption.



Figure 6.4: Always-on 64GB memory for continuous recording.

6.4. Smart Wi-Fi Connectivity

Connect your camera to your smartphone via built-in Wi-Fi for real-time preview, video playback, and quick sharing through the dedicated app. The 1.47-inch screen also allows for instant shot preview.

Aperçu en Direct – Contrôlez Chaque Image

Prévisualisez, ajustez et capturez avec précision — chaque image nette, chaque instant saisi



Figure 6.5: Live preview and control every shot with precision.

6.5. Ultra-Portable Design

Weighing only 53g, this camera is incredibly lightweight and portable. Its compact size allows you to carry it anywhere, ensuring you never miss an epic moment.

Explorateur de Poche

Assez petit pour être oublié, assez puissant pour tout capturer. Emportez-le partout et enregistrez chaque moment épique sans encombrement.



Figure 6.6: The Bextgoo 4K Sport Camera is a pocket explorer, small enough to be forgotten, powerful enough to capture everything.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the camera body. For the lens, use a specialized lens cleaning cloth and solution. Do not use harsh chemicals.
- **Waterproof Case Care:** After using the waterproof case in saltwater, rinse it thoroughly with fresh water and let it air dry. Check the O-ring seal regularly for any damage or debris.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Store the camera with a partial charge (around 50%) if not used for extended periods.
- **Storage:** Store the camera in a cool, dry place away from direct sunlight and extreme temperatures.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Camera does not turn on.	Low battery; camera frozen.	Charge the battery. If still unresponsive, press the reset button (located under the bottom cover) with a thin object.
Cannot record video or take photos.	Memory card full or not inserted correctly; camera frozen.	Check memory card insertion. Delete old files or format the card (backup important data first). Reset the camera.
Wi-Fi connection issues.	Incorrect Wi-Fi password; camera Wi-Fi not activated; app issues.	Ensure camera Wi-Fi is on. Re-enter Wi-Fi password. Restart camera and smartphone. Reinstall the app if necessary.
Blurry or unstable footage.	Lens dirty; EIS not enabled; extreme movement.	Clean the lens. Ensure EIS is enabled in settings (via app). Try to minimize excessive shaking during recording.
Camera gets hot during use.	Normal operation for 4K recording; prolonged use.	It is normal for the camera to warm up during 4K recording. If it becomes excessively hot, stop use and allow it to cool down.

9. SPECIFICATIONS

Brand	Bextgoo
Model Number	M11-WP0301
Video Recording Resolution	4K
Effective Capture Resolution	12 Megapixels
Photo Sensor Technology	CMOS
Lens Type	Wide Angle (150°)
Max Focal Length	2.96 Millimeters
Max Aperture	2.96 Millimeters
Screen Size	1.47 Inches
Connectivity Technology	Wi-Fi
Image Stabilization	Electronic (EIS)
Water Resistance Level	Waterproof (with included housing up to 30M)
Battery Capacity	1200mAh
Installed Flash Memory Size	64 GB
Form Factor	Compact
Compatible Devices	Smartphone
Country of Origin	China

10. WARRANTY & SUPPORT

10.1. Warranty Information

The Bextgoo 4K Sport Camera M11-WP0301 comes with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or natural disasters.

10.2. Customer Support

Bextgoo is dedicated to providing high-quality security products and excellent customer satisfaction. Our competent support team is always ready to assist you with installation, usage, or technical questions. For support, please contact us through the official Bextgoo website or your purchase platform.



Figure 10.1: Our support team is available to assist you.

© 2026 Bextgoo. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

