

[Manuals.plus](#) /

› [PHILIPS](#) /

› Philips 32-inch HD QLED Smart TV with Google TV (PQT6731) Instruction Manual

PHILIPS PQT6731

Philips 32-inch HD QLED Smart TV with Google TV (PQT6731)

Instruction Manual

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using your Philips Smart TV. Keep this manual for future reference.

- Do not expose the TV to rain or moisture.
- Ensure proper ventilation around the TV.
- Use only the power cord supplied with the TV.
- Do not open the TV casing; refer all servicing to qualified personnel.
- Keep the TV away from direct sunlight, heat sources, and strong magnetic fields.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- Philips 32-inch HD QLED Smart TV (PQT6731)
- Remote Control
- AAA Batteries (x2)
- TV Stand (x2)
- Stand Screws
- Power Cable
- Quick Start Guide
- Warranty Card

3. SETUP

3.1 Attaching the Stand

Place the TV screen-down on a soft, flat surface. Align the stand pieces with the designated slots on the bottom of the TV and secure them with the provided screws using a screwdriver.



Image: Front view of the Philips 32-inch Smart TV with its stand attached.

3.2 Connecting Peripherals

Connect your devices to the appropriate ports on the back of the TV. This model features multiple HDMI and USB ports for various connections.

- **HDMI Ports:** Connect Blu-ray players, game consoles, or other HDMI-enabled devices.
- **USB Ports:** Connect USB storage devices for media playback.

- **Audio Output:** Connect external sound systems.
- **AV Input:** For older devices requiring composite video and stereo audio.



Image: Diagram illustrating the USB, HDMI, audio output, and AV input ports on the TV.

3.3 Power Connection and Initial Setup

Connect the power cable to the TV and then to a power outlet. The TV will guide you through the initial setup process, including Wi-Fi connection, Google account login, and language selection. This TV is a tuner-less model; therefore, an external tuner is required to watch broadcast television (terrestrial, BS/110°CS).

4. OPERATING INSTRUCTIONS

4.1 Remote Control Functions

The included remote control allows for easy navigation and voice search. It features dedicated buttons for popular streaming services like Netflix, YouTube, Hulu, ABEMA, PICTURE, and Live TV for quick access.



充実な動画配信サービス

シームレスなエンターテインメントを楽しむ



Image: The remote control for the Philips Smart TV, highlighting direct access buttons for streaming services and voice search functionality.

4.2 Google TV Interface

Your Philips TV is equipped with Google TV, providing a personalized home screen to access movies, shows, and apps from all your subscriptions. Use the Google Assistant for voice search to find content or control your TV. Profiles can be created for customized recommendations.

QLED

自然で美しい画質へ

エンタメ体験のためにうまれた

アニメにおいて、色彩表現はポイントです。

QLEDは、くすみのない発色で、クリアなライン描写を実現しました。




Image: The Google TV home screen showing various streaming applications and content recommendations.

4.3 Chromecast Built-in

The TV includes Chromecast built-in, allowing you to cast content directly from your iPhone or Android devices to the TV screen. Enjoy photos, videos, and games on a larger display.



Pixel Plusエンジン

映像が、奥行きと精細さを増して蘇る



Image: A smartphone and tablet displaying content being cast wirelessly to the Philips Smart TV.

4.4 Picture and Sound Settings

Adjust picture and sound settings to your preference. The TV supports HDR10 for enhanced contrast and Dolby Audio for immersive sound.

- **Picture Modes:** Select from Standard, Vivid, Sports, Movie, Game, and Energy Saving modes to optimize viewing for different content.
- **Sound:** Utilize Dolby Audio for clear and powerful sound.



Image: A visual representation of different picture modes available on the Philips Smart TV, including Standard, User, Vivid, Sports, Movie, Game, and Energy Saving.

4.5 Bluetooth Connectivity

Connect Bluetooth 5.1 compatible devices such as soundbars, speakers, headphones, or wireless earphones for a personalized audio experience.



Image: A person watching the Philips Smart TV with headphones, illustrating Bluetooth 5.1 connectivity for various audio devices.

5. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your TV.

- **Cleaning the Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, use a screen cleaner specifically designed for TVs.
- **Cleaning the Body:** Use a soft, dry cloth to wipe the TV's exterior. Avoid abrasive cleaners or solvents.
- **Software Updates:** Ensure your TV is connected to the internet to receive automatic software updates, which improve performance and add new features.

6. TROUBLESHOOTING

If you encounter issues, refer to the following common solutions:

- **No Power:** Check if the power cable is securely connected to both the TV and the power outlet. Ensure the outlet is functional.
- **No Picture/Sound:** Verify that the correct input source is selected. Check all cable connections (HDMI, AV).
- **Remote Control Not Responding:** Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the TV's IR sensor.
- **Network Connection Issues:** Restart your Wi-Fi router and the TV. Ensure the TV is within range of your Wi-Fi network.

Frequently Asked Questions (FAQ)

- **Q1: Is an internet connection required to use Google TV?**
A1: Yes, an internet connection is required. Please restart the TV after connecting to the internet.
- **Q2: For Chromecast functionality, do all devices need to be on the same wireless network?**
A2: Yes, all devices must be on the same wireless network. Please restart the TV after connecting to the internet.
- **Q3: How do I use the Chromecast feature?**
A3: Android users can use the Google Home app. Apple users can download the VideoCast or Aircscreen app to utilize Chromecast functionality.
- **Q4: What languages does 'OK Google' support?**
A4: 'OK Google' supports over 40 languages. After logging into your Google account, you can set your preferred language for the Google Assistant.

7. SPECIFICATIONS

Feature	Specification
Screen Size	32 inches
Brand	PHILIPS
Display Technology	QLED
Resolution	1080i (HD)
Refresh Rate	60 Hz
Special Features	Chromecast built-in, Google TV, Voice Search
Connectivity Technology	Wi-Fi, Bluetooth 5.1
Aspect Ratio	16:9
Product Dimensions (D x W x H)	6 x 71.6 x 42.4 cm (without stand)
Product Weight (without stand)	3.2 kg
Product Weight (with stand)	3.3 kg
HDR Support	HDR10

Audio Format	Dolby Audio
HDMI Ports	2
USB Ports	2
Model Number	PQT6731

8. WARRANTY AND SUPPORT

8.1 Warranty Information

This Philips product comes with a **1-year manufacturer's warranty** from the date of purchase. In case of product defects under normal use, a free product exchange will be provided. This warranty does not cover malfunctions caused by customer negligence or misuse.

8.2 Customer Support

For any inquiries or support needs, please contact Philips customer service. Our Japanese staff are available to assist you promptly and courteously.

- **Contact Hours:** Monday - Friday, 10:00 - 12:00 and 13:00 - 17:00 (excluding Saturdays, Sundays, public holidays, summer holidays, and New Year holidays).
- If the product arrives damaged or scratched during delivery, please contact us for a free exchange.

PHILIPS



12ヶ月保証

✓ こちらの商品は購入日から、1年間の保証がついています。商品のお届けから、アフターサービスまで、全てにおいてご満足いただけるよう努めております。



**迅速・丁寧
に対応**

🎧 当店ではすべて日本人スタッフが対応しております。何かご不明点等がございましたら、お気軽にお問い合わせください。誠実に対応させていただきます！

Image: Information regarding Philips' 12-month warranty and dedicated customer support.