Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KEGIAN KE-DC76R

KEGIAN Pedestal Fan User Manual

Model: KE-DC76R

Introduction

Thank you for choosing the KEGIAN Pedestal Fan. This manual provides important information regarding the safe operation, assembly, maintenance, and troubleshooting of your new fan. Please read this manual thoroughly before use and retain it for future reference.

Important Safety Instructions

- Read all instructions before using this fan.
- Ensure the power supply voltage matches the rating label on the fan.
- Do not operate the fan with a damaged cord or plug. If damaged, contact qualified service personnel.
- Keep fingers and other objects away from the fan blades and openings during operation.
- Do not use the fan near water or in excessively humid environments.
- Unplug the fan from the power outlet before cleaning or performing any maintenance.
- Place the fan on a stable, level surface to prevent tipping.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

Package Contents

Verify that all components are present in the package:

- 1 x KEGIAN Pedestal Fan Unit
- 1 x Remote Control
- 1 x User Manual (this document)

Product Diagram

Familiarize yourself with the parts of your KEGIAN Pedestal Fan:




Figure 1: Internal components of the fan head, highlighting the brushless DC motor and 5 bionic blades.




Figure 2: Key features including adjustable height, remote control, and ambient light.

Assembly Instructions

The KEGIAN Pedestal Fan is designed for easy assembly. Follow these steps:

1. **Base Attachment:** Place the fan base on a flat surface. Insert the main pole into the base and secure it according to the markings.
2. **Fan Head Attachment:** Carefully attach the fan head unit to the top of the main pole. Ensure it clicks securely into place.
3. **Power Connection:** Plug the power cord into a standard 120V AC electrical outlet.

Your fan is now ready for operation.

Operating Instructions

Control Panel and Remote Control

The fan can be operated using the touch control panel on the unit or the included remote control. The remote control requires 2 AAA batteries (not included).



Figure 3: Fan control panel and remote control layout.

Power On/Off

- Press the **Power** button on the control panel or remote to turn the fan on or off.

Adjusting Fan Speed

The fan offers 16 speed settings.

- Press the **Speed +** or **Speed -** buttons on the control panel or remote to increase or decrease the fan speed.

Selecting Modes

The fan features 4 operating modes:

- **ECO Mode:** Automatically adjusts fan speed based on room temperature to optimize energy consumption.
- **Turbo Mode:** Provides instant maximum airflow for rapid cooling.
- **Sleep Mode:** Operates at progressively quieter speeds for undisturbed rest.
- **Natural Mode:** Simulates a natural breeze by varying fan speeds.
- Press the **Mode** button on the control panel or remote to cycle through the available modes.

Oscillation

The fan offers 120° horizontal and 120° vertical motorized oscillation for wide air distribution.



Figure 4: Fan oscillation range.

- Press the **Oscillation** button on the control panel or remote to activate or deactivate horizontal oscillation.
- Press the **Vertical Oscillation** button (if available on remote) or cycle through oscillation options on the control panel to activate or deactivate vertical oscillation.

Timer Function

Set the fan to automatically turn off after a specified period (1-12 hours).

- Press the **Timer** button on the control panel or remote to set the desired operating duration. Each press increases the timer by 1 hour.

Adjusting Height

The fan's height can be adjusted to suit your needs.

- Loosen the height adjustment knob/collar on the main pole.
- Adjust the pole to the desired height (up to 8.27 inches of adjustment).
- Tighten the knob/collar to secure the fan at the new height.

Ambient Night Lighting

The fan includes an ambient night light feature.

- Press the **Light** button on the control panel or remote to turn the ambient light on or off.

Child Lock

Activate the child lock to prevent unintended operation.

- Press and hold the **Child Lock** button (or indicated combination) on the control panel or remote for a few seconds to activate/deactivate.

Product Overview Video

Your browser does not support the video tag.

Video: An overview of the KEGIAN Pedestal Fan, demonstrating its features and operation.

Maintenance

Regular cleaning helps maintain the fan's performance and extends its lifespan.

- **Cleaning the Exterior:** Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Cleaning the Grille and Blades:** The front grille is removable for easy cleaning. Carefully remove the front grille and wipe the fan blades with a soft cloth. Ensure all parts are dry before reassembling.
- **Storage:** When not in use for extended periods, store the fan in a cool, dry place, preferably in its original packaging.

Caution: Always unplug the fan before cleaning.

Troubleshooting

If you encounter issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply. Power cord not properly plugged in.	Check if the power outlet is working. Ensure the power cord is securely plugged into the outlet and the fan.
Weak airflow.	Fan speed is too low. Grille or blades are dirty.	Increase the fan speed setting. Clean the fan grille and blades as per maintenance instructions.
Fan makes unusual noise.	Loose parts. Obstruction in fan blades.	Check for any loose components and tighten them. Ensure nothing is obstructing the fan blades. If rattling persists at high speeds, refer to the manufacturer for support.
Remote control not working.	Batteries are dead or incorrectly inserted. Obstruction between remote and fan.	Replace batteries with new ones, ensuring correct polarity. Remove any obstacles between the remote and the fan's receiver.
Oscillation not working.	Oscillation function is off.	Press the oscillation button to activate.

Specifications

Feature	Detail
Model Number	KE-DC76R
Brand	KEGIAN
Type	Pedestal Fan / Floor Fan
Power Source	Electric
Voltage	120 Volts (AC)
Wattage	50 watts
Number of Speeds	16
Operating Modes	ECO, Turbo, Sleep, Natural
Oscillation	120° Horizontal, 120° Vertical
Timer	1-12 Hours
Noise Level	20 Decibels
Air Flow Capacity	1200 Cubic Feet Per Minute (CFM)
Max Air Speed	30 Feet Per Second
Product Dimensions (D x W x H)	16"D x 16"W x 42"H
Adjustable Height	Up to 8.27 inches
Control Method	Remote, Touch Panel

Feature	Detail
Material	Acrylonitrile Butadiene Styrene (ABS)
Indoor/Outdoor Usage	Indoor
Certifications	ETL

Warranty and Customer Support

For warranty information or customer support inquiries, please refer to the warranty card included with your purchase or contact KEGIAN directly through their official website or customer service channels. This manual does not contain specific warranty terms or contact details.

© 2026 KEGIAN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GTKFXN1G

More documents and user manuals: **https://manuals.plus/**