

[Manuals.plus](#) /

› [Wellspeed](#) /

› Wellspeed Silent Ceiling Fan with Light and Remote Control, 52 inch White User Manual

Wellspeed 52 inch/132 cm

Wellspeed Silent Ceiling Fan with Light and Remote Control (52 inch/132 cm)

User Manual

1. INTRODUCTION

Thank you for choosing the Wellspeed Silent Ceiling Fan with Light and Remote Control. This manual provides essential information for the safe installation, operation, and maintenance of your new ceiling fan. Please read it thoroughly before use and retain it for future reference.

Key Features:

- **6 Adjustable Speed Settings:** Customize airflow from a gentle breeze to a powerful circulation.
- **3-Color Adjustable Lighting with Dimmable Intensity:** Choose between warm, neutral, and cool light, and adjust brightness to suit your needs.
- **Reversible DC Motor:** Efficient operation for both summer (downward airflow for cooling) and winter (upward airflow for heat distribution).
- **Silent Operation:** Enjoy a peaceful environment with noise levels below 35 decibels.
- **Remote Control:** Conveniently manage all fan and light functions from anywhere in the room.
- **Timer Function:** Set the fan to automatically turn off after 1, 3, or 6 hours.



Image: The Wellspeed ceiling fan providing comfortable airflow with 6 adjustable speeds.

2. IMPORTANT SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Read all instructions carefully before installation and operation.
- Ensure the installation location can support the fan's weight (approximately 6-8 kg).
- All electrical connections must be performed by a qualified electrician and comply with local codes and regulations.
- Turn off power at the circuit breaker before installation or maintenance.
- Do not insert objects into the fan blades while the fan is operating.
- Keep children away from the fan during operation.
- Ensure the fan blades are at least 2.3 meters (7.5 feet) from the floor.
- This fan is designed for indoor use only. For outdoor use, ensure it is installed in a covered patio area to prevent direct exposure to rain.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before proceeding with installation.

- Ceiling Fan Unit (Motor, Blades, Light Kit)
- Remote Control
- Mounting Bracket
- Hardware Kit (screws, wire nuts, etc.)
- User Manual

4. SPECIFICATIONS

Feature	Detail
Brand	Wellspeed
Model	52 inch / 132 cm
Color	White
Product Dimensions (L x W x H)	132L x 132W x 21H centimeters (52L x 52W x 8.3H inches)
Room Type	Bedroom, Living Room, Kitchen, Covered Terrace
Indoor/Outdoor Use	Indoor (Covered Outdoor for Terrace)
Power Source	Electric Corded
Installation Type	Flush Mount / Ceiling Mount
Control Method	Remote Control
Motor Type	Reversible DC Motor
Light Output	Up to 2300 Lumens
Color Temperature	3 adjustable settings (Warm, Neutral, Cool)
Noise Level	Below 35 dB

Feature	Detail
Energy Label	E
Country of Origin	China

Dimensions du produit



Diamètre de travail : 52 pouces / 132 cm

52 pouces désigne le diamètre maximal des pales du ventilateur et du moteur lorsque celui-ci est en marche, et non la taille des pales elles-mêmes.



Dimensions de la pièce

12 x 12 pieds - 18 x 18 pieds

Image: Product dimensions and recommended room sizes (12x12 ft - 18x18 ft).

5. INSTALLATION GUIDE

Professional installation by a qualified electrician is recommended.

Before You Begin:

- Ensure power is OFF at the circuit breaker.
- Gather all necessary tools (screwdriver, wire strippers, ladder, etc.).
- Unpack all components and check against the package contents list.

Step-by-Step Installation:

1. **Mount the Bracket:** Secure the mounting bracket to the ceiling junction box using the provided screws. Ensure it is firmly attached and can support the fan's weight.
2. **Wire Connections:** Connect the fan's electrical wires to your household wiring according to the wiring diagram in the full instruction manual (not included here). Ensure all connections are secure with wire nuts.
3. **Attach the Fan Body:** Carefully lift the fan body and attach it to the mounting bracket. Secure it with the designated screws.
4. **Install Blades:** Attach the fan blades to the motor housing. Ensure they are securely fastened.
5. **Install Light Kit:** Connect the light kit wiring and attach the light cover to the fan body.
6. **Restore Power:** Once installation is complete and all connections are secure, restore power at the circuit breaker.

6. OPERATION GUIDE

Your Wellspeed ceiling fan is operated using the included remote control.

Remote Control Functions:

Télécommande

Profitez d'une utilisation pratique d'un simple geste du doigt



1 à 6 vitesses



Lumière
Marche / Arrêt



Minuterie
(1 h / 3 h / 6 h)



Mode Vent Doux



Réversible



Température de
couleur

Image: Overview of the remote control and its functions.

- **Fan ON/OFF:** Press the fan button to turn the fan on or off.
- **Speed Control (1-6):** Use the '1' to '6' buttons to select desired fan speed. '1' is the lowest, '6' is the highest.
- **Light ON/OFF:** Press the light button to turn the light on or off.
- **Color Temperature Adjustment (WW/NW/DW):** Cycle through Warm White, Neutral White, and Daylight White light temperatures.

- **Brightness Adjustment (+/-):** Increase or decrease the light intensity.
- **Timer (1H/3H/6H):** Set the fan to automatically turn off after 1, 3, or 6 hours.
- **Reversible Function:** Press the reverse button to change the direction of the fan blades.
- **Sleep Mode:** Activates a gentle, quiet fan speed for undisturbed rest.

Reversible Motor Function:

The reversible DC motor allows for year-round comfort.

- **Summer Mode (Counter-clockwise rotation):** Pushes air downwards, creating a cooling breeze.
- **Winter Mode (Clockwise rotation):** Draws warm air upwards, distributing heat evenly throughout the room.

Fonction d'inversion



Image: Reversible function for summer cooling and winter heat circulation.

Lighting Features:

The integrated LED light offers versatile illumination.

- **3 Color Temperatures:** Easily switch between warm (3000K), neutral (4200K), and cool (6500K) lighting.
- **Dimmable:** Adjust the brightness from 20% to 100% to create the perfect ambiance.

- **No Flicker:** Designed for eye comfort, preventing screen flicker and glare.

Plus lumineux que les autres ventilateurs de plafond


Plus de lumens, 3 températures de couleur et intensité réglable



6500K



4200K



3000K

Réglage de l'intensité de 20 % à 100 %



20%



40%



60%



80%



100%

Jusqu'à **2300**
Lumens



Image: Adjustable light with 3 color temperatures and dimming capability up to 2300 lumens.

Pas de scintillement de l'écran

Nous prenons soin de vos yeux



Le nôtre

Autre

Image: The fan's light is designed to be flicker-free for eye comfort.

Silent Operation:

The advanced motor technology ensures quiet performance, ideal for bedrooms and quiet spaces.



Silencieux et Minuterie

Juste le vent, pas un bruit



1 h / 3 h / 6 h

Réglage de la minuterie

30dB ↓

10dB

40dB

60dB

80dB

Feuilles tombantes

Les nôtres

Bibliothèque

Parler

En plein air

Image: Silent operation (below 30dB) and timer function for undisturbed sleep.

7. MAINTENANCE

Regular maintenance helps ensure the longevity and optimal performance of your ceiling fan.

- **Cleaning:** Dust the fan blades and motor housing periodically with a soft, damp cloth. Do not use abrasive cleaners or

solvents.

- **Blade Inspection:** Check the fan blades for any signs of damage or warping. Replace damaged blades immediately.
- **Tighten Screws:** Periodically check and tighten all screws on the fan and mounting bracket to prevent wobbling or noise.
- **Light Source:** The integrated LED light source is designed for long life and is generally not user-replaceable. Contact customer support if the light fails.
- **Power Off:** Always ensure the power is turned off at the circuit breaker before performing any cleaning or maintenance.

8. TROUBLESHOOTING

If you encounter issues with your fan, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Fan does not start	No power; Loose wiring; Remote control battery dead	Check circuit breaker; Verify wiring connections; Replace remote control battery.
Light does not work	Loose wiring; LED failure	Check wiring connections; Contact customer support for LED replacement.
Fan wobbles	Loose mounting screws; Unbalanced blades	Tighten all mounting screws; Ensure blades are securely attached and balanced.
Remote control not working	Battery dead; Remote not paired	Replace battery; Refer to the full manual for remote pairing instructions.
Fan is noisy	Loose screws; Obstruction; Motor issue	Check and tighten all screws; Ensure nothing is obstructing the blades; If noise persists, contact support.

9. WARRANTY & SUPPORT

Warranty Information:

Wellspeed offers a **one-year warranty** on this product. If the ceiling fan fails within one year from the date of purchase due to manufacturing defects, we will replace it. This warranty does not cover damage caused by improper installation, misuse, accidents, or unauthorized modifications.

Customer Support:

For technical assistance, warranty claims, or any questions regarding your Wellspeed ceiling fan, please contact our customer support team. Refer to your purchase documentation for specific contact details or visit the official Wellspeed website.

10. PRODUCT APPLICATIONS

The Wellspeed Silent Ceiling Fan is suitable for various indoor spaces and covered outdoor areas.



Image: Ideal for Kitchens



Chambre

Image: Perfect for Bedrooms



Terrasse

Image: Suitable for Living Rooms



Image: Can be used on Covered Terraces (Note: Install in a covered patio to avoid direct rain exposure).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question