



[Manuals.plus](#) /

> [COSTWAY](#) /

> COSTWAY Outdoor Picnic Table Instruction Manual, Model: Picnic Table

COSTWAY Picnic Table

COSTWAY Outdoor Picnic Table Instruction Manual

Model: Picnic Table

[Contents](#) [Assembly](#) [Introduction](#) [Safety Information](#) [Package](#)
[Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

Thank you for choosing the COSTWAY Outdoor Picnic Table. This manual provides essential information for the safe assembly, operation, and maintenance of your new picnic table. Please read these instructions thoroughly before use and retain them for future reference.

This picnic table is designed for outdoor use, offering a durable and weather-resistant solution for gatherings, meals, and activities in your patio, backyard, garden, or camping site. Constructed from high-density polyethylene (HDPE) and a sturdy steel frame, it is built to withstand various outdoor conditions and provide long-lasting enjoyment.



Figure 1: COSTWAY Outdoor Picnic Table in use.

2. SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the product:

- **Weight Capacity:** Do not exceed the maximum weight capacity of 330 lbs for the tabletop and 550 lbs for the seats. Overloading can cause structural failure and injury.
- **Stable Surface:** Always place the picnic table on a flat, stable, and level surface to prevent tipping.
- **Assembly:** Ensure all components are correctly assembled and all fasteners are securely tightened before use. Regularly check fasteners for tightness.
- **Children:** Supervise children around the picnic table. The smooth, rounded corners are designed for safety, but caution is always advised.
- **Weather Conditions:** While weather-resistant, extreme weather conditions (e.g., strong winds) may require securing or storing the table to prevent damage or displacement.

- **Cleaning:** Use mild soap and water for cleaning. Avoid harsh chemicals or abrasive cleaners that could damage the HDPE material or powder-coated steel frame.
- **Movement:** When moving the table, lift it rather than dragging to prevent damage to the legs or frame.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Tabletop (1)
- Bench Seats (2)
- Table Legs/Frame (2 sets)
- Bench Legs/Frame (2 sets)
- Hardware Pack (Screws, Hex Bolts, Washers, Wrench)
- Assembly Guide (1)



Figure 2: Product dimensions and components overview.

4. ASSEMBLY INSTRUCTIONS

Tools Recommended: Screwdriver (not included), Wrench (included in hardware pack).

Follow these steps carefully for proper assembly:

1. **Attach Legs to Tabletop:** Place the tabletop upside down on a soft, clean surface to prevent scratches. Align the table leg frames with the pre-drilled holes on the underside of the tabletop. Secure them using the provided screws. Tighten with a screwdriver.
2. **Attach Legs to Benches:** Similarly, align the bench leg frames with the pre-drilled holes on the underside of each

bench seat. Secure them using the provided screws.

3. **Connect Table and Bench Frames:** Insert the tabletop support brackets into the pre-drilled holes on the table leg frames. Secure the legs to these brackets using the included hex bolts and washers. Tighten with the provided wrench.
4. **Final Tightening:** Once all connections are made, carefully flip the table upright. Double-check all screws and bolts to ensure they are securely tightened. Do not overtighten.

Supreme HDPE Tabletop & Strong Steel Frame

— Bring a classic picnic table to your patio —



Tough



Weather
resistance



Anti-cracking



Figure 3: Detail of the durable HDPE tabletop and strong steel frame.

5. OPERATION

Your COSTWAY Outdoor Picnic Table is designed for straightforward use in various outdoor settings.

- **Placement:** Choose a flat, stable outdoor location for your picnic table. Ensure there is adequate space around the table for comfortable seating and movement.
- **Seating:** The table is designed to comfortably seat up to 6 people. Distribute weight evenly across the benches.
- **Weight Limits:** Adhere to the specified weight capacities: 330 lbs for the tabletop and 550 lbs for the benches.

Avoid placing excessively heavy items on the table or benches.

- **Versatility:** This table is suitable for various activities such as outdoor dining, family gatherings, board games, or as a workspace in your garden or patio.



Figure 4: The picnic table is versatile for various outdoor spaces.

6. MAINTENANCE

Regular maintenance will help prolong the life and appearance of your picnic table.

- **Cleaning:** The HDPE tabletop and benches are stain-resistant and easy to clean. Wipe spills and dirt immediately with a damp cloth and mild soap. Rinse with clean water and dry thoroughly. Avoid abrasive brushes or harsh chemical cleaners.
- **UV Protection:** The HDPE material is UV-protected to resist fading, peeling, or cracking from sun exposure.
- **Frame Care:** The steel frame is powder-coated for weather resistance. If scratches occur, touch up with rust-inhibiting paint to prevent corrosion.

- **Fastener Checks:** Periodically inspect all screws and bolts for tightness. Re-tighten as necessary to maintain stability.
- **Storage:** During prolonged periods of non-use or in harsh winter conditions, consider storing the table indoors or covering it with a protective outdoor furniture cover to extend its lifespan.



Figure 5: Features highlighting easy cleaning, wood texture, and safety.

7. TROUBLESHOOTING

If you encounter any issues with your picnic table, refer to the following common solutions:

Problem	Possible Cause	Solution
Table feels wobbly or unstable.	Uneven ground; loose fasteners.	Move the table to a flat, level surface. Check and tighten all screws and bolts.

Problem	Possible Cause	Solution
Difficulty assembling parts.	Incorrect alignment; missing hardware.	Review assembly instructions carefully. Ensure parts are oriented correctly. Verify all hardware is present. Contact customer support if parts are missing.
Stains on tabletop/benches.	Spills not cleaned promptly.	Wipe immediately with a damp cloth and mild soap. For stubborn stains, a soft brush may be used gently.
Rust spots on frame.	Damage to powder coating; prolonged exposure to moisture.	Clean the area, sand lightly if necessary, and apply rust-inhibiting paint. Store in a dry area or cover during wet seasons.

8. SPECIFICATIONS

Feature	Detail
Brand	COSTWAY
Model Name	Picnic Table
Overall Dimensions (L x W x H)	54" x 59" x 28.5"
Table Dimensions (L x W x H)	54" x 28" x 28.5"
Seat Dimensions (L x W x H)	54" x 10" x 17"
Tabletop Thickness	2"
Material	High-Density Polyethylene (HDPE) tabletop/benches, Steel frame
Table Weight Capacity	330 lbs
Seat Weight Capacity	550 lbs
Net Weight	48 lbs
Seating Capacity	Up to 6 people
Color	Green (as per current variant)
Assembly Required	Yes
Indoor/Outdoor Usage	Outdoor



Figure 6: Seating capacity and weight limits.

9. WARRANTY & SUPPORT

COSTWAY products are designed for quality and durability. For specific warranty information, please refer to the documentation included with your purchase or visit the official COSTWAY website.

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact COSTWAY customer support through their official channels. Please have your model number and purchase details ready when contacting support.

Contact Information: Please refer to your purchase receipt or the COSTWAY official website for the most current customer service contact details.



