

## YESHOMY B0GTLTJH2

# YESHOMY Modern TV Stand 48-inch Instruction Manual

Model: B0GTLTJH2

## INTRODUCTION

This manual provides essential information for the assembly, operation, and maintenance of your YESHOMY Modern TV Stand. Designed to accommodate televisions up to 55 inches, this media console features 8 open shelves with adjustable height levels, offering versatile storage solutions for your living space. Please read these instructions carefully before beginning assembly and retain them for future reference.

## SAFETY INFORMATION

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all parts are securely fastened before use. Periodically check and re-tighten fasteners as needed.
- Do not exceed the maximum weight capacity of 150 lbs (68 kg) for the top surface.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Use caution when moving the assembled unit to prevent injury or damage.

## PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Top Panel
- Bottom Panel
- Side Panels

- Adjustable Shelves
- Back Panels
- Legs and Mounting Hardware
- Assembly Hardware (screws, cam locks, dowels, etc.)
- Assembly Tool (Allen wrench, screwdriver)

## ASSEMBLY INSTRUCTIONS

---

Assembly typically takes approximately 30-40 minutes. It is recommended to have two people for easier and safer assembly. Do not use power tools for assembly as this may overtighten and damage the wood.

1. **Identify All Parts:** Lay out all panels and hardware. Match them with the provided parts list and diagrams in your physical manual.
2. **Assemble the Main Frame:** Attach the side panels to the bottom panel using the specified hardware (e.g., cam locks and dowels). Ensure they are aligned correctly.
3. **Install Adjustable Shelves:** Insert the shelf pins into the desired height holes on the side panels. Place the adjustable shelves onto these pins.
4. **Attach the Top Panel:** Secure the top panel to the assembled frame using the remaining hardware.
5. **Secure Back Panels:** Fasten the back panels to the rear of the unit using small nails or screws.
6. **Attach Legs:** Mount the support legs to the bottom of the TV stand using the provided screws.

*For detailed step-by-step diagrams, please refer to the printed assembly guide included with your product.*

## FEATURES AND USAGE

---



This image illustrates the versatility of the YESHOMY TV Stand, showcasing its use as both a shoe organizer in an entryway and a media console in a living room, highlighting its adaptable cube design.



This image demonstrates the TV stand's functionality as a general storage unit, featuring decorative baskets, books, and other items within its open shelves, emphasizing its capacity for organization.

The YESHOMY Modern TV Stand is designed for optimal functionality and aesthetic appeal. It features 8 open cube storage spaces, ideal for organizing various items.

- **Adjustable Shelves:** Three adjustable height levels allow you to customize the internal space of the cubes to fit different sized items, such as books, media devices, or decorative pieces.
- **Cable Management:** Integrated cable management openings in the back panels help keep wires organized and out of sight, maintaining a clean and tidy entertainment area.
- **Versatile Storage:** The open shelves are perfect for gaming consoles, streaming devices, speakers, and other accessories. The design also allows for use as a bookcase or display cabinet.

Your browser does not support the video tag.

This video provides a visual overview of the YESHOMY Modern TV Stand, highlighting its aesthetic design, storage capabilities, and practical features like cable management. It showcases the product in a home setting, demonstrating its versatility and modern appeal.

## MAINTENANCE

---

# Water-Resistant & Easy to Clean

The smooth, waterproof top surface protects against spills and stains. Simply wipe clean—ideal for plants, drinks, and daily use.



This image demonstrates the water-resistant and easy-to-clean surface of the TV stand, showing a hand wiping away a spilled drink, indicating simple maintenance.

To ensure the longevity and appearance of your TV stand, follow these maintenance guidelines:

- **Cleaning:** Wipe the surface with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish. The water-resistant top surface allows for easy cleanup of spills.
- **Dusting:** Regularly dust with a dry, soft cloth.
- **Protection:** Use coasters under drinks and protective pads under heavy or sharp objects to prevent scratches and stains.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.

## TROUBLESHOOTING

If you encounter any issues with your TV stand, refer to the following common problems and solutions:

- **Wobbling/Instability:** Ensure all screws and fasteners are tightened. Check that the unit is placed on a level surface.
- **Scratches/Dents:** Minor scratches can sometimes be touched up with a furniture repair marker matching the finish. For significant damage, contact customer support.

- **Difficulty Assembling:** Re-read the assembly instructions carefully. Ensure all parts are correctly oriented before tightening. Do not force parts together.

## SPECIFICATIONS



This image provides a visual representation of the TV stand's overall dimensions and its maximum weight capacity for televisions.

Feature	Detail
Overall Dimensions (W x D x H)	47.6 x 11.5 x 24 inches
Each Cube Open Storage Partition (W x D x H)	11.1 x 11 x 11.8 inches
Maximum TV Size Supported	Up to 55 inches
Weight Capacity (Top Surface)	150 lbs (68 kg)
Material	Wood
Color	Black

Item Weight	46.56 Pounds
Assembly Required	Yes

## Product Dimensions



This detailed diagram provides all key measurements of the TV stand, including overall width, depth, height, and individual shelf dimensions.

### WARRANTY AND SUPPORT

Your YESHOMY TV Stand comes with a standard manufacturer's warranty against defects in materials and workmanship. For specific warranty details, claims, or technical support, please refer to the warranty card included in your package or contact YESHOMY customer service directly. Please have your model number (B0GTLLTJH2) and purchase date available when contacting support.