

[Manuals.plus](#) /

> [OSRAM](#) /

> OSRAM LED Ceiling Fan Brisote 1060mm 66W CCT User Manual

OSRAM Brisote 1060mm 66W CCT

OSRAM LED Ceiling Fan Brisote 1060mm 66W CCT User Manual

Model: Brisote 1060mm 66W CCT

1. INTRODUCTION

This manual provides essential information for the safe installation, operation, and maintenance of your OSRAM LED Ceiling Fan Brisote 1060mm 66W CCT. Please read these instructions carefully before use and retain them for future reference.

2. SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Ensure the power supply is disconnected before installation or maintenance.
- Installation must be performed by a qualified electrician.
- Do not operate the fan with a damaged cord or plug.
- Keep hands, hair, and clothing away from moving fan blades.
- This product is designed for indoor use only (IP20 rating).
- The light source in this product is of energy class E.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before proceeding with installation.

- 1x OSRAM LED Ceiling Fan Brisote 1060mm 66W CCT
- 1x Remote Control (batteries not included)
- Mounting hardware (screws, etc.)
- User Manual (this document)



Figure 3.1: OSRAM LED Ceiling Fan Brisote 1060mm 66W CCT.

4. SETUP AND INSTALLATION

This ceiling fan is designed for ceiling mounting. While the product specification states "Assembly required: No", professional installation by a qualified electrician is recommended to ensure safety and proper functionality.

4.1 Pre-Installation Checks

- Ensure the ceiling structure can support the weight of the fan (6.3 kg).
- Verify that the electrical wiring at the installation site is compatible with the fan's requirements (220 Volts AC).
- Turn off the main power supply at the circuit breaker before beginning any electrical work.

4.2 Mounting the Fan

Follow the detailed instructions provided in the separate installation guide (if included) for mounting the fan to the ceiling. Ensure all connections are secure and properly insulated.

4.3 Remote Control Setup

Insert AAA batteries (not included) into the remote control unit. Ensure correct polarity. The remote control is pre-paired with the fan.

5. OPERATING INSTRUCTIONS

The OSRAM Brisote ceiling fan is controlled via the included remote control. Familiarize yourself with the remote's functions for optimal use.



Figure 5.1: Remote control functions for light and fan speed.

5.1 Fan Operation

- **Power On/Off:** Press the fan power button on the remote to turn the fan on or off.
- **Fan Speed:** Use the speed buttons (1-6) to adjust the airflow. The fan offers 6 speed levels, providing a maximum airflow of 6460 m³/h.
- **Retractable Blades:** The fan blades automatically extend when the fan is turned on and retract when turned off, giving the appearance of a ceiling lamp when not in use.
- **Seasonal Modes (Summer/Winter):**




Figure 5.2: Summer and Winter operation modes.

- **Summer Mode:** Press the "Summer" button. Blades rotate counter-clockwise, creating a downward breeze for cooling.

- **Winter Mode:** Press the "Winter" button. Blades rotate clockwise, circulating warm air downwards without creating a direct draft.
- **Timer Function:** Set the fan to turn off automatically after 1, 2, 4, or 8 hours using the timer buttons.
- **Breeze Mode:** Activate the "Breeze" mode for a natural, fluctuating airflow simulation.

5.2 Light Operation

- **Light On/Off:** Press the light power button on the remote to turn the light on or off.
- **Color Temperature (CCT) Adjustment:** The light offers three color temperature settings: 3000K (Warm White), 4000K (Neutral White), and 6500K (Cool White). Cycle through these settings by pressing the CCT button.
- **Dimming:** Use the dimming buttons (DIM+ / DIM-) to adjust the brightness of the light. The maximum luminous flux is 2600 lumens.




Figure 5.3: Integrated LED light and retractable fan blades.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

- **Cleaning:** Disconnect power before cleaning. Use a soft, damp cloth to wipe the fan housing and blades. Do not use abrasive cleaners or solvents.
- **Blade Cleaning:** Periodically clean dust from the fan blades to maintain airflow efficiency.
- **Inspection:** Annually inspect all connections and mounting hardware for tightness.
- **Light Source:** The LED light source is integrated and designed for a long lifespan (20,000 hours). It is not user-replaceable.

7. TROUBLESHOOTING

If you encounter issues with your OSRAM LED Ceiling Fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not operate.	No power supply. Remote control batteries are dead. Incorrect wiring.	Check circuit breaker. Replace remote control batteries. Consult a qualified electrician.

Problem	Possible Cause	Solution
Light does not turn on.	No power supply. Remote control batteries are dead. LED light source failure.	Check circuit breaker. Replace remote control batteries. Contact customer support if within warranty.
Fan makes excessive noise.	Loose mounting screws. Blades are unbalanced. Obstruction.	Tighten all mounting screws. Ensure blades are clean and free of debris. Check for any objects interfering with blade rotation.
Remote control not working.	Dead batteries. Obstruction between remote and fan. Remote not paired (unlikely for this model).	Replace batteries. Ensure clear line of sight. Refer to specific pairing instructions if available (not typically needed for pre-paired units).

8. SPECIFICATIONS

Feature	Detail
Brand	OSRAM
Model Name	Ceiling fan Brisote 1060mm 66W CCT
Model Number	4058075857834
Color	White
Material	Steel
Dimensions (L x W x H)	106L x 106W x 38H cm
Diameter	106 cm (1060 mm)
Product Weight	6.3 kg (6300 Grams)
Power (Fan + Light)	66 Watts
Voltage	220 Volts AC
Luminous Flux	2600 Lumens (max)
Color Temperature (CCT)	3000K / 4000K / 6500K (selectable)
Beam Angle	116°
Lifespan (LED)	20,000 hours
Airflow (max)	6460 m³/h
Control Method	Remote Control
IP Rating	IP20 (Indoor use only)
Energy Efficiency Class (Light Source)	E

Feature	Detail
Assembly Required	No (Professional installation recommended)
Country of Origin	China
Manufacturer	LEDVANCE

9. WARRANTY AND SUPPORT

Specific warranty details for your OSRAM LED Ceiling Fan Brisote are typically provided with your purchase documentation or can be found on the official OSRAM website. For technical support, service, or warranty claims, please refer to the contact information provided by your retailer or the manufacturer's official support channels.

Please retain your proof of purchase for any warranty claims.