

[Manuals.plus](#) /

› [YITAHOME](#) /

› YITAHOME 240 Gallon Large Outdoor Storage Box Instruction Manual

YITAHOME MAYIHpQ0KT

YITAHOME 240 Gallon Large Outdoor Storage Box Instruction Manual

Model: MAYIHpQ0KT

[Overview](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty &](#)

[Support](#)

PRODUCT OVERVIEW

The YITAHOME 240 Gallon Large Outdoor Storage Box is designed to provide a robust and versatile storage solution for your outdoor spaces. Constructed from heavy-duty, weather-resistant resin, this deck box is built to endure various elements while maintaining its appearance.



THE MAGIC OF STORAGE

Image: The YITAHOME 240 Gallon Large Outdoor Storage Box, showcasing its spacious design and black resin finish in a garden setting.

Key Features:

- **Durable Construction:** Made from UV-protected, weather-resistant resin that resists fading, cracking, and flaking, ensuring longevity.
- **Smooth & Safe Access:** Features a hydraulic piston lid for effortless opening and soft closing, preventing accidental slams.
- **Versatile Storage:** Offers a large 240-gallon capacity, suitable for gardening tools, outdoor cushions, pool supplies, and more. Can also serve as extra seating.
- **Enhanced Security:** Includes a built-in lockable latch for securing your belongings. A lock is provided for immediate use.
- **Simple Assembly:** Designed for quick and straightforward assembly, typically completed within 30 minutes.

SETUP INSTRUCTIONS

Assembly

The YITAHOME 240 Gallon Large Outdoor Storage Box is designed for easy assembly with minimal parts. Please refer to the included assembly guide for detailed, step-by-step instructions specific to your product. Ensure all components are present before beginning assembly.

Setting Your Lock Password

Your storage box includes a combination lock for added security. Follow these steps to set your personalized password:

1. The initial password is 000. Align this code with the scale line on the lock body. Press the button on the top with your hand, and the locking beam will pop up, allowing you to open it.
2. With the lock open, use a metal object (like a pen tip) to forcefully press the code-adjusting hole at the bottom until it is in a sunken state. Do not release it.
3. While holding the metal object in place, turn the number dials to set your desired new password.
4. Release the metal object. The operation is now complete, and your new password is set.

HOW TO SET YOUR LOCK PASSWORD



1. The initial password is 000. Align with the scale line of the lock body. Press the butt on on the top with your hand, and the locking beam will pop up, then you can open it.



2. Use metal to forcefully press against the code - adjusting hole at the bottom until it is in a sunken state, and do not release it.



3. Use metal to press against the lock - hole at the bottom while turning the numbers to set the password you need.



4. Just release the metal that is propping against the bottom, and then the operation will be completed.

Image: A visual guide demonstrating the four steps to set or reset the combination lock password.

OPERATING INSTRUCTIONS

Opening and Closing the Lid

The storage box lid is equipped with hydraulic pistons for smooth and safe operation. To open, simply lift the lid gently; the pistons will assist in raising it. To close, pull the lid down; the pistons will ensure a soft, controlled descent, preventing sudden drops.



Image: A detailed view of the hydraulic piston that assists in opening and closing the lid smoothly.

Using the Lock

To secure your belongings, close the lid and engage the combination lock. Ensure the locking beam is properly inserted into the latch. Scramble the numbers on the lock to secure it. To unlock, dial your set password and press the top button to release the locking beam.

Repositioning the Storage Box

The storage box features built-in side handles for easy repositioning. When moving the box, ensure the lid is closed and secured. Lift using the side handles and move to the desired location. For heavy loads, it is recommended to empty the box before moving or seek assistance.

MAINTENANCE

Cleaning

To clean your YITAHOME storage box, wipe it down with a damp cloth and a mild soap solution. Rinse thoroughly with water and dry with a soft cloth. Avoid using abrasive cleaners, harsh chemicals, or stiff brushes, as these can damage the resin surface.

Weather Protection

The storage box is constructed from weather-resistant and UV-protected resin. While designed for outdoor use, regular cleaning and occasional inspection for any wear can help maintain its condition. Ensure the lid is properly closed during inclement weather to protect contents.



THE ADVENTURE AWAITS AND YOUR STUFF IS SAFE

No matter the weather, it ensures your equipment stays dry and protected.

Image: The YITAHOME storage box depicted in a stormy, ocean-like setting with rain, illustrating its weather-resistant properties.

TROUBLESHOOTING

Water Leakage

If you experience water leakage, check the following:

- **Lid Alignment:** Ensure the lid is properly aligned and fully closed. Uneven surfaces or obstructions can prevent a complete seal.
- **Assembly:** Verify that all panels and components were assembled correctly and securely according to the instruction manual. Gaps in assembly can lead to water ingress.
- **Seals:** Inspect any rubber seals or weatherstripping for damage or displacement.

Lid Not Closing Properly or Warping

If the lid does not close flat or appears warped:

- **Even Surface:** Ensure the storage box is placed on a flat, level surface. Uneven ground can cause the box frame to twist, affecting lid closure.
- **Overfilling:** Avoid overfilling the box, as contents can obstruct the lid's closing mechanism.
- **Extreme Conditions:** While weather-resistant, prolonged exposure to extreme heat or direct sunlight without proper ventilation can potentially affect resin products. Consider placement in partially shaded areas if possible during intense heat.

Lock Malfunction

If the combination lock is not working:

- **Correct Combination:** Double-check that you are entering the correct combination.
- **Reset Procedure:** If you forgot the combination or it's not working, follow the "Setting Your Lock Password" instructions to reset it.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	YITAHOME
Model Number	MAYIHpQ0KT
Color	Black
Material	Resin
Item Dimensions (L x W x H)	62.8"L x 30.1"W x 27.1"H
Storage Volume	240 Gallons
Item Weight	50.5 pounds
Maximum Weight Recommendation	660 pounds
Special Features	Built-In Handle, Lockable, Rust Resistant, Scratch Resistant, Weathertight
Water Resistance Level	Waterproof
Opening Mechanism	Lift-Off Lid with Hydraulic Pistons



Image: A diagram detailing the external dimensions (62.8"L x 30.1"W x 27.1"H), weight capacity (660 LBS), storage space (240 GALLON), and internal dimensions (60.8" x 27.7" x 26") of the storage box, along with close-ups of the wicker weaving and armrest design.

WARRANTY AND SUPPORT

Warranty Information

YITAHOME provides a **5-year parts warranty** for this product. This warranty covers manufacturing defects and material flaws under normal use. Please retain your proof of purchase for any warranty claims.

Customer Support

For any questions, assistance with assembly, troubleshooting, or warranty claims, please contact YITAHOME customer support. Our team is available to assist you.

- **Chat with Us:** Visit the official YITAHOME website for live chat support.

- **Call Us:** Refer to your product packaging or the YITAHOME website for contact phone numbers.
- **Email Us:** Send your inquiries to the customer support email address found on the YITAHOME website.

© 2026 YITAHOME. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question