

[Manuals.plus](#) /

› [MEGAWHEELS](#) /

› MEGAWHEELS EB01 Electric Bike Instruction Manual

MEGAWHEELS EB01

MEGAWHEELS EB01 Electric Bike Instruction Manual

Model: EB01 | Brand: MEGAWHEELS

INTRODUCTION

The MEGAWHEELS EB01 Electric Bike is engineered for adults seeking a high-performance, versatile, and reliable riding experience. Featuring a powerful 1500W peak motor, a long-range 48V 15.6Ah removable battery, and 20-inch all-terrain fat tires, this e-bike is designed to conquer various landscapes from city streets to rugged trails. With a 7-speed Shimano shifter, 6-level suspension system, and dual disc brakes, it offers a smooth, safe, and controlled ride. This manual provides essential information for assembly, operation, maintenance, and safety to ensure optimal performance and longevity of your EB01 electric bike.

WHAT'S IN THE BOX

Your MEGAWHEELS EB01 Electric Bike package includes the following components:

- E-Bike (85% pre-assembled)
- Removable 48V 15.6Ah Battery
- 54V 2A Charger
- Assembly Tools
- Instruction Manual
- Pedals (metal)
- Front Brake Rotor
- Headlight




Image: All components neatly packaged within the box, including the partially assembled bike, battery, charger, and tools.

SETUP AND ASSEMBLY

Your EB01 electric bike arrives 85% pre-assembled, requiring minimal setup to get you riding. Follow these steps for final assembly:

- 1. Unpacking:** Carefully remove all components from the box. Inspect for any damage during transit.
- 2. Tire Inflation:** Inflate the 20"x4.0" fat tires to the recommended pressure (ensure beads are seated correctly).
- 3. Front Brake Rotor Installation:** Attach the front brake rotor to the front wheel using the provided tools.
- 4. Front Wheel Installation:** Securely install the front wheel onto the bike's front fork.
- 5. Handlebar Adjustment:** Adjust the handlebar to a comfortable riding position and tighten all bolts.
- 6. Headlight Installation:** Mount the headlight to the front of the bike and connect its cable.
- 7. Pedal Installation:** Attach the metal pedals to the crank arms, ensuring they are tightened securely.
- 8. Battery Insertion:** Insert the removable battery into its designated slot on the frame and lock it with the provided key.

Your browser does not support the video tag.

Video: Step-by-step guide on how to install the MEGAWHEELS EB01 electric bike.

KEY FEATURES

The MEGAWHEELS EB01 is equipped with advanced features for an enhanced riding experience:

Powerful 1500W Peak Motor

Experience robust torque and acceleration with the 750W (1500W peak) brushless motor, capable of conquering 30° inclines. The bike can reach speeds of up to 33 MPH (after unlocking).




Image: Diagram illustrating the powerful 1500W brushless motor and its components.

Long-Range 48V 15.6Ah Removable Battery

The UL 2849 certified battery provides a range of up to 75 miles (PAS) or 40 miles (Pure Electric) on a single charge. It features IP54 waterproofing, a secure key lock, and a BMS for safety and efficiency. Fast charging takes 5-7 hours.



Image: Close-up view of the removable 48V 15.6Ah battery integrated into the bike frame.

20-inch All-Terrain Fat Tires & 6-Level Suspension

Conquer any surface with 20"x4.0" puncture-resistant fat tires and a sophisticated 6-level suspension system that absorbs bumps for a smooth ride.

SMOOTH GEAR TRANSITIONS(7-Speed)

From novice to expert cyclist,
discover a gear shift that seamlessly adapts to your riding rhythm.




Image: Illustration highlighting the 6-level suspension system designed to smooth out bumps.

Dual Disc Braking System

The dual disc brakes provide precision modulation and instant stopping power, ensuring maximum safety in all conditions.



Image: Visual representation of the dual disc braking system on the front and rear wheels.

3 Riding Modes & 7-Speed Shifter

Choose from 3 riding modes (Bike, Assisted, Throttle) and utilize the professional 7-speed shifter for precise speed control and adaptability to various terrains.

Real-Time Smart Display

Max speed is 19-20 mph before speed limit is lifted,

Max speed is 32-33 mph after speed limit is lifted



Image: Infographic showing the three distinct riding modes: Bike, Assisted Riding, and Throttle Mode.

SMOOTHES OUT EVERY BUMP

Equipped with a robust suspension system, whether descending stairs, crossing rough terrain, or climbing gravel slopes, effectively absorbs shocks to ensure a comfortable ride.




Image: Close-up of the 7-speed Shimano gear shifter for smooth transitions.

Smart LCD Display & 360° Lighting

The smart LCD provides real-time tracking of speed, battery status, and PAS strength. Ultra-bright LED headlights and a responsive taillight ensure full visibility for night riding.

3 RIDING MODES

Meet Different Needs



BIKE MODE

Power off, normal biking just pedaling



ASSISTED RIDING

Power on with throttle



THROTTLE MODE

Just throttle no need to pedal



Image: The smart LCD display showing speed, battery, and assist levels.

FRONT LIGHTS AND REAR LIGHTS

Safe riding around the clock, thanks to lights that brighten your path and enhance your visibility.



Image: The bright LED headlight and taillight for enhanced safety and visibility.

OPERATING INSTRUCTIONS

Turning On the E-bike

To power on your MEGAWHEELS EB01, insert the key into the ignition and turn it. Then, press and hold the 'M' button on the display unit until the screen illuminates.

Your browser does not support the video tag.

Video: Demonstration of how to turn on the MEGAWHEELS EB01 electric bike.

Removing the Speed Limit

The EB01 has a factory default speed limit. To remove it: Turn on the battery and ignition key. Hold the left brake lever, press and hold the 'M' button to turn on the display, then twist the throttle to the maximum. Release the brake lever to remove the speed limit. Repeat these steps to restore the speed limit. For a visual guide, refer to the instructional video.

Your browser does not support the video tag.

Video: Detailed instructions on how to remove the speed limit on your EB01 electric bike.

SPECIFICATIONS

Feature	Detail
Bike Type	Electric Bike, Fat Tire Electric Bike
Motor	1500W Peak (750W Rated) Brushless Motor
Max Speed	33 MPH (*After unlocking), 20 MPH (Default)
Battery	48V 15.6Ah Removable, UL 2849 Certified, IP54 Waterproof
Range	Up to 75 miles (PAS), 40 miles (Pure Electric)
Charging Time	5-7 hours
Tires	20" x 4.0" Puncture-Resistant All-Terrain Fat Tires
Suspension	6-level Suspension System
Brakes	Front and Rear Dual Disc Brakes
Gears	7-Speed Shimano Shifter
Riding Modes	3 (Bike, Assisted Riding, Throttle)
Display	Smart LCD Display
Lighting	Ultra-bright LED Headlights, Taillight
Frame Material	High Carbon Steel
Max Load Capacity	330 lbs
Recommended Height	5.5-6.5 ft
Item Weight	76 Pounds

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your EB01 electric bike:

- **Tire Pressure:** Check tire pressure regularly and maintain it within the recommended range for optimal performance and safety.
- **Brake Inspection:** Periodically inspect brake pads and rotors for wear. Adjust or replace as needed to ensure effective stopping power.
- **Battery Care:** Charge the battery fully after each ride. Avoid completely draining the battery to prolong its lifespan. Store the battery in a cool, dry place.
- **Chain Lubrication:** Keep the chain clean and lubricated to ensure smooth gear shifts and prevent rust.
- **Fastener Check:** Regularly check all bolts, nuts, and fasteners for tightness. Tighten any loose components to prevent accidents.
- **General Cleaning:** Clean the bike regularly with a damp cloth. Avoid using high-pressure water jets directly on electrical components.

TROUBLESHOOTING

If you encounter any issues with your EB01 electric bike, refer to the following common troubleshooting tips:

- **Bike Not Powering On:** Ensure the battery is fully charged and properly seated in the frame. Check that the ignition key is turned to the 'ON' position and the display is activated.
- **Motor Not Assisting:** Verify that the pedal assist level is set above '0' on the display. Check for any error codes on the LCD. Ensure the brake levers are not partially engaged.
- **Reduced Range:** This could be due to low tire pressure, riding in higher assist modes, or riding against strong headwinds. Ensure tires are properly inflated and consider using lower assist levels.
- **Brakes Squealing:** This may indicate dirty brake pads or rotors, or misaligned calipers. Clean the brake components or have them inspected by a professional.
- **Unusual Noises:** Inspect the chain, gears, and wheels for any obstructions or loose parts. Lubricate the chain if it sounds dry.

For further assistance, please contact our 24/7 expert support team.

WARRANTY AND SUPPORT

Your MEGAWHEELS EB01 Electric Bike is backed by a **1-Year Limited Warranty**. This warranty covers manufacturing defects and ensures your electric bike stays adventure-ready.

Our US-based technical support team is available **24/7** to assist with any maintenance questions, part replacements, or technical issues you may encounter. Please refer to your purchase documentation for specific warranty terms and contact information.