Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

FABULETTA ZWQL6I0A83O849I9UJB9VZ27

FABULETTA Dust Bags for Samsung Bespoke Jet Clean Station VCA-ADB95B User Manual

1. Introduction

This manual provides essential information for the proper use and maintenance of your FABULETTA Dust Bags, designed for compatibility with Samsung Bespoke Jet Clean Station models VCA-ADB95B, VS20B95, VS25C, and VS28C series vacuums. Please read these instructions carefully to ensure optimal performance and longevity of your vacuum system.

2. Safety Information

- Always ensure the vacuum cleaner is unplugged from the power outlet before installing or replacing dust bags.
- Keep packaging materials away from children.
- Do not attempt to wash or reuse disposable dust bags.

3. Product Overview

The FABULETTA Dust Bags are high-quality replacement bags designed to fit specific Samsung Bespoke Jet Clean Station models. Each bag is crafted from durable materials to efficiently capture dust and debris, preventing harmful particles from re-entering the environment. This package contains 5 dust bags.



Image: Front view of a single FABULETTA Dust Bag, showing the opening and pull tab.

The dust bag features a secure sealing mechanism to contain collected dust effectively.

4. Installation (Replacing the Dust Bag)

Follow these steps to replace the dust bag in your Samsung Bespoke Jet Clean Station:

1. Ensure the Clean Station is powered off and unplugged from the electrical outlet.
2. Open the Clean Station's dust bag compartment. Refer to your Samsung Clean Station's user manual for specific instructions on accessing this compartment.
3. Carefully remove the full dust bag from the compartment. Most bags have a sealing mechanism that closes automatically upon removal to prevent dust leakage.
4. Dispose of the used dust bag responsibly according to local regulations.
5. Unpack a new FABULETTA Dust Bag.
6. Align the new dust bag with the slot in the Clean Station's compartment. Ensure the bag is fully inserted and securely seated.
7. Close the dust bag compartment door firmly until it clicks into place.
8. Plug in and power on your Clean Station.



Image: Angled view of a single FABULETTA Dust Bag, illustrating the connection point for installation.

5. Operating

Once installed, the dust bag operates automatically as part of your Samsung Bespoke Jet Clean Station's cleaning cycle. The Clean Station will transfer dust from your vacuum's dustbin into the installed dust bag, providing a hygienic and efficient disposal solution.

6. Maintenance (When to Replace)

For optimal performance and hygiene, it is recommended to replace the dust bag every 2 to 3 months, or when the 'bag full' indicator on your Samsung Bespoke Jet Clean Station illuminates. Regular replacement ensures efficient dust collection and prevents strain on your vacuum's motor, maintaining peak performance.



Image: A pack of five FABULETTA Dust Bags, with close-up views of the bag's top and connection port, highlighting the design for easy replacement.

7. Troubleshooting

- **Reduced Suction/Inefficient Dust Collection:** Ensure the dust bag is correctly installed and not overfilled. If the bag is full, replace it. Check for any obstructions in the Clean Station's dust transfer path.
- **'Bag Full' Indicator Remains On After Replacement:** Verify that the new bag is fully seated and the compartment door is securely closed. If the issue persists, consult your Samsung Clean Station's user manual.

8. Specifications

Product Name	FABULETTA Dust Bags

Compatibility	Samsung Bespoke Jet Clean Station VCA-ADB95B, VS20B95, VS25C, VS28C series vacuums
Bag Model Numbers	VCA-ADB95B, DJ67-00913B
Package Contents	5 Dust Bags
Recommended Replacement	Every 2-3 months or when indicator shows full
Item Weight	6.5 ounces
Product Dimensions	4.72 x 4.72 x 4.72 inches (per bag, approximate)

9. Warranty and Support

For warranty information or product support, please contact FABULETTA customer service through the retailer where the product was purchased or visit the official FABULETTA website. Please have your purchase receipt and product model number (ZWQL6I0A83O849I9UJB9VZ27) available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GTRQGCST

More documents and user manuals: **https://manuals.plus/**