

[Manuals.plus](#) /

› [WACASA](#) /

› WACASA HDPE Pool Lounge Chairs (Model B0GTV7RMX8) Instruction Manual

WACASA B0GTV7RMX8

WACASA HDPE Pool Lounge Chairs Instruction Manual

Model: B0GTV7RMX8

[Safety Information](#)

[Setup](#)

[Operation](#)

[Maintenance
Support](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty &](#)

1. SAFETY INFORMATION

Always follow the assembly instructions carefully. Do not exceed the maximum weight capacity of 450 lbs. Keep the chair on a stable, level surface to prevent tipping.

2. SETUP AND ASSEMBLY

The WACASA HDPE Pool Lounge Chairs are designed for easy assembly, typically taking less than 20 minutes for one person. All necessary tools and pre-drilled, labeled parts are included.

2.1 Unpacking

Carefully remove all components from the packaging. Verify that all parts are present according to the parts list provided in your package. If any parts are missing or damaged, please contact customer support.

2.2 Assembly Steps

Follow these steps for quick assembly:

1. Attach legs with screws.
2. Tighten screws using the provided tool.
3. Insert backrest into the seat frame.
4. Secure armrests to the sides using bolts.
5. Attach casters (wheels) to the base.

For a visual guide, refer to the assembly video below.



Figure 1: Product Dimensions and Weight Capacity.

75% ASSEMBLED

8 PARTS 1 PERSON 25 MINS



EASY TO INSTALL



STEP 1



STEP 2



STEP 3



STEP 4

Figure 2: Easy Assembly Steps.

Your browser does not support the video tag.

Video 1: Quick Assembly Instruction. This video provides a detailed visual guide for assembling your WACASA pool lounge chair.

3. OPERATION

3.1 Adjusting the Backrest

The lounge chair features a 6-position adjustable backrest. To adjust, lift the backrest slightly and move it to your desired angle. Ensure it locks securely into place before use. The positions range from approximately 110° (relaxed) to 180° (flat for sleeping).



Figure 3: 6-Position Adjustable Backrest.

Your browser does not support the video tag.

Video 2: Green comfort, 6 angles. Your outdoor escape. This video demonstrates the 6-position adjustable backrest feature.

3.2 Using the Wheels

The integrated wheels allow for easy repositioning of the chair. Simply tilt the chair slightly on its wheels and roll it to your desired location. Avoid dragging the chair without using the wheels to prevent damage.



Enjoy a coolness summer
Ultimate comfort

Figure 4: Effortless Movement with Wide Wheels.

3.3 Cup Holder Functionality

Each chair includes a convenient pull-out cup holder located on the armrest. Gently pull it out to place your beverage or small items, and push it back in when not in use.



Figure 5: Integrated Pull-out Cup Holder.

4. MAINTENANCE

The WACASA HDPE Pool Lounge Chairs are designed for zero maintenance due to their durable HDPE material. However, regular cleaning is recommended to maintain appearance.

4.1 Cleaning

- Wipe down with a damp cloth and mild soap as needed.
- Rinse thoroughly with water to remove any soap residue.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the material.

4.2 Storage

While the chairs are weather-resistant, storing them in a covered area during extreme weather conditions or off-season can extend their lifespan and preserve their appearance.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair feels unstable after assembly.	Screws or bolts are not fully tightened.	Check all connections and tighten screws/bolts securely. Ensure the chair is on a flat, level surface.
Backrest does not stay in position.	Backrest mechanism not fully engaged.	Ensure the backrest is lifted and lowered until it clicks into a secure position. Avoid forcing the mechanism.
Difficulty moving the chair.	Wheels are obstructed or not properly installed.	Check wheels for debris. Ensure wheels are securely attached and rotate freely. Tilt the chair to engage the wheels properly.
Surface discoloration or stains.	Accumulation of dirt, mildew, or environmental factors.	Clean with mild soap and water. For stubborn stains, a soft brush may be used. Rinse thoroughly.

If you encounter issues not listed here, please contact WACASA customer support for assistance.

6. SPECIFICATIONS

- **Brand:** WACASA
- **Model:** B0GTV7RMX8
- **Color:** Grey
- **Material:** High Density Polyethylene (HDPE)
- **Product Dimensions (L x W x H):** 77.56" x 20.28" x 11.81"
- **Seat Width (between armrests):** 20.28"
- **Seat Height (from ground):** 11.8"
- **Maximum Weight Capacity:** 450 lbs
- **Reclining Positions:** 6
- **Features:** Wheels, Cup Holder, Easy Installation, UV-resistant, Weather-resistant

- **Intended Use:** Outdoor (Poolside, Deck, Backyard)

7. WARRANTY AND SUPPORT

WACASA is committed to providing excellent customer service and support. For any questions, concerns, or assistance with your product, please contact our dedicated customer service team.

Contact Information: Please refer to your purchase documentation or the WACASA official website for the most current contact details.

Protection Plans: Extended protection plans may be available for purchase. Please check with your retailer or WACASA for details on 2-Year, 3-Year, or Complete Protect plans.

Return Policy: This product typically has a 30-day refund/replacement return policy. Please consult your purchase receipt or retailer's policy for specific terms.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question