

OLIXIS AS-XCQ2YGS-BU

OLIXIS Wet Dry Vacuum Cleaner AS-XCQ2YGS-BU User Manual

Model: AS-XCQ2YGS-BU

1. PRODUCT OVERVIEW

The OLIXIS Wet Dry Vacuum Cleaner is a cordless, all-in-one cleaning solution designed for various hard floor types. It combines vacuuming and mopping functions, featuring a self-cleaning system and a dual water tank design for efficient operation.

Key Features:

- **Versatile Cleaning:** Suitable for marble, tile, hardwood, and laminate floors.
- **Dual Power Modes:** ECO mode for surface messes and Turbo mode for deep cleaning.
- **Self-Cleaning System:** Automatic brush roller and duct cleaning on the charging dock.
- **Dual Water Tank Design:** Separate 0.35L clean water tank and 0.5L dirty water tank.
- **Cordless Operation:** Up to 35 minutes runtime, covering approximately 560 sq ft.
- **Maneuverability:** 140° pivoting head, 60° handle tilt, and dual-edge cleaning for tight spaces.
- **Anti-Tangle Brush Roller:** Designed to minimize hair tangles.
- **Smart Display:** LCD screen indicates real-time status, including water levels and faults.

Wet Dry Vacuum Floor Washer

Designed for Action, Built for Convenience



Cord Free



ECO Mode:

- Powerful Suction to Lift Surface Debris.
- Moderate Pressure to Glide on All Floors



Turbo Mode:

- Roots Out Deep-Set Dirt from Carpets.
- Activates Deep-Pile Carpet Cleaning.



Self-Cleaning/ Fault Indicator



Battery Level Indicator



Dual Scrapers

Image: The OLIXIS Wet Dry Vacuum Cleaner highlighting its operational modes and indicators on the display panel.

One Machine. Every Floor.

Marble

Hardwood

Tile

Laminate

Image: The vacuum cleaner demonstrating its ability to clean different hard floor surfaces.

2. SETUP AND ASSEMBLY

Follow these steps to assemble your OLIXIS Wet Dry Vacuum Cleaner before first use.

Assembly Instructions:

1. Unpack all components from the packaging.
2. Insert the handle into the main body of the vacuum until it clicks securely into place.
3. Ensure the clean water tank and dirty water tank are correctly installed.
4. Place the vacuum on its charging dock.
5. Connect the adapter to the charging dock and plug it into a power outlet.
6. Allow the vacuum to fully charge before initial use.

Video: This video demonstrates the step-by-step installation process for the OLIXIS wet dry vacuum mop, showing how to assemble the main components and prepare it for use.

3. OPERATING INSTRUCTIONS

Familiarize yourself with the operational aspects of your OLIXIS Wet Dry Vacuum Cleaner for optimal

cleaning performance.

Filling the Clean Water Tank:

1. Press the release button to detach the clean water tank.
2. Open the tank cap and fill with clean water. You may add a compatible cleaning solution as per the solution's instructions.
3. Close the cap securely and reattach the tank to the main body until it clicks.

Powering On and Mode Selection:

- Press the power button to turn on the vacuum.
- Select between **ECO Mode** for general cleaning and lighter messes, or **Turbo Mode** for stubborn dirt and deep cleaning. The current mode will be displayed on the LCD screen.

Cleaning Operation:

- Guide the vacuum across the floor surface. The 140° pivoting head and 60° handle tilt allow for easy maneuverability around furniture and obstacles.
- Utilize the dual-edge cleaning feature to clean close to walls and corners (less than 0.98 inches on the left edge, less than 0.39 inches on the right edge).
- The smart display will provide real-time status updates, such as low clean water or a full dirty water tank.

Dual Water Tank System



Tank-Compatible
with Cleaning Solutions

0.5 L Dirty Water Tank

* When water level reaches MAX
mark, suction stops.

0.35 L Clean Water Tank

* Flashing the Fault Indicator when insufficient
clean water is detected

Image: A detailed view of the vacuum's dual water tank system, indicating the capacities for clean and dirty water.

Effortless **Reach Thorough** Clean



Image: The vacuum cleaner showcasing its flexible design for reaching difficult areas and cleaning edges.

Video: This video illustrates the operational functions of the OLIXIS wet dry vacuum mop, demonstrating how it vacuums and mops simultaneously on various surfaces.

4. MAINTENANCE AND CARE

Regular maintenance ensures the longevity and optimal performance of your OLIXIS Wet Dry Vacuum Cleaner.

Self-Cleaning System:

- After each use, place the vacuum back on its charging dock.
- Press the dedicated self-cleaning button. The vacuum will automatically clean the brush roller and internal ducts.
- For best results, ensure the dirty water tank is emptied and the clean water tank has sufficient water before initiating self-cleaning.

Emptying the Dirty Water Tank:

1. When the smart display indicates the dirty water tank is full, or after each use, remove the dirty water tank.

- 2. Carefully open the tank and dispose of the dirty water.
- 3. Rinse the tank thoroughly with clean water and allow it to air dry before reattaching.

Brush Roller and Filter Cleaning:

- Periodically inspect the brush roller for tangled hair or debris. Use the included cleaning tool to remove any obstructions.
- Remove and rinse the dry filter as needed. Ensure it is completely dry before reinstalling to prevent damage.



Image: The vacuum cleaner docked for self-cleaning, emphasizing the automated cleaning of the roller and ducts.

5. TROUBLESHOOTING GUIDE

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Vacuum does not turn on	Low battery; Not charged	Ensure the vacuum is fully charged. Check charger connection.

Problem	Possible Cause	Solution
Poor suction or cleaning performance	Dirty water tank full; Clean water tank empty; Clogged brush roller/filter	Empty dirty water tank. Refill clean water tank. Clean brush roller and filter.
Water leakage	Water tanks not properly installed; Tank caps loose	Ensure both clean and dirty water tanks are securely attached and caps are tightened.
Self-cleaning not working	Vacuum not on charging dock; Insufficient water in clean tank; Dirty tank full	Place vacuum correctly on dock. Ensure clean water tank is filled. Empty dirty water tank.

If the issue persists after attempting these solutions, please contact OLIXIS customer support.

6. PRODUCT SPECIFICATIONS

Detailed specifications for the OLIXIS Wet Dry Vacuum Cleaner AS-XCQ2YGS-BU.

Feature	Specification
Brand	OLIXIS
Model Number	AS-XCQ2YGS-BU
Special Feature	Cordless, Rechargeable, Wet/Dry, Wheels
Filter Type	Dry Filter
Surface Recommendation	Hard Floor
Power Source	Battery Powered
Clean Water Tank Capacity	0.35 liters
Dirty Water Tank Capacity	0.5 liters
Recommended Uses	Pet Hair, General Floor Cleaning
Color	Blue
Noise Level	82 Decibels
Number of Power Levels	2 (ECO, Turbo)
Indoor/Outdoor Usage	Indoor
Item Weight	10.38 Pounds
Item Dimensions (L x W x H)	13.05"L x 11.38"W x 43.62"H
Form Factor	Upright
Included Components	Accessory Kit, Adapter, Charging Dock, Crevice Tool, User Manual
Voltage	21.6 Volts
Battery Life / Runtime	Up to 35 minutes



**ETL, FCC, DOE
certificated**

**Up to 35 mins
Runtime**
(Eco: 35 min; Turbo: 25 min)

Cord-Free

560 Sq. Ft.

<82 dB

Wet Dry Vacuum Floor Washer

Pick Your Power. Match Your Style.

Image: An overview of the vacuum cleaner's key performance specifications and certifications.

7. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or contact OLIXIS customer service directly. Keep your purchase receipt for warranty claims.

OLIXIS Customer Service: Please visit the official OLIXIS website or refer to the contact details provided in your product packaging for support.