VASAGLE ULSB502KC01

VASAGLE ELLAN Collection Boho Shoe Bench with Cushion (Model ULSB502KC01) Instruction Manual

1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your VASAGLE ELLAN Collection Boho Shoe Bench with Cushion, Model ULSB502KC01. Please read all instructions carefully before assembly and use to ensure safe and correct operation.




Image 1.1: The VASAGLE ELLAN Collection Boho Shoe Bench with Cushion, showcasing its design in an entryway setting.

2. Safety Information

- Do not exceed the maximum weight limit of**300 lb (136 kg)** for the top seat.
- Ensure the bench is stable and secure in its location to prevent tipping.
- Keep the bench away from heat sources and direct sunlight to maintain its longevity and material integrity.

- Always use the product on a flat, level surface.
- Keep small parts and packaging materials away from children during assembly.




Image 2.1: Detailed dimensions and maximum static weight capacity of the shoe bench.

3. Package Contents

Before beginning assembly, verify that all components listed below are present and undamaged:

- 1 x Shoe Bench (main components)
- 1 x Assembly Kit (includes screws, dowels, and other hardware)
- 1 x Instructions (this manual)

4. Setup and Assembly

Assembly of the VASAGLE ELLAN Collection Boho Shoe Bench is designed to be straightforward. Follow the step-by-step instructions provided in the included assembly kit. Ensure all parts are correctly oriented before tightening fasteners.

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify each part using the labels provided in the assembly kit.
3. Follow the illustrated instructions in the assembly kit to connect the panels, doors, and shelves.
4. Attach the cushion to the top surface of the bench.
5. Once assembled, gently move the bench to its desired location.



Image 4.1: An overview of the shoe bench, illustrating its structure and components.

5. Operating Instructions

The VASAGLE ELLAN Collection Boho Shoe Bench is designed for versatile storage and comfortable seating.

5.1 Storage Functionality

The bench features four cabinet doors, concealing two storage compartments. Each compartment includes an adjustable shelf, offering **5 height options** to accommodate various footwear types, from heels to ankle boots.

- To adjust a shelf, carefully remove it from its current position.
- Align the shelf pins with the desired height holes on the side panels.
- Ensure the shelf is level and securely seated before placing items on it.



Image 5.1: The interior of the shoe bench, demonstrating adjustable shelves for different shoe sizes.

5.2 Seating Functionality

The bench is equipped with a high-density foam-padded cushion, providing a comfortable surface for sitting while changing shoes or for general use.



Image 5.2: Close-up of the comfortable, high-density foam cushion.



Image 5.3: The shoe bench in use, supporting a person tying their shoes.

6. Maintenance

To ensure the longevity and appearance of your shoe bench, follow these maintenance guidelines:

- **Cleaning:** Wipe the surfaces with a**dry cloth**. Avoid abrasive cleaners or harsh chemicals.
- The synthetic rattan surface is water- and stain-resistant, making it easy to clean spills promptly.

- Regularly check all fasteners and tighten them if necessary to maintain structural stability.
- Avoid prolonged exposure to direct sunlight or extreme humidity to prevent material damage.



Image 6.1: The rounded corners of the bench, designed for safety and durability.

7. Troubleshooting

If you encounter any issues with your shoe bench, consider the following common solutions:

- **Instability:** Ensure all screws and fasteners are securely tightened. Verify that the bench is placed on a flat, even surface.
- **Doors not closing properly:** Check if the hinges are correctly aligned and tightened. Ensure no items inside the cabinet are obstructing the door's path.
- **Missing parts:** Refer to the package contents list. If parts are missing, contact customer support with your model number and a description of the missing components.

8. Specifications

Feature	Detail
Model Number	ULSB502KC01
Product Dimensions (D x W x H)	13.8" x 47.2" x 20.9" (35 cm x 120 cm x 53 cm)
Material	MDF (Medium Density Fiberboard), Particleboard, Synthetic Rattan, High-Density Foam, Cationic Fabric
Frame Material	MDF (Medium Density Fiberboard), Particleboard
Color	Natural Brown
Item Weight	46.6 Pounds (21.1 kg)
Maximum Weight Recommendation	300 Pounds (136 kg)
Required Assembly	Yes

9. Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official VASAGLE website. Ensure you have your model number (ULSB502KC01) available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Where can I find the instruction manual for the VASAGLE ELLAN Collection Boho Shoe Bench ULSB502KC01?

You can find the instruction manual for the VASAGLE ELLAN Collection Boho Shoe Bench (Model ULSB502KC01) directly on Manuals+ at the following link: VASAGLE ULSB502KC01 Instruction Manual.Key Assembly and Usage Highlights:Assembly: The bench requires...

Read full answer