

SEDETA 67" L Shaped Desk with Hutch

SEDETA 67" Farmhouse L-Shaped Desk with Hutch Instruction Manual

Model: 67" L Shaped Desk with Hutch

1. INTRODUCTION

This manual provides instructions for the assembly, operation, and maintenance of your SEDETA 67" Farmhouse L-Shaped Desk with Hutch. This desk is designed for home office use, featuring ample storage, a spacious work surface, and an integrated power outlet.

2. SAFETY INFORMATION

- Read all instructions carefully before assembly and use.
- Keep all small parts and packaging materials away from children.
- Assemble the desk on a soft, clean surface to prevent scratches.
- Ensure all fasteners are securely tightened before use. Periodically check and re-tighten fasteners.
- Do not exceed the maximum load capacity of 300 lbs for the desktop.
- Use the desk on a level surface to prevent tipping.
- Do not stand or sit on the desk or hutch.

3. PACKAGE CONTENTS

Your SEDETA L-Shaped Desk with Hutch ships in two separate boxes. Please verify all parts are present and undamaged before beginning assembly. If any parts are missing or damaged, refer to the 'Warranty and Support' section.

Typical contents include:

- Desk panels (desktop, side panels, drawer components, hutch components)
- Hardware kit (screws, dowels, cam locks, drawer slides, handles)
- Integrated power outlet with USB ports

- Assembly instructions manual
- Allen wrench (included)



Figure 3.1: Overall dimensions and shipping information. Note the desk ships in two boxes.

4. ASSEMBLY INSTRUCTIONS

4.1 Preparation

- Clear a spacious area for assembly.
- It is recommended that two people assemble this desk for ease and safety.
- Unpack all components and lay them out. Verify all parts against the parts list in your included manual.
- Keep small number stickers on parts until they are assembled to aid identification.

4.2 Tools Required

- Phillips head screwdriver (not included)
- Allen wrench (included)

4.3 Assembly Steps

Follow the step-by-step instructions provided in the separate assembly manual included with your product. Ensure all diagrams are carefully reviewed for correct orientation of parts. Pay close attention to the drawings as some holes may appear similar.

Your browser does not support the video tag.

Video 4.1: Overview of the Farmhouse L-shaped desk with hutch, demonstrating features and assembly aspects.

5. FEATURES AND OPERATION

5.1 Storage Capacity

The desk offers extensive storage options to help organize your workspace:

- **Four Storage Drawers:** Includes a file drawer compatible with legal size, letter size, and A4 size documents.
- **Four Open Shelves:** Located in the hutch and under the L-section for easy access to books and decor.
- **Storage Cabinet:** A closed cabinet for concealed storage.
- **Two Sliding Doors:** On the hutch, allowing flexible access and concealment of items.

3 Storage Drawers × 2

Find more private storage space for your home office.



Figure 5.1: Detail of the three storage drawers, including the versatile file drawer.



Figure 5.2: Comprehensive view of the desk's large storage capacity.

5.2 Adjustable Shelf

The hutch features an adjustable shelf behind the sliding barn doors, allowing you to customize storage space for items of various heights.

Barn Door with Adjustable Shelf

Meet your diverse storage needs, practical and convenient



Figure 5.3: Adjustable shelf feature within the hutch.

5.3 Integrated Power Outlet

The desk includes a built-in charging station for convenience:

- 4 AC Outlets (120V/12A)
- 2 USB Ports (5V/2A)
- 6.5-foot power cord
- On/Off safety switch for secure power management.

Convenient Charging Station

Include 4 AC Outlets and 2 USB Ports



Figure 5.4: Integrated power outlet with AC and USB ports.

6. MAINTENANCE AND CARE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** Immediately wipe up any spills to prevent damage to the engineered wood.
- **Fasteners:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten as necessary.
- **Placement:** Avoid placing the desk in direct sunlight or near heat sources to prevent warping or discoloration.
- **Weight Distribution:** Distribute weight evenly across the desktop and shelves to maintain stability.

7. TROUBLESHOOTING

- **Wobbly Desk:**
 - a. Ensure all assembly screws and bolts are fully tightened.
 - b. Verify the desk is on a level surface. Adjust furniture glides if applicable.
- **Drawers Not Sliding Smoothly:**

- a. Check that drawer slides are correctly installed and aligned.
 - b. Ensure no obstructions are in the drawer tracks.
 - c. Lubricate drawer slides with a silicone-based lubricant if needed.
- **Power Outlet Not Working:**
 - a. Ensure the desk's power cord is securely plugged into a functional wall outlet.
 - b. Check that the safety switch on the power outlet is in the 'On' position.
 - c. If the outlet has a reset button, press it.
 - **Missing or Damaged Parts:**
 - a. Refer to the 'Warranty and Support' section for contact information to request replacements.

8. SPECIFICATIONS

Feature	Detail
Brand	SEDETA
Model	67" L Shaped Desk with Hutch
Dimensions (D x W x H)	47.2"D x 67"W x 65.4"H
Material	Engineered Wood
Color	Oak
Item Weight	180 Pounds
Load Capacity (Desktop)	300 lbs
Number of Drawers	3 (including 1 file drawer)
Number of Open Shelves	5
Number of Cabinets	1
Power Outlet	4 AC Outlets, 2 USB Ports
Assembly Required	Yes
Recommended Assembly Persons	2

9. WARRANTY AND SUPPORT

SEDETA is committed to providing quality products and customer satisfaction. If your desk arrives damaged, scratched, or with any parts missing, please contact our customer service team for assistance. We will arrange for free replacement parts or provide a partial refund as appropriate.

For support, please refer to the contact information provided with your purchase documentation or visit the official SEDETA store on Amazon: [SEDETA Store](#)