



[Manuals.plus](#) /

› [Flieks](#) /

› Flieks Metal Queen Over Queen Bunk Bed Instruction Manual

Flieks W1580S00340-MZJ

Flieks Metal Queen Over Queen Bunk Bed Instruction Manual

Model: W1580S00340-MZJ | Brand: Flieks

1. INTRODUCTION

Thank you for choosing the Flieks Metal Queen Over Queen Bunk Bed. This manual provides essential information for the safe assembly, operation, and maintenance of your new bunk bed. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

This bunk bed is designed for space-saving and durability, featuring a robust metal construction suitable for teens and adults. It includes integrated ladders and safety guardrails for secure use.

2. SAFETY INFORMATION

WARNING: Failure to follow these warnings and instructions could result in serious injury or death.

- **Maximum Weight Capacity:** The upper bunk is designed to support a maximum weight of **250 lbs**. The lower bunk is designed to support a maximum weight of **500 lbs**. Do not exceed these limits.
- **Mattress Thickness:** The recommended mattress thickness for the upper bed is **6 inches**. The recommended mattress thickness for the bottom bed is **8 inches**. Ensure the mattress on the upper bunk does not exceed the guardrail height.
- **Guardrails:** Always use the guardrails on the upper bunk. Ensure they are properly installed and secured.
- **Ladder Safety:** Always use the ladder for entering and exiting the upper bunk. Do not use the bed as a play structure.
- **Assembly:** This bunk bed requires assembly by at least two adults. Ensure all parts are correctly aligned and all fasteners are securely tightened before use. Periodically check and re-tighten all fasteners.
- **No Jumping:** Do not allow jumping on the bed.
- **Ventilation:** Ensure adequate ventilation around the bed.
- **Children:** The upper bunk is not suitable for children under 6 years of age.
- **Strangulation Hazard:** Never attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to, hooks, belts, and jump ropes.

3. PACKAGE CONTENTS

Before assembly, please ensure all components are present and undamaged. Refer to the parts list provided in your packaging. If any parts are missing or damaged, do not proceed with assembly. Contact customer support immediately. Typical components include:

- Metal frame sections (headboards, footboards, side rails, support beams)
- Metal slats for mattress support
- Ladders (integrated)
- Hardware pack (bolts, nuts, washers, Allen wrench)
- Instruction manual




Image: Front view of the bunk bed frame, illustrating its structural components.

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly requires two adults. Please follow these steps carefully. Do not fully tighten bolts until instructed.

1. **Unpack and Identify Parts:** Lay out all components on a clean, soft surface (e.g., a carpet or blanket) to prevent scratching. Identify each part using the provided parts list.
2. **Assemble Headboards/Footboards:** Attach the vertical support posts to the horizontal frame sections for both the upper and lower beds. Hand-tighten bolts only.
3. **Connect Side Rails:** Attach the side rails to the assembled headboards and footboards for both the upper and lower beds. Ensure the ladder sections are correctly oriented.
4. **Install Slats:** Place the metal slats onto the designated support ledges on both the upper and lower bed frames. Secure them with the provided fasteners. Ensure all slats are evenly spaced and firmly attached.
5. **Secure Upper Bunk:** Carefully lift the upper bunk frame and align it with the support posts of the lower bunk. Secure it using the provided bolts and washers. This step requires two people.

6. **Final Tightening:** Once the entire structure is assembled, go back and securely tighten all bolts and fasteners using the Allen wrench. Do not overtighten.
7. **Check Stability:** Gently shake the assembled bunk bed to ensure it is stable and all connections are secure.



Image: Assembled bunk bed frame, ready for mattresses.

5. OPERATING INSTRUCTIONS (USAGE)

To ensure safe and proper use of your Flieks bunk bed:

- **Mattress Placement:** Place the recommended size and thickness mattresses on both the upper and lower bunks. Ensure the upper mattress does not extend above the guardrails.
- **Ladder Use:** Always use the integrated ladders to access the upper bunk. Face the ladder when climbing up or down.
- **Weight Distribution:** Distribute weight evenly on both bunks. Avoid concentrating weight in one small area.
- **No Horseplay:** Do not allow rough play, jumping, or swinging on the bunk bed.
- **Clearance:** Ensure there is adequate head clearance for the person on the lower bunk.

Size: inch




Image: Bunk bed in use with mattresses and bedding.

6. MAINTENANCE

Regular maintenance will prolong the life and safety of your bunk bed:

- **Cleaning:** Wipe the metal frame with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that could damage the finish.
- **Fastener Check:** Periodically (every 3-6 months) check all bolts, screws, and fasteners to ensure they are tight. Retighten if necessary. Loose fasteners can compromise the bed's stability and safety.
- **Slat Inspection:** Inspect the metal slats for any signs of bending or damage. Replace any damaged slats immediately.
- **Environmental Conditions:** Avoid exposing the bed to extreme humidity or direct sunlight for prolonged periods, which can affect the metal finish.

7. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Squeaking Noises:**

- Check all bolts and fasteners. Tighten any that are loose.
- Ensure slats are properly seated and secured.
- Apply a small amount of lubricant (e.g., silicone spray) to metal-on-metal contact points if tightening does not resolve the issue.

- **Bed Feels Unstable/Wobbly:**

- Verify that all assembly steps were followed correctly.
- Ensure all bolts are fully tightened.
- Check that the bed is placed on a level surface.

- **Missing or Damaged Parts:**

- Do not attempt to assemble the bed with missing or damaged parts.
- Contact Flieks customer support immediately for replacement parts.

8. SPECIFICATIONS

Detailed specifications for the Flieks Metal Queen Over Queen Bunk Bed:

Feature	Specification
Model Number	W1580S00340-MZJ
Size	Queen over Queen
Material	Metal
Overall Product Dimensions (L x W x H)	82.7" x 63" x 63.7"
Upper Bed Weight Capacity	250 lbs
Bottom Bed Weight Capacity	500 lbs
Recommended Upper Mattress Thickness	6 inches
Recommended Bottom Mattress Thickness	8 inches
Number of Slats (Each Bed)	20
Color	Black
Assembly Required	Yes



Image: Dimensional drawing of the bunk bed.

9. WARRANTY INFORMATION

Flieks provides a limited warranty for this product against manufacturing defects. The warranty period typically covers structural components and is valid from the date of purchase. Please retain your proof of purchase for warranty claims. For specific warranty terms and conditions, refer to the warranty card included with your product or visit the official Flieks website.

10. CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact our customer support team:

- **Website:** [Visit the Flieks Store on Amazon](#)
- **Email:** support@flieks.com (Example email, please refer to your product packaging for actual contact details)
- **Phone:** 1-800-XXX-XXXX (Example phone, please refer to your product packaging for actual contact details)

Our customer service representatives are available to assist you during business hours.