

Sluban M38-P8052C

Sluban Garfield Lasagna Construction Set M38-P8052C Instruction Manual

Model: M38-P8052C

1. PRODUCT OVERVIEW

The Sluban Garfield Lasagna Construction Set (Model M38-P8052C) is a building block set designed for children aged 6 to 12 years. It allows for the construction of a lasagna box featuring the Garfield character. The set includes an interactive mechanism that enables the box lid to open and close, revealing the Garfield figure inside.

This set contains 250 pieces made from high-quality ABS plastic, along with an exclusive Garfield figure and various decorative food accessories such as tomatoes and vegetables. Once assembled, the model measures approximately 12 cm (4.72 inches) in width and 16.1 cm (6.34 inches) in height.



Figure 1: Assembled Garfield Lasagna Construction Set with the lid open.

2. SAFETY INFORMATION

- **WARNING: CHOKING HAZARD** - Small parts. Not suitable for children under 36 months (3 years) due to potential choking risks.
- Adult supervision is recommended during assembly and play, especially for younger children within the recommended age range.
- Keep all packaging materials away from children to prevent suffocation.
- Do not ingest any parts of the construction set.
- Inspect all pieces regularly for damage. Discontinue use if any parts are broken or cracked.

3. PACKAGE CONTENTS

The Sluban Garfield Lasagna Construction Set package includes:

- 250 x ABS plastic building blocks and decorative elements.
- 1 x Exclusive Garfield figure.
- 1 x Instruction booklet for assembly.



Figure 2: Retail packaging of the Sluban Garfield Lasagna Construction Set.

4. ASSEMBLY INSTRUCTIONS

Follow the step-by-step instructions provided in the included instruction booklet to assemble your Sluban Garfield Lasagna Construction Set. The assembly process typically involves:

1. **Unpacking:** Carefully remove all pieces from the packaging.
2. **Sorting:** It is recommended to sort the building blocks by color or shape to facilitate assembly.
3. **Following the Booklet:** Refer to the detailed diagrams and instructions in the assembly booklet. Each step will guide you on which pieces to connect and where.
4. **Connecting Pieces:** Ensure pieces are firmly connected to create a stable structure.
5. **Attaching the Crank:** Pay close attention to the instructions for attaching the interactive crank mechanism.
6. **Adding Details:** Attach the Garfield figure and decorative food elements as indicated in the final

steps.

If you encounter any difficulties, re-examine the instruction booklet or refer to the product images for visual guidance.




Figure 3: Side view of the assembled set, illustrating its dimensions.

5. OPERATING INSTRUCTIONS

The Sluban Garfield Lasagna Construction Set features an interactive mechanism to open and close the lasagna box lid.

1. **Locate the Crank:** Identify the small crank handle located on the side of the assembled lasagna box.
2. **Opening the Lid:** Gently turn the crank in one direction (e.g., clockwise) to raise the lid of the lasagna box. This action will reveal the Garfield figure inside.
3. **Closing the Lid:** Turn the crank in the opposite direction (e.g., counter-clockwise) to lower and close the lid of the lasagna box.

Operate the crank smoothly and avoid excessive force to prevent damage to the mechanism.

6. MAINTENANCE

To ensure the longevity and cleanliness of your Sluban Garfield Lasagna Construction Set, follow these maintenance guidelines:

- **Cleaning:** Wipe the assembled model and individual pieces with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the set in a cool, dry place away from direct sunlight and extreme temperatures to prevent material degradation.

- **Inspection:** Periodically check all connections and the crank mechanism for any signs of wear or looseness.

7. TROUBLESHOOTING

If you encounter issues with your construction set, consider the following:

- **Missing Pieces:** Double-check the packaging and surrounding area. If a piece is genuinely missing, contact Sluban customer support (refer to Section 9).
- **Difficulty Assembling:** Review the instruction booklet carefully, paying attention to the orientation of pieces. Sometimes, a piece may appear similar to another but has a slightly different connection point.
- **Crank Mechanism Not Working:** Ensure all parts of the crank mechanism are correctly assembled and not obstructed by other blocks. Check for any loose connections.
- **Loose Connections:** Press pieces firmly together until they click into place.

8. SPECIFICATIONS

Feature	Specification
Model Number	M38-P8052C
Brand	Sluban
Theme	Garfield Lasagna
Number of Pieces	250
Material	ABS plastic
Assembled Dimensions (W x H)	12 cm x 16.1 cm (4.72 in x 6.34 in)
Item Weight	400 Grams
Recommended Age	6-12 Years (Manufacturer Minimum Age: 36 months)
Educational Objective	Development of fine motor skills
Special Features	Interactive crank mechanism, Movable joints

9. WARRANTY AND SUPPORT

Sluban products are manufactured to high-quality standards. For information regarding product warranty, returns, or customer support, please refer to the contact details provided on the product packaging or visit the official Sluban website. Please retain your proof of purchase for any warranty claims.