

[Manuals.plus](#) /

› [TABWEE](#) /

› TABWEE K10 Kids Tablet User Manual

TABWEE K10

TABWEE K10 Kids Tablet User Manual

Model: TABWEE K10

1. INTRODUCTION

Welcome to the TABWEE K10 Kids Tablet user manual. This guide provides essential information for setting up, operating, maintaining, and troubleshooting your new tablet. Please read this manual thoroughly to ensure optimal performance and a safe user experience for your child.

2. PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 * K10 Kids Tablet
- 1 * Shockproof Case
- 1 * Stylus
- 1 * Type-C Cable
- 1 * User Guide (this document)

3. PRODUCT OVERVIEW

The TABWEE K10 is a 10-inch Android 15 tablet designed for children, featuring advanced parental controls, a durable shockproof case, and a blue light filtering HD screen. It comes with 12GB RAM (4GB physical + 8GB virtual) and 64GB ROM, expandable up to 2TB via MicroSD card.



Image: Front and back view of the TABWEE K10 Kids Tablet in its pink shockproof case.

4. SETUP GUIDE

4.1 Initial Charging

Before first use, fully charge the tablet using the provided Type-C cable and a compatible power adapter (not included). The battery capacity is 5000 mAh, offering approximately 6-8 hours of continuous use.



Image: The TABWEE K10 Kids Tablet connected to a charger via its Type-C port.

4.2 Power On/Off

- **To Power On:** Press and hold the power button until the screen lights up.
- **To Power Off:** Press and hold the power button, then select "Power Off" from the options.
- **To Restart:** Press and hold the power button, then select "Restart" from the options.

4.3 Initial Configuration

Upon first power-on, follow the on-screen prompts to:

1. Select your language.
2. Connect to a Wi-Fi network (supports WiFi 6 for stable connection).
3. Set up your Google account or create a new one.
4. Configure parental controls (see Section 5.1 for details).

5. OPERATING INSTRUCTIONS

5.1 Parental Control Setup

The TABWEE K10 features an integrated parental control application. This allows you to manage your

child's digital environment securely.

- **Content Filtering:** Block inappropriate websites and applications.
- **Screen Time Management:** Set daily limits for tablet usage.
- **Application Management:** Control which applications your child can access.
- **Account Configuration:** Create and manage child profiles.



Image: A child interacting with the TABWEE K10 tablet using the included stylus, highlighting its child-friendly design.



Image: A parent and child using the TABWEE K10 tablet, with a smartphone displaying the parental control interface, illustrating content filtering and time limit settings.

5.2 Using the Stylus

The included stylus allows for precise interaction with the tablet screen, ideal for drawing, writing, and

educational games. Ensure the stylus is used gently to avoid scratching the screen.

5.3 Display Features

The 10.1-inch IPS HD screen (1280x800 resolution) features Low Blue Light technology to protect your child's eyes by intelligently adjusting brightness and reducing blue light emission.



Image: The TABWEE K10 tablet screen showing a colorful, child-friendly interface with various educational applications, emphasizing the visual quality.

5.4 Camera Usage

The tablet is equipped with two HD cameras: a 2MP front camera and a 5MP rear camera. These are suitable for online classes, homework photography, and video calls.

5.5 Storage Expansion

The tablet has 64GB of internal storage. You can expand this up to 2TB using a MicroSD card (not included) for additional videos, games, and applications.

6. MAINTENANCE AND CARE

6.1 Cleaning the Tablet

- Use a soft, lint-free cloth to clean the screen and body.
- For stubborn marks, slightly dampen the cloth with water or a screen cleaner.
- Avoid using harsh chemicals, abrasive materials, or excessive moisture.

6.2 Shockproof Case

The included ecological silicone shockproof case with reinforced corners protects the tablet from drops and impacts. Ensure the case is properly fitted at all times.



Image: The TABWEE K10 Kids Tablet in its pink shockproof case, demonstrating the integrated kickstand for hands-free viewing.

6.3 Battery Care

- Charge the tablet regularly, but avoid leaving it fully charged or fully discharged for extended periods.
- Use only the provided Type-C cable for charging.
- Do not expose the tablet to extreme temperatures.

7. TROUBLESHOOTING

7.1 Tablet Not Turning On

- Ensure the tablet is sufficiently charged. Connect it to a charger for at least 30 minutes.
- Press and hold the power button for 10-15 seconds to force a restart.

7.2 Wi-Fi Connection Issues

- Check if Wi-Fi is enabled in the tablet's settings.
- Restart your Wi-Fi router.
- Forget the network and reconnect, ensuring the correct password is entered.

- Ensure the tablet is within range of the Wi-Fi signal.

7.3 Slow Performance

- Close unnecessary background applications.
- Clear cache and data for frequently used apps.
- Ensure there is sufficient free storage space.
- Restart the tablet.

7.4 Parental Control Issues

- Verify that the parental control settings are correctly configured.
- Check for any updates to the parental control application.
- Ensure the tablet's date and time are accurate, as this can affect time-based restrictions.

8. SPECIFICATIONS

Feature	Detail
Model Name	TABWEE K10
Operating System	Android 15
Processor	Quad-Core 2.0 GHz (Rockchip)
RAM	12 GB (4GB physical + 8GB virtual)
Internal Storage	64 GB
Expandable Storage	Up to 2 TB via MicroSD
Screen Size	10.1 Inches
Display Resolution	1280 x 800 Pixels (IPS HD)
Battery Capacity	5000 mAh (Lithium-polymer)
Battery Life	Approx. 8 hours
Connectivity	WiFi 6 (802.11ax), Bluetooth
Cameras	Front: 2 MP, Rear: 5 MP
Dimensions (L x W x Thickness)	24.1 x 16.1 x 0.9 cm
Special Features	Advanced Parental Control, Shockproof Case, Low Blue Light Screen

9. WARRANTY AND SUPPORT

9.1 Product Warranty

The TABWEE K10 Kids Tablet comes with a **4-year manufacturer's warranty**. Please retain your proof of purchase for warranty claims. This warranty covers manufacturing defects under normal use.

9.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact TABWEE customer support

through the official TABWEE store on Amazon or refer to the contact information provided in your purchase documentation.

You can visit the official TABWEE store for more information: [TABWEE Store](#)

10. SAFETY INFORMATION

- Do not attempt to disassemble or repair the tablet yourself.
- Keep the tablet away from water and other liquids.
- Avoid exposing the tablet to direct sunlight or high temperatures for prolonged periods.
- Supervise young children during tablet usage, especially when charging.
- Use only approved accessories.