

[Manuals.plus](#) /

› [LEEMC](#) /

› LEEMC S12 Wireless Earbuds User Manual

LEEMC S12

LEEMC S12 Wireless Earbuds User Manual

Model: S12

INTRODUCTION

Thank you for choosing the LEEMC S12 Wireless Earbuds. These earbuds are designed to provide a high-fidelity audio experience with features like Environmental Noise Canceling (ENC) for clear calls, IPX7 waterproofing for active lifestyles, and an extended 50-hour playtime. This manual will guide you through the setup, operation, and maintenance of your new earbuds to ensure optimal performance and longevity.

PACKAGE CONTENTS

Please check the package for the following items:

- LEEMC S12 Wireless Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual
- Ear Tips (various sizes, typically pre-installed medium)

PRODUCT OVERVIEW

Familiarize yourself with the components of your LEEMC S12 Wireless Earbuds.



Image: A single LEEMC S12 wireless earbud in green, held by a hand. The earbud features an over-ear hook design for secure fit and an in-ear tip. The charging case is visible in the background, slightly out of focus. This image illustrates the physical design and color of the earbud.

Earbud Components:

- **Ear Hook:** Provides a secure fit, especially during sports and vigorous activities.
- **Multi-function Touch Control Area:** For playback, calls, and voice assistant.
- **LED Indicator:** Displays status (pairing, charging, connected).
- **Microphone:** For calls and voice commands, featuring ENC noise canceling.
- **Charging Contacts:** For charging inside the case.
- **Ear Tip:** Ensures comfort and sound isolation.

Charging Case Components:

- **Earbud Charging Slots:** Holds and charges the earbuds.
- **LED Digital Display:** Shows the charging case battery percentage.
- **USB-C Charging Port:** For charging the case.

SETUP

1. Initial Charging

1. **Charge the Case:** Connect the provided USB charging cable to the USB-C port on the charging case and a power source (e.g., computer USB port, wall adapter). The LED digital display on the case will show the battery percentage increasing.
2. **Charge the Earbuds:** Place the earbuds into their respective charging slots in the case. Ensure the charging contacts align. The earbuds will begin charging automatically. The LED indicator on the earbuds may show a light during charging and turn off when fully charged.
3. **Full Charge:** For first-time use, fully charge both the charging case and the earbuds.

2. Bluetooth Pairing

1. **Power On:** Open the charging case. The earbuds will automatically power on and enter pairing mode. The LED indicator on one earbud will flash, indicating it is ready to pair.
2. **Activate Bluetooth:** On your device (smartphone, tablet, computer), enable Bluetooth.
3. **Select Device:** Search for "S12" in the list of available Bluetooth devices and select it to connect.
4. **Connection Confirmation:** Once connected, you will hear an audible confirmation, and the LED indicator on the earbuds will turn off or flash slowly.
5. **Automatic Reconnection:** After the initial pairing, the earbuds will automatically connect to the last paired device when removed from the charging case and Bluetooth is enabled on your device.

Note: If pairing fails, place the earbuds back into the charging case, close the lid, and then repeat the pairing steps.

OPERATING INSTRUCTIONS

The LEEMC S12 earbuds feature touch controls for easy management of audio and calls.

Power On/Off

- **Power On:** Open the charging case, or long-press the touch control area for 3 seconds if earbuds are outside the case and off.
- **Power Off:** Place earbuds back into the charging case and close the lid, or long-press the touch control area for 5 seconds.

Music Playback

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap the right earbud.
- **Previous Track:** Double tap the left earbud.
- **Volume Up:** Triple tap the right earbud.
- **Volume Down:** Triple tap the left earbud.

Call Management

- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Long-press on either earbud for 2 seconds.

Voice Assistant

- **Activate Voice Assistant:** Long-press on either earbud for 2 seconds (when not on a call).

MAINTENANCE

Proper care ensures the longevity and performance of your earbuds.

Cleaning

- Regularly clean the ear tips and charging contacts with a soft, dry, lint-free cloth.
- Do not use harsh chemicals, cleaning solvents, or strong detergents.
- Ensure no moisture enters the earbud openings.

Storage

- Store the earbuds in their charging case when not in use to protect them and keep them charged.
- Avoid storing in extreme temperatures (hot or cold) or high humidity.

Water Resistance (IPX7)

- The earbuds are IPX7 waterproof, meaning they can withstand immersion in water up to 1 meter for 30 minutes.
- This rating applies to the earbuds only, not the charging case.
- Do not intentionally submerge the charging case in water.
- Ensure earbuds are completely dry before placing them back into the charging case to prevent damage to the charging contacts.

TROUBLESHOOTING

If you encounter issues, try the following solutions:

Earbuds Not Pairing/Connecting

- Ensure both earbuds are charged.
- Place both earbuds back into the charging case, close the lid, wait a few seconds, then open the lid again to re-enter pairing mode.
- Turn off Bluetooth on your device, then turn it back on and try searching for "S12" again.
- Forget/delete "S12" from your device's Bluetooth list and attempt to pair again.
- Try pairing with a different device to rule out device-specific issues.

Only One Earbud Working

- Ensure both earbuds are charged.
- Place both earbuds back into the charging case, close the lid, and then open it again. This often forces them to re-sync.
- If the issue persists, perform a factory reset (refer to specific instructions if available, otherwise try long-pressing both earbuds simultaneously while in the case for 10 seconds).

No Sound or Low Volume

- Check the volume level on both your device and the earbuds.
- Ensure the earbuds are properly seated in your ears.
- Clean any debris from the ear tips and speaker mesh.

Charging Issues

- Ensure the charging cable is securely connected to both the case and the power source.
- Try a different USB-C cable and power adapter.
- Clean the charging contacts on both the earbuds and inside the case.
- Ensure the charging case itself has sufficient power.

SPECIFICATIONS

Model Name	S12
Connectivity	Bluetooth
Ear Placement	In Ear
Noise Control	Environmental Noise Cancellation (ENC)
Water Resistance	IPX7 Waterproof (Earbuds only)
Battery Life (Total)	Up to 50 Hours (with charging case)
Impedance	32 Ohms
Sensitivity	98 dB
Audio Driver Size	14.2 Millimeters
Control Type	Button Control (Touch)
Material	Plastic

SAFETY INFORMATION

- Do not disassemble or modify the product.
- Keep away from extreme temperatures and direct sunlight.
- Avoid dropping or subjecting the earbuds to strong impacts.
- Keep out of reach of children and pets.
- Do not use the earbuds at high volume for extended periods to prevent hearing damage.
- Be aware of your surroundings when using earbuds, especially in traffic or dangerous situations.

WARRANTY AND SUPPORT

LEEMC products are designed for reliability and performance. For warranty information or technical support, please refer to the contact details provided on the product packaging or the official LEEMC website. Please retain your proof of purchase for warranty claims.

