

[Manuals.plus](#) /

› [Tangkula](#) /

› Tangkula 86.5" 3-Seat Patio Wicker Sofa Instruction Manual (Model 75123-HW)

Tangkula 75123-HW

Tangkula 86.5" 3-Seat Patio Wicker Sofa Instruction Manual

Model: 75123-HW

PRODUCT OVERVIEW

This Tangkula patio wicker sectional sofa is designed for outdoor living, offering flexible seating and comfort for your garden, porch, or backyard. The set includes two corner sofas and one armless sofa, allowing for various configurations.



Image: The Tangkula 86.5" 3-seat patio wicker sofa in a grey finish, assembled on a wooden deck, showcasing its full configuration.

Key Features:

- **Modular Seating:** Includes 2 corner sofas and 1 armless sofa for flexible arrangements, convertible between an 86.5" 3-person sofa and a loveseat with an armless chair.
- **Durable Construction:** Features handwoven mix gray PE rattan, which is sunlight resistant and breathable.
- **Comfortable Cushions:** Equipped with 3 seat cushions, 3 back cushions, and 2 pillows, all sponge-filled for comfort. Zippered seat cushion covers are removable for cleaning.
- **Sturdy Frame:** Constructed with a heavy-duty metal frame, supporting up to 400 lbs per seat. Includes L-shaped foot pads for stability.
- **Convenient Design:** Smooth acacia wood armrests with built-in cup holders.

SETUP AND ASSEMBLY

Assembly of the Tangkula patio wicker sofa is required. Please ensure all components are present before beginning. It is recommended to assemble the unit on a soft, clean surface to prevent damage.

Components Included:

- 2 x Corner Sofas
- 1 x Armless Sofa
- 3 x Seat Cushions
- 3 x Back Cushions
- 2 x Throw Pillows
- Sofa Clips
- Assembly Hardware (bolts, washers, Allen wrench)

Refer to the detailed assembly instructions provided in the product packaging for step-by-step guidance. Ensure all connections are tightened securely before use.

OPERATING INSTRUCTIONS

The modular design of this sofa allows for flexible arrangement to suit your space and needs.

Configuration Options:

- **3-Seat Sofa:** Combine all three pieces (two corner sofas and one armless sofa) to form a continuous 86.5" sofa. Use the included sofa clips to secure the pieces together, preventing separation during use.
- **Loveseat and Armless Chair:** Separate the components into a two-seater loveseat and a standalone armless chair for alternative layouts.



3-Person Sofa

Enhance social interaction



Premium Mix Gray PE Rattan



◀ Sofa Clips



Loveseat + Armless Chair

Offer personal space



Image: Demonstrates the modularity of the sofa, showing both the full 3-person configuration and a separated loveseat with an armless chair, highlighting the sofa clips for secure connection.

Using Cup Holders:

The acacia wood armrests feature built-in cup holders for convenient placement of beverages. Ensure cups are placed securely to prevent spills.



Acacia Wood Armrests



2 Convenient Cup Holders



Heavy-Duty Metal Frame

Image: Detailed view of the acacia wood armrest, showing the integrated cup holder and the texture of the PE rattan.

CARE AND MAINTENANCE

Proper care will extend the lifespan and maintain the appearance of your patio sofa.

- **Weather Protection:** Avoid prolonged exposure to rain. Consider using a protective cover during inclement weather or when not in use for extended periods.
- **Wood Care:** Treat the acacia wood armrests with maintenance oil (not included) regularly to preserve their natural appearance and prevent weathering.
- **Cushion Cleaning:** The seat cushion covers are zippered and removable for easy cleaning. Follow the care instructions on the cushion labels for washing.
- **Rattan Cleaning:** Wipe the PE rattan with a damp cloth and mild soap solution. Rinse thoroughly and allow to air dry.
- **Safety:** Keep the sofa away from open flames or high heat sources. Supervise children and pets to avoid entrapment risks.

TROUBLESHOOTING

If you encounter any issues with your Tangkula patio sofa, please review the following common points:

- **Stability Issues:** Ensure all assembly bolts are securely tightened. Check that the L-shaped foot pads are properly positioned on a level surface.
- **Cushion Deformity:** Allow new cushions time to fully expand after unpacking. If a cushion remains deformed, try fluffing it or exposing it to warm, dry air.
- **Damaged Components:** If any parts arrived damaged or become damaged during assembly, do not proceed with assembly. Contact customer support for replacement parts.

For problems not addressed here, please contact Tangkula customer support.

PRODUCT SPECIFICATIONS



Image: Technical drawing illustrating the overall dimensions of the 3-seat sofa (86.5" width), and individual dimensions for the armless sofa and corner sofa components.

Feature	Detail
---------	--------

Feature	Detail
Brand	Tangkula
Model Number	75123-HW
Overall Dimensions (3-Seater Sofa)	27" (L) x 86.5" (W) x 26.5" (H)
Armless Sofa Dimensions	27" (L) x 24.5" (W) x 26.5" (H)
Corner Sofa Dimensions	27" (L) x 31" (W) x 26.5" (H)
Seat Height	12"
Backrest Height	14.5"
Each Seat Dimensions	24.5" (W) x 24.5" (D)
Weight Capacity (Each Seat)	400 lbs
Net Weight	71 lbs
Material	PE Rattan, Metal, Acacia Wood, Sponge, Polyester
Color	Mix Grey (Rattan), Grey (Cushion)
Assembly Required	Yes
Indoor/Outdoor Usage	Outdoor

WARRANTY INFORMATION

Specific warranty details for the Tangkula 86.5" 3-Seat Patio Wicker Sofa are not provided in this manual. For information regarding product warranty, please refer to the documentation included with your purchase or contact Tangkula customer support directly.

CUSTOMER SUPPORT

For assistance with assembly, missing parts, product inquiries, or troubleshooting, please contact Tangkula customer support.

Manufacturer: Tangkula

Please have your model number (75123-HW) and purchase details ready when contacting support.