

[Manuals.plus](#) /

› [Remington](#) /

› Remington Balder Head & Beard Shaver XR8000US User Manual

Remington XR8000US

Remington Balder Head & Beard Shaver XR8000US User Manual

Model: XR8000US

1. INTRODUCTION

Thank you for purchasing the Remington Balder Head & Beard Shaver. This versatile grooming tool is designed for efficient head shaving and precise beard trimming, offering both wet and dry use. Please read this manual thoroughly before first use to ensure safe and optimal performance of your device.




Image: The Remington Balder Head & Beard Shaver, highlighting its dual functionality for head and beard grooming.

2. IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should always be observed, including the following:

- Do not reach for an appliance that has fallen into water. Unplug it immediately.
- Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Except when charging, always unplug this appliance from the electrical outlet immediately after using.
- Unplug this appliance before cleaning.

- This appliance is for household use only.
- Close supervision is necessary when this appliance is used by, on, or near children or invalids.
- Use this appliance only for its intended household use as described in this manual.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged.

3. PRODUCT OVERVIEW AND COMPONENTS

Your Remington Balder Head & Beard Shaver comes with several components to facilitate a complete grooming experience.



Image: What's included in the box: the shaver unit, rotary head attachment, T-blade trimmer attachment, various guide combs, a cleaning brush, and a USB charging cable.

Key Features:

- **5 Flexing Blades:** Designed to adapt to the contours of your head for a close shave.
- **DURADRIIVE Motor:** Provides powerful performance, especially for thick hair.
- **T-Blade Trimmer:** For precise beard trimming, detailing, and styling.
- **Adjustable Combs:** Ranging from 0.4mm to 5mm for the T-blade, plus additional guide combs (6mm, 8mm, 12mm, 14mm, 16mm, 18mm).
- **80 Minutes Runtime:** Cordless operation with a long-lasting battery.
- **100% Waterproof:** Suitable for wet or dry use, including in the shower.
- **Less Mess Hair Pocket:** Captures trimmings for easier cleanup.
- **Travel Lock:** Prevents accidental activation during travel.

4. SETUP

4.1 Initial Charging

Before using your shaver for the first time, it is recommended to fully charge it. The shaver uses a USB-C charger.

1. Connect the USB charging cable to the shaver's charging port.
2. Plug the other end of the USB cable into a compatible USB power adapter (not included) or a USB port.
3. The 3-stage LED indicators will show the charging status. A full charge provides approximately 80 minutes of runtime.

OVER 1 MONTH'S USAGE³


80 minutes of cordless runtime gives you the freedom to shave when you want.



**80
MINS
RUNTIME**



**USB-C
CHARGING**



³Based on 2 minutes usage, every day

Image: The shaver's battery indicator and USB-C charging port, illustrating its 80-minute runtime.

4.2 Attaching/Detaching Heads

The shaver features interchangeable heads for different grooming needs.

- To attach a head (rotary shaver or T-blade trimmer), align the head with the shaver body and gently push until it clicks into place.
- To detach a head, firmly grasp the shaver body and the attachment head, then pull them apart. The magnetic connection makes this easy.

5. OPERATING INSTRUCTIONS

5.1 Head Shaving (Rotary Head)

For best results, ensure your hair is short (0.5mm or less) before using the rotary head.

1. Attach the 5-blade rotary head to the shaver body.

2. Press the power button to turn on the shaver.
3. Gently press the shaver against your scalp and move it in small, circular motions.
4. For thicker hair or a faster shave, press the Turbo Boost button (if available) to increase motor speed.
5. The flexible blades will contour to your head for a smooth finish.

5 FLEXING BLADES FOR A FAST SHAVE

Shave your whole head
in under 2 minutes¹



¹Based on 1 day growth (0.5mm)

Image: The 5 flexing blades of the rotary shaver head, designed for a close and comfortable shave.

Your browser does not support the video tag.

Video: An official Remington video demonstrating the features and use of the Balder Head & Beard Shaver.

5.2 Beard Trimming (T-Blade Trimmer)

Use the T-blade trimmer for precise styling and maintaining your beard.

1. Detach the rotary head and attach the T-blade trimmer.
2. Select the desired guide comb (0.4mm-5mm adjustable, or fixed combs like 6mm, 8mm, 12mm, 14mm, 16mm, 18mm) and attach it to the T-blade.
3. Turn on the shaver.

4. Trim your beard by moving the trimmer against the direction of hair growth. Use without a comb for precise edging and detailing.

T-BLADE TRIMMER FOR PRECISE DETAILING

Perfect for beards, sideburns,
necklines & hard-to-reach areas.



0.4 – 5mm
ADJUSTABLE
COMB



Image: The T-blade trimmer attachment, ideal for precise detailing and beard styling, shown with an adjustable comb.

6 COMBS FOR TOTAL CONTROL

From stubble to shape up.
The right length for
any style.



Image: A selection of 6 guide combs and the adjustable T-blade comb, offering various length settings for total control over your style.

5.3 Wet or Dry Use

Your shaver is 100% waterproof (IPX7 rated), allowing for versatile use.

- **Dry Shave:** Use on dry skin for a quick and convenient shave.
- **Wet Shave:** Use with shaving gel or foam for a more comfortable and smoother experience, especially for sensitive skin. It can also be used in the shower.

WET OR DRY USE

100% waterproof design
lets you shave in the
shower or on the go.



100%
WATERPROOF



Image: The shaver's waterproof design is highlighted by water splashes, confirming its suitability for wet or dry use.

6. MAINTENANCE

6.1 Cleaning Your Shaver

Regular cleaning ensures optimal performance and hygiene.

1. Turn off and unplug the shaver before cleaning.
2. Detach the shaver head (rotary or T-blade).
3. Empty the hair pocket by tapping out accumulated hair.
4. Rinse the shaver head and the hair pocket under running water. The shaver is 100% waterproof, allowing for easy rinsing.
5. Use the provided cleaning brush to remove any stubborn hair particles from the blades and internal components.
6. Allow all parts to air dry completely before reassembling or storing.

6.2 Blade Replacement

For continued optimal performance, it is recommended to replace the shaver heads periodically. Replacement parts information may be found on the official Remington website or by contacting customer support. Please note that replacement rotary head information is not explicitly listed in the product details provided.

7. TROUBLESHOOTING

- **Shaver not turning on:** Ensure the shaver is fully charged. If it's charged, check if the travel lock is activated (indicated by a lock icon). Press and hold the power button for a few seconds to deactivate the travel lock.
- **Poor shaving performance:** Clean the shaver head thoroughly to remove any hair buildup. Ensure the blades are not dull; consider replacing the shaver head if performance does not improve after cleaning.
- **Shaver pulling hair:** This can occur if the battery is low or if the hair is too long for the rotary head. Recharge the shaver or pre-trim longer hair with the T-blade attachment before using the rotary head.
- **Charging issues:** Ensure the USB-C cable is securely connected to both the shaver and the power source. Try a different USB power adapter if necessary.

8. SPECIFICATIONS

Feature	Detail
Model Number	XR8000US
Power Source	Battery Powered
Battery Type	Lithium-Ion
Battery Average Life	80 minutes
Head Type	Rotary
Number of Blades	5
Waterproof Rating	100% Waterproof (IPX7)
Item Weight	16 ounces
Included Components	Rotary Attachment, T-Blade Trimmer Attachment, Guide Combs, Charger

9. WARRANTY AND SUPPORT

Your Remington Balder Head & Beard Shaver comes with a **2-Year Guarantee** from the manufacturer, Spectrum Brands. This warranty covers defects in materials and workmanship under normal household use.

For warranty claims, technical support, or to inquire about replacement parts, please visit the official Remington website or contact their customer service department. Keep your proof of purchase for warranty validation.

You can find more information and support at the [Remington Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GV5T3YVC>

More documents and user manuals: **<https://manuals.plus/>**