Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bellemave FST00191-FT-BB1

Bellemave Full Triple Bunk Bed with Slide Instruction Manual

Model: FST00191-FT-BB1

1. Safety Information

Please read and understand all instructions before assembling and using this bunk bed. Failure to follow these instructions can result in serious injury.

- **Maximum Weight Capacity:** Each bed is designed to support a maximum weight of 250 pounds. Do not exceed this limit.
- **Age Recommendation:** The top bunk is not suitable for children under 6 years of age.
- **Guardrails:** Always use the guardrails on the top bunk. Ensure they are properly installed and secured.
- **Ladder and Slide:** Use the ladder for entering and exiting the upper bunks. Use the slide only as intended, one person at a time.
- **Prohibited Activities:** Do not allow jumping on the bed. Do not attach or hang items to any part of the bunk bed that are not designed for use with the bed, for example, but not limited to, hooks, belts, and jump ropes.
- **Ventilation:** Ensure adequate ventilation around the bed.
- **Assembly:** This product requires adult assembly. Two people are recommended for safe and efficient assembly.

2. Setup and Assembly

Before beginning assembly, ensure all parts are present and undamaged. Clear a spacious area for assembly. Standard household tools (e.g., Phillips head screwdriver, Allen wrench) may be required.

1. Unpack all components and verify against the parts list provided in your packaging.
2. Follow the step-by-step diagrams in your included assembly guide. Attach the main frame components securely.
3. Install the bed slats for each bunk, ensuring they are evenly spaced and firmly attached.
4. Attach the guardrails to the top bunk and the ladder to the designated side.
5. Securely attach the slide to the lower bunk frame as per the instructions.
6. Once assembled, double-check all bolts and fasteners to ensure they are tight.

Product Dimensions Overview:




Image: Detailed dimensions of the Bellemave Full Triple Bunk Bed with Slide, showing overall length, width, height, and individual bunk and slide measurements.

3. Operating Instructions

This Bellemave Full Triple Bunk Bed is designed to provide three sleeping surfaces and an integrated slide for recreational use.

- **Mattress Usage:** Use only Full-size mattresses on all three bunks. Ensure the mattress thickness does not exceed the maximum recommended height for the top bunk to maintain guardrail effectiveness.
- **Ladder Access:** Always use the provided ladder to access the middle and top bunks. Ensure a firm grip and stable footing.
- **Slide Usage:** The slide is intended for single-person use at a time. Ensure the landing area is clear before sliding.
- **Top Bunk Storage:** The top bunk can also be utilized for storage when not in use as a sleeping area, provided the weight limit is respected.



Image: The Bellemave Full Triple Bunk Bed with Slide, fully assembled with mattresses and bedding, situated in a bedroom setting.




Image: A close-up view of the integrated slide component of the Bellemave Full Triple Bunk Bed, showing its design and attachment to the bed frame.

4. Maintenance

Regular maintenance will ensure the longevity and safety of your Bellemave bunk bed.

- **Cleaning:** Wipe the metal frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Fastener Check:** Periodically (e.g., every 3 months) check all bolts, screws, and fasteners to ensure they are tight. Re-tighten if necessary.
- **Guardrail and Ladder Inspection:** Regularly inspect guardrails, ladder steps, and slide for any signs of wear, damage, or loose connections. Replace or repair any damaged parts immediately.
- **Structural Integrity:** Ensure the bed remains stable and level. Adjust if any wobbling or instability is detected.




Image: A detailed view of the metal frame construction and slat support system of the Bellemave bunk bed, highlighting its structural components.

5. Troubleshooting

If you encounter any issues with your bunk bed, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Bed is wobbly or unstable.	Loose fasteners or uneven assembly.	Check and tighten all bolts and screws. Ensure the bed is on a level surface.
Squeaking noises.	Loose connections or friction between metal parts.	Re-tighten all fasteners. Apply a small amount of lubricant (e.g., silicone spray) to contact points if necessary.
Ladder or slide feels loose.	Mounting bolts are not fully tightened.	Inspect and tighten the bolts securing the ladder and slide to the bed frame.

6. Specifications

- **Model Number:** FST00191-FT-BB1
- **Brand:** Bellemave

- **Size:** Full
- **Material:** Metal
- **Product Dimensions (L x W x H):** 78.7" x 56.7" x 77.5"
- **Item Weight:** 68 pounds
- **Maximum Weight Recommendation (per bed):** 250 pounds
- **Included Components:** Guardrails, Slats, Ladders, Slide
- **UPC:** 800067034877

For a visual representation of the dimensions, please refer to the diagram in the 'Setup and Assembly' section.

7. Warranty and Support

For any questions regarding assembly, missing parts, or product issues, please contact Bellemave customer support. Refer to your purchase documentation for specific warranty details.
You can visit the official Bellemave store for more information:Bellemave Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GV6CD7GY

More documents and user manuals: **https://manuals.plus/**