

[Manuals.plus](#) /

› [Aeitto](#) /

› Aeitto 1800W Blender & Grinder Combo User Manual

Aeitto B0GVDQ8LMZ

Aeitto 1800W Blender & Grinder Combo User Manual

Model: B0GVDQ8LMZ

INTRODUCTION

Thank you for purchasing the Aeitto 1800W Blender & Grinder Combo. This appliance is designed for efficient blending and grinding tasks in your kitchen, offering versatility for smoothies, ice crushing, and grinding various ingredients. Please read this manual thoroughly before first use to ensure safe operation and optimal performance. Keep this manual for future reference.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before operating the blender.
- Do not immerse the motor base in water or other liquids.
- Unplug from outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter or touch hot surfaces.
- Keep hands and utensils out of container while blending to prevent the possibility of severe injury to persons or damage to the blender. A scraper may be used but only when the blender is not running.
- Blades are sharp. Handle with care.
- Always operate blender with lid in place.
- Do not blend hot liquids in the large blender jar without proper ventilation to prevent pressure buildup.

- Do not use the appliance for other than intended use.
- An overheat protection device is designed to ensure safer use. If the motor overheats, the blender will automatically shut off. Allow it to cool down before resuming operation.

PACKAGE CONTENTS

Verify that all items are included in your package:

- Blender Motor Base (1)
- 68oz. Blender Jar with Blending Blade Assembly (1)
- Tamper (1)
- 28oz. Grinding Cup with Grinding Blade Assembly (1)

PRODUCT OVERVIEW

Familiarize yourself with the components of your Aeitto Blender & Grinder Combo.

68oz. Large Capacity

Perfect for The Whole Family



The Aeitto blender features a black motor base with a silver control panel. The panel includes an 'OFF/ON' switch, a 'PULSE' button, and two rotary dials. The left dial has settings for 40S, 90S, 120S, and 180S. The right dial has settings for START, WARM PUREES, SMOOTHIES, ICE CRUSH, and GRINDS. The clear 68oz. jar is filled with green leafy vegetables, banana slices, and ice cubes. The base is surrounded by fresh fruit (lemons, oranges) and ice cubes.

 13oz	x5	 8oz	x8
 12oz	x6	 7oz	x10
 3oz	x22	 10oz	x7



Two glasses of juice (one orange, one green) and a plate of fruit (lemons, oranges) and ice cubes are shown next to the blender.

Image: The Aeitto 1800W Blender and Grinder Combo, featuring the motor base, 68oz blending jar, and control panel.

Main Components:

- **Motor Base:** Houses the 1800W motor and control panel.
- **68oz. Blender Jar:** Large capacity jar for blending smoothies, juices, and frozen drinks. Equipped with a 6-leaf blending blade.
- **28oz. Grinding Cup:** Smaller cup designed for grinding coffee beans, nuts, and spices. Equipped with a grinding blade.
- **Lids:** Securely cover the blending jar and grinding cup during operation.
- **Tamper:** Used to push down ingredients towards the blades when blending thick mixtures.

Control Panel:

Four Intelligent Preset Programs

Just turn the knob to make your favourite drink



Image: Close-up of the blender's control panel, displaying the ON/OFF switch, speed dial, PULSE switch, and a rotary dial for preset programs (Warm Purees, Smoothies, Ice Crush, Grains).

- **ON/OFF Switch:** Powers the unit on or off.
- **Speed Dial (MIN-MAX):** Adjusts blending speed manually.

- **PULSE Switch:** Provides short bursts of high-speed blending for chopping or quick mixing.
- **Preset Program Dial:** Selects one of four intelligent preset programs: Warm Purees, Smoothies, Ice Crush, and Grains.

SETUP

Before first use, wash all parts that will come into contact with food (blender jar, grinding cup, lids, blades) in warm soapy water, then rinse and dry thoroughly. The motor base should only be wiped clean with a damp cloth.

1. Place the motor base on a clean, dry, and stable surface.
2. Ensure the ON/OFF switch is in the 'OFF' position and the unit is unplugged.
3. **For Blending:** Place the 68oz blender jar onto the motor base, aligning the jar's base with the motor base's coupling. Turn clockwise until it locks securely into place.
4. **For Grinding:** Place the 28oz grinding cup onto the motor base, aligning the cup's base with the motor base's coupling. Turn clockwise until it locks securely into place.
5. Add your ingredients to the jar or cup. Do not overfill beyond the maximum fill line.
6. Securely place the lid onto the jar or cup. Ensure the lid is properly sealed.

OPERATING INSTRUCTIONS

This section details how to use your blender for various tasks.

General Operation:

1. Ensure the blender jar or grinding cup is securely locked onto the motor base and the lid is properly sealed.
2. Plug the power cord into a standard electrical outlet.
3. Turn the ON/OFF switch to the 'ON' position. The indicator light may illuminate.
4. Select your desired operating mode:

Using the Speed Dial (Manual Control):

- Turn the speed dial from MIN to MAX to gradually increase or decrease the blending speed.
- Start with a lower speed and gradually increase as needed for optimal blending.
- For thick mixtures, use the tamper through the lid opening to push ingredients towards the blades.

Using the PULSE Function:

- Flip the PULSE switch for short bursts of high-speed blending.
- This is ideal for chopping ingredients, breaking down large chunks, or for quick mixing.
- Release the switch to stop the pulse action.

Using Preset Programs:

The blender features four intelligent preset programs for common tasks:

- **Warm Purees:** For smooth, warm purees.
- **Smoothies:** Optimized for creating smooth and consistent smoothies.
- **Ice Crush:** Designed to efficiently crush ice for frozen drinks.
- **Grains:** Suitable for grinding grains and other dry ingredients in the grinding cup.

To use a preset program:

1. Turn the preset program dial to the desired program.
2. The blender will automatically run through the program cycle and stop when complete.

After Operation:

1. Turn the ON/OFF switch to the 'OFF' position.
2. Unplug the appliance from the power outlet.
3. Carefully remove the jar or cup from the motor base.
4. Remove the lid and pour out the contents.

CLEANING AND MAINTENANCE

Proper cleaning and maintenance will extend the life of your blender.

Easy to Clean



Image: The left side shows the blender jar undergoing self-cleaning with water. The right side shows blender components, including the jar and grinding cup, placed in a dishwasher for cleaning.

Auto Cleaning Function:

For quick and easy cleaning of the blender jar:

1. Add half warm water and a few drops of dishwashing soap to the blender jar.
2. Secure the lid.
3. Run the blender for 30 to 60 seconds using the speed dial or a short pulse.
4. Rinse the jar thoroughly with clean water.

Dishwasher Safe Parts:

All parts except the motor base are dishwasher safe. Place the blender jar, grinding cup, lids, and tamper on the top rack of your dishwasher.

Cleaning the Motor Base:

- Always unplug the motor base before cleaning.
- Wipe the motor base with a damp cloth. Do not immerse it in water or any other liquid.
- Dry thoroughly after cleaning.

TROUBLESHOOTING

If you encounter issues with your blender, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; ON/OFF switch is off; Jar/cup not properly assembled; Overheat protection activated.	Ensure power cord is securely plugged in. Turn ON/OFF switch to 'ON'. Ensure jar/cup is locked securely onto the base. If motor overheated, unplug and let cool for 15-20 minutes.
Ingredients are not blending smoothly.	Too little liquid; Too many ingredients; Ingredients are too large; Blades are jammed.	Add more liquid. Reduce the amount of ingredients. Cut ingredients into smaller pieces. Use the tamper to push ingredients towards the blades. Use the Pulse function.
Motor smells or makes unusual noise.	Overloading; Overheating.	Reduce ingredients. Unplug and let the motor cool down. Do not operate continuously for extended periods.
Lid leaks during operation.	Lid not properly secured; Jar overfilled.	Ensure lid is firmly pressed onto the jar/cup. Do not fill ingredients above the maximum fill line.

SPECIFICATIONS

Feature	Detail
Brand	Aeitto

Feature	Detail
Model	B0GVDQ8LMZ
Motor Power	1800 Watts
Peak Speed	Up to 25,000 RPM
Blender Jar Capacity	68 oz.
Grinding Cup Capacity	28 oz.
Material	BPA-Free Plastic (Containers)
Dishwasher Safe Parts	Blender Jar, Grinding Cup, Lids (excluding motor base)
Control Type	Manual Speed Dial, Pulse Switch, Preset Programs
Product Dimensions (D x W x H)	7.87"D x 9.06"W x 19.29"H

WARRANTY AND SUPPORT

This product comes with a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including the warranty period and coverage details. For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact Aeitto customer service through the contact information provided in your product documentation or on the official Aeitto website. Please have your model number (B0GVDQ8LMZ) and purchase date ready when contacting support.